



**875-0441-10**

**R632  
GNSS Receiver**

User Guide  
Revision: A5  
June 27, 2022

## Table of Contents

---

Device Compliance, License and Patents.....	4
Terms and Definitions.....	6
Chapter 1: Introduction .....	10
Overview .....	10
Product Overview .....	11
Key Features.....	14
What’s Included in Your Kit.....	15
Chapter 2: Operating the R632 .....	16
Overview .....	16
Powering the Receiver On/Off.....	17
Ports .....	19
SIM and MicroSD Cards .....	20
Connecting to the WebUI .....	23
Upgrading Firmware .....	24
Using the WebUI .....	26
Mounting R632 as a Base Station .....	47
Configuring R632 as a Base Station .....	49
Setting up R632 RTK Output .....	51
Logging Raw Data.....	56
Chapter 3: Installing the R632 .....	57
Overview .....	57
Routing and Securing the Antenna Cable.....	58
Measuring Antenna Dimensions.....	59
Mounting the Antennas.....	61
Heading Configuration .....	62
Measuring R632 Dimensions .....	67
Mounting the R632 .....	69
Connecting the R632.....	75
Connecting the Receiver to External Devices .....	77
Connecting the Receiver to External Accessories.....	83

Appendix A: Troubleshooting .....	84
Overview .....	84
Troubleshooting .....	85
Appendix B: Technical Specifications.....	88
Overview .....	88
Technical Specifications .....	89
Index.....	94
End User License Agreement .....	95
Warranty Notice.....	99

---

## Device Compliance, License and Patents

---

### Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

---

### Copyright Notice

Copyright Hemisphere GNSS, Inc. (2022). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

---

### Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax4™, S320™, SBX-4™, Vector™, XF1™, and XF2™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

---

### Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

*Continued on next page*

## Device Compliance, License and Patents, Continued

---

**Notice to Customers**      Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[PRECISION@HGNS.COM](mailto:PRECISION@HGNS.COM)  
[WWW.HGNS.COM](http://WWW.HGNS.COM)

---

**Technical Support**      If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[SUPPORT.HGNS.COM](http://SUPPORT.HGNS.COM)

---

**Documentation  
Feedback**

Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website: [HGNS.COM](http://HGNS.COM)

---

## Terms and Definitions

---

**Introduction** The following table lists the terms and definitions used in this document.

---

### R632 Terms & definitions

<b>Term</b>	<b>Definition</b>
Activation	Activation refers to a feature added through a one-time purchase. For features that require recurring fees, see <b>Subscription</b> .
Atlas	Atlas is a subscription-based service provided by Hemisphere GNSS.
Base Station	The Base Station is a receiver placed over a familiar point to provide real-time observations and send those observations to nearby RTK rovers via UHF radio or the internet.
BeiDou	BeiDou is a global navigation satellite system deployed and maintained by China.
BIN message	Binary message
Cold Start	Position moved more than 100km during power-off, or power-off is longer than 3 days.
CSEP	The distance in meters that the receiver has calculated between the primary and secondary antenna. This value should always be accurate to within 2 cm.
dB	Decibel. The unit of measurement used to express signal-to-noise ratio (SNR).
DGPS	Differential GPS refers to a receiver using differential corrections.

*Continued on next page*

## Terms and Definitions, Continued

---

### R632 Terms & definitions, continued

Term	Definition
Firmware	Firmware is the software loaded into the receiver that controls the functionality of the receiver and runs the GNSS engine.
Galileo	Galileo is a global navigation satellite system deployed and maintained by the European Union and European Space Agency.
GLONASS	Global Orbiting Navigation Satellite System (GLONASS) is a Global Navigation Satellite System deployed and maintained by Russia.
GNSS	Global Navigation Satellite System (GNSS) is a system that provides autonomous 3D position (latitude, longitude, and altitude) and accurate timing globally by using satellites. Current GNSS providers are GPS, GLONASS, Galileo, BeiDou, NavIC (IRNSS), and QZSS.
GPS	Global Positioning System (GPS) is a global navigation satellite system deployed and maintained by the United States.
Heading	Heading is the angle between true north and the vector calculated from the primary to secondary antenna.
Heading Bias	Heading Bias is an offset applied to the heading value calculated by the receiver.
Hot Start	RF signal loss when power is on.
I/O	Input/Output
LED	Light Emitting Diode

*Continued on next page*

## Terms and Definitions, Continued

### R632 Terms & definitions, continued

Term	Definition
Mountpoint	Mountpoints are the specified data streams in NTRIP. Multiple base stations may send data to an NTRIP caster.
MSEP	This is the distance in meters between the primary and secondary antenna. This differs from CSEP in that the user measures this value and inputs it into the receiver.
Multipath	Multipath occurs when the GNSS signal reaches the antenna by two or more paths. This causes incorrect pseudo-range measurements and leads to less precise GNSS solutions.
NavIC (IRNSS)	Navigation with Indian Constellation and Indian Regional Navigational Satellite System (IRNSS) is a regional navigation satellite system deployed and maintained by India.
NMEA	National Marine Electronics Association (NMEA) is a marine electronics organization that sets standards for communication between marine electronics.
NTRIP	Networked Transport of RTCM via Internet Protocol – a protocol for transmitting differential GNSS or RTK over the internet.
NTRIP Server	The NTRIP server sends data from the NTRIP source (base station) to the NTRIP caster.
PPS	Pulse-per-second is a pulse output by the receiver precisely aligned to the GNSS time. Default output is every one second.
QZSS	Quasi-Zenith Satellite System (QZSS) is a regional satellite navigation system deployed and maintained by Japan.
RF	Radio Frequency
RMS	Root Mean Square

*Continued on next page*



## Terms and Definitions, Continued

### R632 Terms & definitions, continued

Term	Definition
ROX	ROX is a Hemisphere GNSS propriety RTK message format that can be used as an alternative to RTCM3 when both the base and rover are Hemisphere branded.
RTCM	Radio Technical Commission for Maritime Services (RTCM) is a standard used to define RTK message formats so that receivers from any manufacturer can be used together.
RTK	Real-Time-Kinematic (RTK) is a real-time GNSS differential method that provides better accuracy compared to other differential corrections.
SBAS	Satellite Based Augmentation System (SBAS) is a system that provides differential corrections over satellite throughout a wide area or region.
SNR	Signal-to-Noise Ratio
Subscription	A subscription is a feature that is enabled for a limited time. Once the end-date of the subscription has been reached, the feature will turn off until the subscription is renewed.
UHF	Ultra-high frequency is the ITU designation for radio frequencies in the range between 300 megahertz (MHz) and 3 gigahertz (GHz), also known as the decimeter band as the wavelengths range from one meter to one tenth of a meter (one decimeter).
Warm Start	Power loss is less than the cold start time or distance.

# Chapter 1: Introduction

## Overview

---

**Introduction** This chapter contains the information you need to get started using your R632 receiver. You can download this manual from the Hemisphere GNSS website at [WWW.HGNSS.COM](http://WWW.HGNSS.COM).

---

## Contents

	<b>Topic</b>	<b>See Page</b>
	Product Overview	11
	Key Features	14
	What's Included in Your Kit	15

---

## Product Overview

---

### Product overview

The R632 GNSS receiver is a full-solution product that provides robust performance and high precision in a compact package. The R632 uses Hemisphere's new Lyra™, Cygnus™, and Aquila™ core technologies, and features new interference rejection and multipath mitigation.

The R632's standard configuration offers multiple methods of connectivity and wireless communications. R632 uses Hemisphere's Atlas® correction network to achieve a stand-alone positioning to 4 cm.

R632 is a high-accuracy GNSS receiver for Survey, GIS, Marine Navigation, and other applications. The product is suitable for base stations and light vehicle applications.



**Figure 1-1: R632 GNSS Receiver**

**Note:** Throughout the rest of this manual the R632 GNSS receiver is referred to simply as the R632.

---

*Continued on next page*

## Product Overview, Continued

---

**Athena™ RTK** The R632 supports the use of Athena™ RTK (Real Time Kinematic) technology. Athena RTK requires the use of two separate receivers: a stationary base station (primary receiver) that broadcasts corrections over a wireless link to the rover (secondary receiver). The localized corrections are processed on the rover to achieve superior accuracy and repeatability. Performance testing has shown positioning accuracy at the centimeter level.

Alternatively, RTK corrections can be brought in over a GNSS network (NTRIP) if one is available in your area.

Athena RTK has the following benefits:

- Improved Initialization time - Performing initializations in less than 15 seconds at better than 99.9% of the time.
- Robustness in difficult operating environments - Extremely high productivity under the most aggressive of geographic environments.

---

*Continued on next page*

## Product Overview, Continued

---

**Atlas® L-band** Atlas L-band corrections are available worldwide. With Atlas, the positioning accuracy does not degrade as a function of distance to a base station, as the data content is not composed of a single base station's information, but an entire network's information.

The R632 provides accurate and reliable heading and position information at high update rates. To accomplish this task, the R632 uses a high performance GNSS receiver and two antennas for GNSS signal processing.

One antenna is designated as the primary GNSS antenna, and the other is the secondary GNSS antenna.

Positions computed by the R632 are referenced to the phase center of the primary GNSS antenna. Heading data references the vector formed from the primary GNSS antenna phase center to the secondary GNSS antenna phase center.

Atlas L-band has the following benefits:

- Positioning accuracy - Competitive positioning accuracies down to 2cm RMS in certain applications.
  - Positioning sustainability - Cutting edge position quality maintenance in the absence of correction signals, using patented technology.
  - Scalable service levels - Capable of providing virtually any accuracy, precision, and repeatability level in the 4 to 50 RMS range.
  - Convergence time - Industry-leading convergence times of 10-40 minutes.
-

## Key Features

---

### R632 key features

Key features of the R632 include:

- Multi-frequency GPS, GLONASS, BeiDou (including Phase 3), Galileo, NavIC (IRNSS)\*, QZSS, and Atlas L-band
- Long-range RTK baselines up to 50 km with fast acquisition times
- Worldwide Atlas L-band corrections to 4 cm
- UHF (400 MHz & 900 MHz), cellular (GSM, 3G & 4G), Bluetooth, and Wi-Fi wireless communication
- Athena GNSS engine providing best-in-class RTK performance
- Status LEDs and powerful WebUI, making the R632 easy to monitor and configure
- Ethernet, Serial, and USB
- NTRIP Server, NTRIP Caster, and NTRIP Client
- Rugged housing
- Easy configuration from WebUI and remote server
- Adapt to power supply requirements in various environments
- IP67 Rated

\*NavIC (IRNSS) will be available as a future firmware update.

---

## What's Included in Your Kit

---

### Kit contents

Table 1-1 provides the description and part number of each part in your kit. Table 1-2 lists the optional cables and accessory parts that are available for use with the R632.

Review the parts shipped with your kit. If any parts are damaged, contact your freight carrier. If any parts are missing, contact your dealer.

**Table 1-1: Parts list**

Part Name	Part Number	Qty
R632 Receiver	752-0053-10	1
Power Cable	054-0226-10	1

**Table 1-2: Optional Cables and Accessory Parts**

Part Name	Part Number	Qty
Cable, DB26 F - 2X DB9 M, 40"L	051-0451-10	1
Cable, DB26 F - DB9 M, 40"L	051-0452-10	1
Cable, DB26 F - RJ45 F, 40"L	051-0453-10	1
Cable, DB26 F - USB M, 40"L	051-0454-10	1
Cable, PWR, 2PIN Conn - SAE, 20"L	054-0225-10	1
Cable, PSAA30R-150-2P	054-0171-0	1

---

## Chapter 2: Operating the R632

### Overview

---

**Introduction** Chapter 2 provides the information you need to power and operate your R632 receiver.

---

### Contents

	<b>Topic</b>	<b>See Page</b>
	Powering the Receiver On/Off	17
	Ports	19
	SIM and MicroSD Cards	20
	Connecting to the WebUI	23
	Upgrading Firmware	24
	Using the WebUI	26
	Mounting R632 as a Base Station	47
	Configuring R632 as a Base Station	49
	Setting up R632 RTK Output	51
	Logging Raw Data	56

---



## Powering the Receiver On/Off

---

### Powering the receiver on/off

To power on the R632 you must connect to an external power supply. The R632 will power on automatically after it connects to the 2-pin power cable and has a power supply.

After powering on, the LED indicators will show the device status. For example, the Wi-Fi power indicator will illuminate green if the power is on.

To power off the R632 disconnect the external power supply.



**Figure 2-1: R632 LED Indicators**

---

*Continued on next page*

## Powering the Receiver On/Off, Continued

Powering the receiver on/off, continued

Table 2-1 lists the R632 indicators by color and function.

**Table 2-1: LED Indicators**

LED	Color	Function
Power	Red	<p>Solid red when connected to power</p> <p>OFF when it is not connected power</p> <p><b>Note:</b> The R632 cannot be powered on when voltage is less than 9V and will be powered on automatically when power is higher than 9V.</p>
Satellite	Yellow	<ol style="list-style-type: none"> <li>1. Flashing yellow is single solution</li> <li>2. Solid yellow is float/fixed solution</li> <li>3. OFF is Invalid solution/or tracked less than 4 satellites</li> </ol>
Bluetooth	Blue	<p>ON, Bluetooth has connected</p> <p>OFF, No connection</p>
Cellular	Green	<p>ON, Cellular is enabled</p> <p>OFF, cellular is disabled</p>
Wi-Fi	Green	Solid green, Client/AP is enabled
UHF	Green	<p>ON, UHF is enabled</p> <p>Flashing green, data transmitting via UHF</p> <p>OFF, UHF is disabled</p>
Heading	Green	<p>ON, Heading is enabled</p> <p>OFF, heading is disabled</p>

## Ports

### R632 ports

Figure 2-2 below shows the R632 communication ports and port name labels.



**Figure 2-2: R632 communication ports**

Table 2-2 lists the communication ports and a description of each function.

**Table 2-2: R632 communication ports**

	<b>Port Name</b>	<b>Description</b>
1	GNSS2	TNC, external GNSS slave antenna connector
2	PWR	2-pin LEMO connector, power supply
3	DB-26	Two RS-485 serial ports One RS-232 serial port One USB 2.0 interface (supports OTG) One PPS output interface One EVENT interface One 100M Ethernet port
4	GNSS1	TNC, external GNSS master antenna connector
5	LTE	SMA, 4G antenna interface
6	UHF	External UHF antenna


## SIM and MicroSD Cards

---

### Insert cards

If you need to use the SIM card or a MicroSD card, you should insert the card before you power on the R632.

Refer to Figure 2-3 below. Open the card cover first, then insert the SIM card and MicroSD card and close the card cover.



**Figure 2-3: Card cover**

---

*Continued on next page*


## SIM and MicroSD Cards, Continued

Insert cards,  
continued

Table 2-3 lists the R632 card slot ports and descriptions.

**Table 2-3: R632 card slots**

	Port Name	Description
1	TF card slot	MicroSD card slot
2	SIM card slot	Standard size SIM card interface



**Figure 2-4: R632 card slots**

*Continued on next page*


## SIM and MicroSD Cards, Continued

### Connect LTE modem

The R632 features an LTE modem that can be used to connect the receiver to the internet. R632 can also be used as an NTRIP client, NTRIP caster, and NTRIP server.

You can also upload raw data files to and FTP site or send emails and SMS messages when receiver conditions or criteria have been met (i.e., the receiver has moved, overheated, etc.). To connect to the LTE modem, use the following steps. Table 2-4 lists the steps to connect the LTE modem.

**Table 2-4: Connect LTE modem**

Step	Action
1	Locate the SIM card slot. <div style="text-align: center;">  </div>
2	Insert the SIM card using the below orientation.
3	Carefully push the SIM card until you hear the card click.
4	Install the LTE antenna.
5	The receiver will automatically power on. <p>The power port is a 2-pin LEMO connector shown in the photo in Step 1. Optional power adapters include an AC and a DC option (8-36V).</p>



## Connecting to the WebUI

### Connect to the WebUI

Use the following steps in Table 2-5 to login to the WebUI.

**Note:** When completing subsequent portions of the R632 setup and installation (discussed later in this manual) return to this section for the steps you need to use the WebUI.

**Table 2-5: Connect to the WebUI**


Step	Action
1	<p>Click to connect to the SSID. The SSID is the serial number of the receiver.</p> 
2	<p>Type 192.168.10.1 in the browser address bar to log into WebUI.</p>
3	<p>Type the username: <b>admin</b> and type the default password: <b>password</b>. Click <b>Log in</b>.</p> 

## Upgrading Firmware

### Upgrade firmware

The R632 has two firmware files: the carrier board firmware, and the GNSS firmware. The carrier board firmware and the GNSS firmware can be upgraded via the WebUI.

To upgrade firmware with the WebUI, log into the WebUI (see [Connecting to the WebUI](#)), and click **System Management**.



Locate the **Online Upgrade** option and click **Choose File**. Select the applicable file. Click **Upgrade**.

*Continued on next page*



## Upgrading Firmware, Continued


---

**Upgrade  
firmware,  
continued**

The WebUI will indicate either **OEM Firmware** (GNSS board) or **WebUI firmware**. Click **OK** to confirm that you wish to upgrade firmware.

Firmware Type : OEM Firmware  
New Version : 6.0Aa02a

Are you sure want to upgrade ?



The status bar displays the upgrade status.

Firmware Type : OEM Firmware  
New Version : 6.0Aa02a

Update running...




## Using the WebUI

### Overview

The R632 WebUI is used for configuration, logging, and data output via the communication ports (RS-232, RS-485, Bluetooth, and Ethernet (TCP/IP). Additional configuration related to the **Reference Station**, **NTRIP**, **Ports**, and **Network** options are available.

### Summary

The **Status** page contains information about the **Device Model**, **Device Serial**, **GNSS Model**, and **GNSS Serial Number** with a brief overview of the **Longitude**, **Latitude**, **Height**, and **GNSS Status**. The **Internal** and **External Memory** indicates the available internal and external storage in real-time. Additionally, the **Status** page shows the **Local Time**, the **Satellites** currently used in the solution, with **Longitude**, **Latitude**, **Height**, and **PDOP**, **HDOP**, **Horizontal RMS**, and **Vertical RMS**. The **Station Number** and **Base (Latitude, Longitude, and Height)** identify the current solution. Other items include the environmental information and selected antenna type visible at the bottom of the page.



**Basic Status**

**R632 Reference Station**

**Station**

Station Name	Test
Run Time	0 Day 3 Hour 7 Minute

**GNSS**

Device Model	R632
Device Serial	D2011052391025
GNSS Model	VZ8
GNSS Serial Number (ESN)	21401000
Radio Model	TBM121
Radio Serial	TBM12120001132

**Memory**

Internal Memory	26.5% (68.01 MB/234.74 MB)
Data Memory	100.0% (7.24 GB/7.24 GB)

**Power**

Battery Power	0%
Power Source	External

**Receiver Status**

**GPS Position**

Local Time	1980-01-01 00:00:00(GPS TIME + 0)
Satellites	0/0
Longitude	113° 0' 0.00000"
Latitude	23° 0' 0.00000"
Height	0.000 m
Status	Idle
Differential Format	NONE
PDOP	0.000
HDOP	0.000
HRMS	0.000
VRMS	0.000

**L-Band/SBAS Status**

Frequency	1545.8500 MHz
Band Rate	9600bps
Signal Strength	0
Bit Error Rate	980-500
Type	AUTO

**Base Station**

Base Longitude	0° 0' 0.00000"
Base Latitude	0° 0' 0.00000"
Base Height	0.000 m

**Antenna**

Antenna Type	HX-GD100A
Antenna Height	0mm
Measurement Mode	Antenna Phase Center

**MET**

MET Type	ZZ11A
Pressure	N/A
Temperature	-1°C
Humidity	-%RH


TechSupport@Hemisphere.com  
© Copyright 2022 Hemisphere GNSS. All Rights Reserved.

Continued on next page


## Using the WebUI, Continued

### Device Information

The **Device Information** page contains an in-depth view of the GNSS receiver's technology. You can see the **GNSS Model**, **GNSS Serial Number**, **Firmware/Software** versions, **IMEI (Internal Modem)**, and **Radio** version and model.



Receiver Information		Mobile Information	
<b>Station Information</b>		<b>GNSS Information</b>	
Station Name	Test	GNSS Model	V28
Run Time	0 Day 3 Hour 12 Minute	GNSS Serial Number (ESN)	21401000
Time Zone	GMT+08:00	GNSS Hardware Version	1
<b>Device Information</b>		GNSS Firmware Version	6.6Aa00
Device Model	R032	Activations & Subscriptions	OPT=20Hz;RTK;RAW;DATA_L2_L5;MULTI_GNSS;HEADING;ATLAS_LBAND;ATLAS_50cm
Device Serial	D0017252351025	Atlas Expiry Date	0000/2000
Hardware Version	M102-V4.2	<b>Mobile Information</b>	
BOOT Version	0117	Mobile Model	E025-G
OS Version	4.1.8-0121-M102	Mobile Version	EG25G0BR07A07M2G
APP Version	2.12-220915-HGNSS	IMEI	EG25G0BR07A07M2
Web Version	3.0	ICCID	
MCU Version	0207	<b>Radio</b>	
<b>Network</b>		Radio Model	TRM121
DHCP	On	Radio Serial	TRM12120030132
MAC address	9C:C3:74:62:D0:DA	Radio Firmware Version	G149.00.1E
IP	0.0.0.0	Radio Channel	2140.125 MHz_HQ
Mask	0.0.0.0	Radio Protocol	South 9000
Gateway	0.0.0.0		
<b>Memory</b>			
Internal Memory	28.5% (60.81 MB/234.74 MB)		
Data Memory	100.0% (7.24 GB/7.24 GB)		


[TechSupport@Hemisphere.com](mailto:TechSupport@Hemisphere.com)  
 © Copyright 2022 Hemisphere GNSS. All Rights Reserved.


*Continued on next page*

## Using the WebUI, Continued

### Sky View

The **Sky View** provides a graphical representation of available satellites being tracked and used in the solution along with the ability to see the **Satellite Vehicle** orientation compared to the R632 GNSS receiver.

The bubbles on the **Sky View** identify the constellation of each satellite vehicle.




*Continued on next page*

## Using the WebUI, Continued


### Signal Chart

The **Signal Chart** shows the SNR values for each signal currently being tracked. The bold signals are the values currently being used in the position solution.



### Compass

On the **Compass** page you can find a graphical real-time view of the **Heading** and the **Course over Ground** data.




*Continued on next page*

## Using the WebUI, Continued

### Spectrum Analyzer

R632 offers a built-in spectrum analyzer that allows the user to review individual GNSS frequency bands for interference. If interference is found, a filter can be put in place to notch the interference out of the GNSS frequency band and leave the rest of the GNSS band still usable.

Turn on **Cygnus™** for easy interference detection.




*Continued on next page*

## Using the WebUI, Continued

### Reference Station

Use the **Reference Station** page to setup and configure your **Reference Station**. You can name the station, set the markers, local time, working mode, and antenna height.

The **Antenna** portion of this page provides a drop-down list of existing **Antenna Manufacturers** and configurations. For manufacturer antennas that are not on the list, a “Custom” option allows you to input the necessary information. When **Working mode** is set to **Base**, the options for **Single**, **Repeat Position**, **BaseLink™** and **SmartLink™** become available.



The screenshot displays the Hemisphere Reference Station configuration interface. The left sidebar contains a navigation menu with options like Reference Station, Reference Station, GNSS Configuration, Tracking Satellites, Heading, Help Server, Recording, Port Configuration, Network, Dynamic LMS, F11 Server, NTPD, SNMPD, Firewall, Administration, Alerts, Registration, Configuration Set, and Remote Debug. The main content area is titled 'Reference Station' and includes the following sections:


- Working Mode:** Radio buttons for 'Base' (selected) and 'Rover'.
- Base Information:**
  - Observer Name: OBSERVER
  - Agency Name: AGENCY
  - Station Name: Test
  - Marker Number: 0
  - Marker Type: GLDDETIC
  - Receiver Number: 0
  - Country Code: CMR - China
  - Site ID:
  - Time Zone: GMT +08:00
- Device Antenna:**
  - Antenna Type: YES-GG466A
  - Antenna Serial:
  - Rotem: 0
  - HWRM: 0
  - HL, LWRM: 116
  - HL, LWRM: 142
  - Buttons: Download, Choose File, No file chosen, Upload
- Reference Coordinates:**
  - Coordinate System: Geodetic Coordinates (B, L, H)
  - Base Longitude: 113 21 59 (E) 82440
  - Base Latitude: 23 7 35 (N) 67690
  - Base Height: 20.000 (m)
  - Height of the point on the ground: 0.000 (m)
  - Buttons: Load Current Position, Get Average Position, Cancel Base Position
- Antenna Height:**
  - Antenna Height: 0 (mm)
  - Measurement Mode: Antenna Phase Center

Continued on next page

## Using the WebUI, Continued

### GNSS Configuration

**GNSS Configuration** allows enabling and disabling of **PPS, BeiDou, GPS, GLONASS, Galileo, QZSS, SBAS, Atlas, and RTK Mode**. **Cutoff Angle** can be adjusted in a situation if the standard 10° cutoff is not sufficient for your application.



*Continued on next page*



## Using the WebUI, Continued

---

### Tracking Satellites

The **Tracking Satellites** page shows every satellite that is capable of being tracked by the R632. If you have a specific satellite that causes issues or has been known to cause interference in your application, you can shut off that specific satellite from being used.

**Note:** Only advanced should make changes to the **Tracking Satellites** page.

---

*Continued on next page*

# Using the WebUI, Continued

## Tracking Satellites, continued

The screenshot shows the Hemisphere webUI interface. On the left is a navigation menu with options: Reference Station, GNSS Configuration, Tracking Satellites, Heading, Ntrip Server, Recording, Port Configuration, Network, and Administration. The 'Tracking Satellites' option is selected. The main area displays a table for configuring satellite tracking. The table has columns for GPS, Don't track, Glonass, Don't track, BeiDou, Don't track, Galileo, Don't track, QZSS, Don't track, IRNSS, and Don't track. Each row represents a satellite ID (G01 to G32) and its corresponding tracking status for each system. At the bottom of the table, there are 'Save/OK' and 'Cancel' buttons.

GPS	Don't track	Glonass	Don't track	BeiDou	Don't track	Galileo	Don't track	QZSS	Don't track	IRNSS	Don't track
G01	<input type="checkbox"/>	R01	<input type="checkbox"/>	C01	<input type="checkbox"/>	E01	<input type="checkbox"/>	J193	<input type="checkbox"/>	I1	<input type="checkbox"/>
G02	<input type="checkbox"/>	R02	<input type="checkbox"/>	C02	<input type="checkbox"/>	E02	<input type="checkbox"/>	J194	<input type="checkbox"/>	I2	<input type="checkbox"/>
G03	<input type="checkbox"/>	R03	<input type="checkbox"/>	C03	<input type="checkbox"/>	E03	<input type="checkbox"/>	J195	<input type="checkbox"/>	I3	<input type="checkbox"/>
G04	<input type="checkbox"/>	R04	<input type="checkbox"/>	C04	<input type="checkbox"/>	E04	<input type="checkbox"/>	J196	<input type="checkbox"/>	I4	<input type="checkbox"/>
G05	<input type="checkbox"/>	R05	<input type="checkbox"/>	C05	<input type="checkbox"/>	E05	<input type="checkbox"/>	J197	<input type="checkbox"/>	I5	<input type="checkbox"/>
G06	<input type="checkbox"/>	R06	<input type="checkbox"/>	C06	<input type="checkbox"/>	E06	<input type="checkbox"/>	J198	<input type="checkbox"/>	I6	<input type="checkbox"/>
G07	<input type="checkbox"/>	R07	<input type="checkbox"/>	C07	<input type="checkbox"/>	E07	<input type="checkbox"/>	J199	<input type="checkbox"/>	I7	<input type="checkbox"/>
G08	<input type="checkbox"/>	R08	<input type="checkbox"/>	C08	<input type="checkbox"/>	E08	<input type="checkbox"/>	J200	<input type="checkbox"/>	I8	<input type="checkbox"/>
G09	<input type="checkbox"/>	R09	<input type="checkbox"/>	C09	<input type="checkbox"/>	E09	<input type="checkbox"/>	J201	<input type="checkbox"/>	I9	<input type="checkbox"/>
G10	<input type="checkbox"/>	R10	<input type="checkbox"/>	C10	<input type="checkbox"/>	E10	<input type="checkbox"/>	J202	<input type="checkbox"/>	I10	<input type="checkbox"/>
G11	<input type="checkbox"/>	R11	<input type="checkbox"/>	C11	<input type="checkbox"/>	E11	<input type="checkbox"/>			I11	<input type="checkbox"/>
G12	<input type="checkbox"/>	R12	<input type="checkbox"/>	C12	<input type="checkbox"/>	E12	<input type="checkbox"/>			I12	<input type="checkbox"/>
G13	<input type="checkbox"/>	R13	<input type="checkbox"/>	C13	<input type="checkbox"/>	E13	<input type="checkbox"/>			I13	<input type="checkbox"/>
G14	<input type="checkbox"/>	R14	<input type="checkbox"/>	C14	<input type="checkbox"/>	E14	<input type="checkbox"/>			I14	<input type="checkbox"/>
G15	<input type="checkbox"/>	R15	<input type="checkbox"/>	C15	<input type="checkbox"/>	E15	<input type="checkbox"/>				
G16	<input type="checkbox"/>	R16	<input type="checkbox"/>	C16	<input type="checkbox"/>	E16	<input type="checkbox"/>				
G17	<input type="checkbox"/>	R17	<input type="checkbox"/>	C17	<input type="checkbox"/>	E17	<input type="checkbox"/>				
G18	<input type="checkbox"/>	R18	<input type="checkbox"/>	C18	<input type="checkbox"/>	E18	<input type="checkbox"/>				
G19	<input type="checkbox"/>	R19	<input type="checkbox"/>	C19	<input type="checkbox"/>	E19	<input type="checkbox"/>				
G20	<input type="checkbox"/>	R20	<input type="checkbox"/>	C20	<input type="checkbox"/>	E20	<input type="checkbox"/>				
G21	<input type="checkbox"/>	R21	<input type="checkbox"/>	C21	<input type="checkbox"/>	E21	<input type="checkbox"/>				
G22	<input type="checkbox"/>	R22	<input type="checkbox"/>	C22	<input type="checkbox"/>	E22	<input type="checkbox"/>				
G23	<input type="checkbox"/>	R23	<input type="checkbox"/>	C23	<input type="checkbox"/>	E23	<input type="checkbox"/>				
G24	<input type="checkbox"/>	R24	<input type="checkbox"/>	C24	<input type="checkbox"/>	E24	<input type="checkbox"/>				
G25	<input type="checkbox"/>			C25	<input type="checkbox"/>	E25	<input type="checkbox"/>				
G26	<input type="checkbox"/>			C26	<input type="checkbox"/>	E26	<input type="checkbox"/>				
G27	<input type="checkbox"/>			C27	<input type="checkbox"/>	E27	<input type="checkbox"/>				
G28	<input type="checkbox"/>			C28	<input type="checkbox"/>	E28	<input type="checkbox"/>				
G29	<input type="checkbox"/>			C29	<input type="checkbox"/>	E29	<input type="checkbox"/>				
G30	<input type="checkbox"/>			C30	<input type="checkbox"/>	E30	<input type="checkbox"/>				
G31	<input type="checkbox"/>			C31	<input type="checkbox"/>	E31	<input type="checkbox"/>				
G32	<input type="checkbox"/>			C32	<input type="checkbox"/>	E32	<input type="checkbox"/>				
				C33	<input type="checkbox"/>	E33	<input type="checkbox"/>				
				C34	<input type="checkbox"/>	E34	<input type="checkbox"/>				
				C35	<input type="checkbox"/>	E35	<input type="checkbox"/>				
				C36	<input type="checkbox"/>	E36	<input type="checkbox"/>				
				C37	<input type="checkbox"/>						
				C38	<input type="checkbox"/>						
				C39	<input type="checkbox"/>						
				C40	<input type="checkbox"/>						
				C41	<input type="checkbox"/>						
				C42	<input type="checkbox"/>						
				C43	<input type="checkbox"/>						
				C44	<input type="checkbox"/>						
				C45	<input type="checkbox"/>						
				C46	<input type="checkbox"/>						
				C47	<input type="checkbox"/>						
				C48	<input type="checkbox"/>						
				C49	<input type="checkbox"/>						
				C50	<input type="checkbox"/>						
				C51	<input type="checkbox"/>						
				C52	<input type="checkbox"/>						
				C53	<input type="checkbox"/>						
				C54	<input type="checkbox"/>						
				C55	<input type="checkbox"/>						
				C56	<input type="checkbox"/>						
				C57	<input type="checkbox"/>						
				C58	<input type="checkbox"/>						
				C59	<input type="checkbox"/>						
				C60	<input type="checkbox"/>						
				C61	<input type="checkbox"/>						
				C62	<input type="checkbox"/>						
				C63	<input type="checkbox"/>						

Continued on next page


## Using the WebUI, Continued

### Heading

The **Heading** page allows the implementation of different Heading settings. This page displays, **Heading, Compass, Pitch, Heave, Course Over Ground (COG), Speed, Roll, and Rate of Turn (ROT)**. Additional adjustments can be made to ACC values.

**Note:** The ACC values shouldn't be touched unless the device is on stable ground.

The ability to turn on **ROLL, GYROAID, TILTAID, LEVEL, MOVEBASE** (Only with Multi-frequency), **DYMANICBASE** are available. This is also the correct page to make any adjustments related to any **BIAS** and **TAU** settings.




*Continued on next page*

## Using the WebUI, Continued

### NTRIP Server

The **NTRIP Server** page allows the implementation of up to three servers. Each server can have unique **IP addresses**, **ports**, and **mount points**, and can output a variety of data protocols (**RTCM**, **CMR**, **ROX**, **DGPS**, and **Raw**).




*Continued on next page*

## Using the WebUI, Continued

### Recording

Use the **Recording** page to enable the data logging on the R632. Specifically, this works for **Raw Data** that will be used for **Post Processing**. Customized fields for **Name**, **Path Type**, **Interval**, **Duration**, and **File Push** are available. **File Push** allows the data to be sent to an external FTP site.

The **Recording** page has a built in Rinex converter that can convert raw data into a usable file for post processing.



The screenshot shows the Hemisphere web interface. The top navigation bar includes: Hemisphere, STATUS, SKY VIEW, SIGNAL CHART, COMPASS, SPECTRUM ANALYZER, DEVICE INFORMATION, DOWNLOAD, and SETTINGS. The left sidebar menu includes: Reference Station, Reference Station, GNSS Configuration, Tracking Satellites, Heading, Ntrip Server, Recording (highlighted), Port Configuration, Network, and Administration. The main content area is titled 'Recording' and contains a 'Record List' table with columns: Schedule Name, Interval, Path, Status, Start Time, Duration Time, File Size, and Operation. Below the table is a 'Create New Record' form with the following fields:

- Schedule Name:
- Path Type:
- File Name:
- File System:
- Interval:
- Duration Time:
- Pool:
- Auto:  Enable  Disable
- Integral Point Record:  Enable  Disable
- File Push:  Enable  Disable
- Convert:  Enable  Disable


At the bottom of the page, there is a footer with the Hemisphere logo, the URL [techsupport@hem-gnss.com](http://techsupport@hem-gnss.com), and the copyright notice: © Copyright 2022 Hemisphere GNSS. All Rights Reserved.

*Continued on next page*

## Using the WebUI, Continued

### Port Configuration

The **Port Configuration** page is used to configure **Bluetooth, UHF, COM1-3, NTRIP Client, NTRIP Caster,** and five **TCP/IP Sockets**. All of these ports can be configured for **Baud Rate, Protocol, Mode, IP Port (TCP/IP, and NTRIP),** and **Function**.



The screenshot displays the Hemisphere WebUI interface. On the left is a navigation menu with options: Reference Station, Reference Station, GNSS Configuration, Tracking Solutions, Tracking, Ntrip Server, Recording, Port Configuration (selected), Network, and Administration. The main content area is titled 'Port Configuration' and contains a 'Ports Summary' table and a 'Port Configuration' section.

Port	Status	Baud Rate	Protocol	Mode	Port	Function
Bluetooth	Close	-	-	-	-	CMD
UHF	Close	440 125 MHz	South 9500	-	-	RTK_OUT(RTKCMD)
COM1	Close	115200	RS485	-	-	CMD
COM2	Close	115200	RS485	-	-	CMD
COM3	Close	115200	RS485	-	-	RTK_OUT(RTKCMD)
Ntrip Client	Close	-	NTRIP	CLIENT	-	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP	SERVER	8000	RTK_OUT(RTKCMD)
Socket 2	Close	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

The 'Port Configuration' section is currently set to 'Bluetooth'. It includes a 'Bluetooth' status indicator (checked) and a 'Function' dropdown menu set to 'CMD(Input/Output)'. There are 'Save' and 'Reset' buttons at the bottom right of this section.

Footer text: TechSupport@Hemisphere.com  
© Copyright, 2022 Hemisphere GNSS. All Rights Reserved.

*Continued on next page*

## Using the WebUI, Continued

### Network

The **Network** page contains options to connect to the R632 via a **Wired** connection, **Wireless** connection, or a **mobile** connection.


Network Connection	Requirements
Wired Connection	Network, Gateway, DNS, and PING
Wireless Connection	DHCP or Static IP address, Mask, Gateway, and MAC Address

The screenshot displays the Hemisphere WebUI Network configuration page. The interface includes a navigation menu on the left with options like Reference Station, GNSS Configuration, Tracking Stations, Hoisting, Ntrip Server, Recording, Port Configuration, Network, Network, Dynamic DNS, FTP Server, NTPD, SNMPD, Firewall, and Administration. The main content area is titled 'Network' and contains the following settings:


- Priority Network:**  Wired Net,  Wireless Net,  Mobile Net
- Switch Strategy:**  Local Network,  Public Network,  Disable
- Current Network:** NONE
- Default Gateway:** 0.0.0.0
- DNS:** 114.114.114.114/8.8.8.8
- PING:** Timeout: 10, Counts: 10
- PING Address:** X.Y.Z.X|X2.Y2.Z2.K2|X3.Y3.Z3.K3
- Web Server:** Web Server Protocol: HTTP, HTTP Server Port: 80
- Wired Net:**  WAN,  LAN; DHCP:  Enable,  Disable; IP: 0.0.0.0; Mask: 0.0.0.0; Gateway: 0.0.0.0; MAC address: D4:53:83:5E:D7:8E; Bit Rate: 0 MB/s; Signal Level: 0 dbm; Channel: 0; Wi-Fi Link Status: Power ON; Virtual AP:  Enable,  Disable
- Mobile Net:**  Enable,  Disable; APN: cmnet; User: ; Password: ; Network Type:  Auto,  GSM,  CDMA-EVDO,  LTE; Authentication Algorithm: ; Modem Version: EG25G6R07A07M2G; IP: 0.0.0.0; Mask: 0.0.0.0; Gateway: 0.0.0.0; Signal Level: 0%; Mobile Link Status: Power OFF; Modem Status: No Internet access
- Do not send tcp-echo:**  Yes,  No
- Reboot with ping failed:**  Yes,  No

## Using the WebUI, Continued

**Dynamic DNS** The **Dynamic DNS** provides the option to use common DNS sites, and an option to input a custom DNS.



**FTP Server** You can select to allow the R632 to output data directly to an **FTP server**.




*Continued on next page*



## Using the WebUI, Continued


### NTP Server

This allows the R632 to output to a specific **NTP Server**.



### Remote Debug

**Remote Debug** is typically used by HGNSS Technical Support. If you have an issue with the R632, HGNSS Technical Support may require you to turn this feature on and provide a specific log for better troubleshooting.




*Continued on next page*

## Using the WebUI, Continued


### SNMPD

SNMPD can be selected to add the R632 to existing Network Management software updates and alerts.



### Firewall

The firewall feature enables a user to “Whitelist”, or specific IP addresses that are authorized to access the R632. Or the user can “Blacklist”, certain IP addressed that they would prefer to deny access to the R632.




*Continued on next page*

## Using the WebUI, Continued

### Alerts

Use the **Alerts** page to send alerts in reference to **Temperature**, **Internal Disk Space**, **Estimated Coordinates**, and **Satellite Counts**. If any of these items fall outside their set parameters, an alert will be sent via SMS or email.

**Note:** Alerts require a mobile data plan to work properly.



The screenshot shows the Hemisphere WebUI interface. On the left is a navigation menu with options like Reference Station, GNSS Configuration, Tracking Satellites, Heading, Ntrip Server, Recording, Port Configuration, Network, Dynamic DNS, FTP Server, NTP, SNTP, Firewall, Administration, Alerts, Registration, Configuration Set, Remote Debug, and System Management. The 'Alerts' page is active, showing configuration options for E-Mail Alerts, SMS Alerts, and Other Alerts. The E-Mail Alerts section has a status toggle set to 'Enable' and fields for SMTP Server, From E-Mail Address, E-Mail Login Name, E-Mail Login Password, and To E-Mail Address. The SMS Alerts section has a status toggle set to 'Enable' and a Phone Number field. The Other Alerts section has four checkboxes: 'Temperature is above a limit' (70 °C), 'Internal Disk space is close to be full (under 500MB)', 'GNSS satellites drop below an amount' (5), and 'Difference between estimated coordinates and base coordinates over' (40 ft). A 'Save' button and a 'Reset' button are at the bottom right. A copyright notice '© All Rights Reserved.' is at the bottom left.


*Continued on next page*

## Using the WebUI, Continued

### Registration

The **Registration** page updates the R632 with **Activations** and **Subscriptions**. The fields below show the **GNSS Serial Number**, **GNSS Functionality**, and **AuthCode** input.

**Note:** When an activation or subscription is input, the user is required to power cycle the device and wait 10 seconds and refresh the page to see the GNSS Functionality change.




*Continued on next page*

## Using the WebUI, Continued


### Configuration Set

The **Configuration** page allows the user to create a current profile of the R632 configuration. This will be packaged as a file that can be saved on a local drive. In the event an R632 needs to be restored, the file can be uploaded and restore all the previous configuration settings.



### Download

The **Download** page provides access to the internal and external storage of the R632 with the option to export these files to an FTP or download and save to a local drive. You can also delete any unwanted files.




*Continued on next page*

## Using the WebUI, Continued

### System Management

Use the **System Management** page to update **Application Software** and **GNSS Firmware** via the “Online Upgrade” feature.

Additionally, the R632 can output logs for **APP**, **OS**, and **Net**. For security purposes, this page allows the user to reset or update the password for the R632 or create a guest password. The R632 can run a **Self-Test**, **Reset**, and **Format Internal Disk** options.



The screenshot displays the Hemisphere R632 WebUI interface. The top navigation bar includes: STATUS, SKY VIEW, SIGNAL CHART, COMPASS, SPECTRUM ANALYZER, DEVICE INFORMATION, DOWNLOAD, and SETTINGS. A left sidebar menu lists various configuration categories, with 'System Management' selected at the bottom. The main content area is divided into several sections:

- Update Firmware:** A section with a 'Select Firmware' dropdown, a 'Choose a file...' button, and a 'Browse' button. A green 'Update' button is visible on the right.
- Security:** A section with two sub-sections:
  - Enable Login Authentication:** Includes a checked checkbox, 'Current User' (admin), and input fields for 'Old Password', 'New Password', and 'Confirm Password' with a green 'Change' button.
  - Enable Guest:** Includes a checked checkbox and input fields for 'New Guest Password' and 'Verify New Password' with a green 'Change' button.
- View Logs:** A table listing logs with 'Clean', 'View', and 'Download' buttons:
 

1 App Log	Clean	View	Download
2 OS Log	Clean	View	Download
3 NET Log	Clean	View	Download
4 Audit Log	Clean	View	Download
- Others:** A list of system actions, each with a green 'OK' button:
  - Self Test
  - Restart Device
  - Factory OEM
  - Reset To Factory Settings
  - Format Internal Disk
  - Net Test
  - Logout

### Language

Supported languages for the R632 include English, Russian, and Chinese.

## Mounting R632 as a Base Station

---

**Roof mount** To use the R632 as a base station, you can either mount the antenna using a roof mount or mount the antenna using a tripod.

To roof mount an antenna is to permanently mount an antenna at the highest possible point, clear of multipath. Permanent base stations are often mounted on the top of buildings. You can mount the A45 antenna onto a 5/8" thread. The example below shows an A45 antenna mounted on a retaining wall on top of the roof of a Hemisphere GNSS office.

To roof mount the antenna, run an Rf cable to the R632. The R632 can be placed on a rack or mounted permanently to the wall of an office. Carefully run the cable down, keeping in mind attenuation (see [Routing and Securing the Antenna Cable](#)).



**Figure 2-5: Roof mounted antenna**

---

*Continued on next page*

## Mounting R632 as a Base Station, Continued

---

**Tripod mount** Another option to mount the R632 as a base station is to place the antenna on a tripod and place it over a known point. This is a less typical setup for the R632. Figure 2-6 shows the R632 receiver mounted on a tripod.



**Figure 2-6: R632 Mounted on a Tripod**

---



## Configuring R632 as a Base Station

---

### Base station configuration

After mounting the R632 as a base station, you must configure the R632 as a reference station.

In the R632 WebUI, click **Reference Station** on the left panel.

**Note:** The configurations before **Working Mode** are used if collecting raw data and converting to Rinex and are used to populate the header file.

To configure the R632 as a base station, set **Working Mode** to **Base**. Use the **Antenna Type** drop-down menu to select an antenna from the list or choose **Custom** for **Antenna Type**.

If choosing custom, type in the antenna phase center offsets and the base station coordinate.

To set the **Coordinate System**, you can select **Geodetic Coordinates** (latitude, longitude, and height) or **Cartesian** (ECEF reference frame). Type in a **Base Height**.


---

*Continued on next page*

## Configuring R632 as a Base Station, Continued

Base station configuration, continued

Type in an **Antenna Height** and **Measurement Mode**. For **Measurement Mode**, you can specify that the base coordinate is to the APC or to the antenna base. Click **Submit**.



**Reference Station**

**Working Mode:**  
 Working Mode:  Base  Rover  
 Base Position:  Single  Repeat Position  BaseLink  Smartlink

**Base Information:**  
 Observer Name: OBSERVER  
 Agency Name: AGENCY  
 Station Name: Test  
 Marker Number: 0  
 Marker Type: GEODETIC  
 Receiver Number: 0  
 Country Code: CHN - China  
 Side ID:  
 Time Zone: GMT+08:00

**Device Antenna:**  
 Antenna Type: HEMAS NONE  
 Antenna Serial:  
 R(mm): 0  
 H(mm): 0  
 HL1(mm): 45.8  
 HL2(mm): 40.5  
 Download  
 Choose File: No file chosen Upload

**Reference Coordinates:**  
 Coordinate System: Geodetic Coordinates (E,U,H)  
 Base Longitude: 113 21 59 82440  
 Base Latitude: 23 7 35 67690  
 Base Height: 30.000 (m)  
 Height of the point on the ground: 0.000 (m)  
 Load Current Position Get Average Position Cancel Base Position

**Diagram:**  
 Antenna Height (mm): 0  
 Measurement Mode: Antenna Phase Center


Submit

After setting up the base station, you will need to output RTK. Refer to the next section, Setting Up R632 RTK Output.

## Setting up R632 RTK Output

### NTRIP Server/Caster

To setup as an NTRIP server, select **NTRIP server** from the dropdown menu on the left panel.



The screenshot shows the Hemisphere software interface. The top navigation bar includes: STATUS, SKY VIEW, SIGNAL CHART, COMPASS, SPECTRUM ANALYZER, DEVICE INFORMATION, DOWNLOAD, and SETTINGS. The left sidebar menu is expanded to show 'Ntrip Server' selected. The main content area is titled 'Ntrip Server' and contains a 'Transfer List' table with columns: Name, Server Address, Mountpoint, Data Type, Interval, Status, Start Time, Data Size, and Operation. Below the table is a 'Create New Transfer' form with the following fields:

- Name:
- Server Address:
- Server Port:
- Network:
- Version:
- Password:
- Mountpoint:
- Data Type:  RTCM3.0  CMR  CMR+  RTCM3.2  ROX  DGPS  RAW
- Auto Connect:  Enable  Disable

At the bottom of the form are 'Create' and 'Reset' buttons.

Type the credentials for the NTRIP caster (Name, Server Address, Server Port, Password, Mountpoint, etc.). Select **Data Type**. Use RTCM3.2 or ROX for best performance. RTCM 3.0 is GPS+GLONASS only.


## Setting up R632 RTK Output, Continued

### External UHF Radio

To output RTK over serial, click **Port Configuration**. Click on the COM port you wish to use to output RTK (COM3 is RS-232 and the COM1 and COM2 are RS-485). Check your cable to see the COM port to which you have access.

Set the COM port to **Enable**. Set the baud rate. For the function of the COM port, set to RTK(Output). Configure the RTK message type. We suggest using RTCM3.2 or ROX for output observations for all constellations / signals.

Next, connect this serial port to an external radio. Most radios will require a null modem connection. (Contact HGNS for the DB26 to null modem DB9.)



The screenshot shows the Hemisphere software interface with the 'Port Configuration' screen active. The interface includes a navigation menu on the left and a main content area. The 'Port Configuration' section contains a 'Ports Summary' table and a 'Port Configuration' section for Bluetooth.

Port	Status	Baud Rate	Protocol	Mode	Port	Function
COM3	Enable					COM3
UHF	Close	440 125 MHz	South 6000	-	-	RTK_OUT(RTCM3)
COM1	Close	115200	RS485	-	-	COM1
COM2	Close	115200	RS485	-	-	COM2
COM3	Enable	115200	RS232			RTK_OUT(RTCM3)
Ntrip Client	Close	-	NTRIP	CLIENT	-	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP	SERVER	6000	RTK_OUT(RTCM3)
Socket 2	Close	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

Below the table, the 'Port Configuration' section for Bluetooth is visible, showing a 'Bluetooth' dropdown menu, an 'Enable' radio button (selected), a 'Disable' radio button, and a 'Function' dropdown menu set to 'CMD(Input/Output)'. There are 'Save' and 'Reset' buttons at the bottom right of the configuration area.


*Continued on next page*

## Setting up R632 RTK Output, Continued

### Internal UHF Radio

To output RTK over UHF, select the UHF radio. Set **Function** to **RTK(Output)**.

Select options to configure radio settings. Set the frequency, protocol. Channel spacing, FEC, and transmit power. Select the **RTK(Output)** format.



The screenshot shows the Hemisphere software interface with the 'SETTINGS' tab selected. The 'Port Configuration' section is expanded to show the 'UHF' radio settings. The settings are as follows:

Socket	Status	Protocol	Server	Port	Format
Socket 3	Close	TCP	SERVER	9001	RAW
Socket 4	Close	TCP	SERVER	9001	RAW
Socket 5	Close	TCP	SERVER	9001	RAW

**Port Configuration :**

- UHF:  Enable  Disable
- Radio Channel: 2 (449.125 MHz) [Default Frequency]
- Radio Protocol: South 9500
- Radio Power: High
- Channel Spacing: 12.5
- FEC: QM
- Function: RTK(Output)
- Data Type: RTCM3.0

Buttons: [Save] [Reset]

Footer: [techsupport@hignss.com](mailto:techsupport@hignss.com)  
© Copyright 2022 Hemisphere GNSS. All Rights Reserved.

*Continued on next page*


## Setting up R632 RTK Output, Continued

### NTRIP Caster

The R632 has a built-in NTRIP caster. You can configure the built-in NTRIP server to send data to the built-in NTRIP caster.

Click **Network** on the left menu. If you are connected via Ethernet, select the **Enable** radio button next to **DHCP** and allow the network switch to determine an IP address, or disable DHCP and type in a static IP address.

If you are using a SIM card (that provides a public IP address), refer to [SIM and MicroSD cards](#) in this manual.



The screenshot displays the Hemisphere R632 web interface for network configuration. The left sidebar shows the 'Network' menu selected. The main content area is titled 'Network' and includes the following sections:

- The Running Network:** Priority Network (Wired Net selected), Switch Strategy (Local Network selected), Current Network (NONE), Default Gateway (0.0.0.0), DNS (114.114.114.114), PING Timeout (10), PING Counts (10), and PING Address (X.Y.Z.X|X2.Y2.Z2.K2|X3.Y3.Z3.K3).
- Web Server:** Web Server Protocol (HTTP), HTTP Server Port (80).
- Wired Net:** Wired Net (WAN selected), DHCP (Enable selected), IP (0.0.0.0), Mask (0.0.0.0), Gateway (0.0.0.0), MAC address (D4:53:83:5E:D7:BE), Bit Rate (0 Mbit/s), Signal Level (0 dBm), Channel (0), Wi-Fi Link Status (Power ON), Wi-Fi Status (No internet access), and Virtual AP (Disable selected).
- Mobile Net:** Mobile Net (Enable selected), APN (cmnet), User, Password, Network Type (Auto selected), Authentication Algorithm, Modem Version (EG23G6880 /AU /M2G), IP (0.0.0.0), Mask (0.0.0.0), Gateway (0.0.0.0), Signal Level (0%), Mobile Isp (Linkdown), Mobile Link Status (Power OFF), and Mobile Status (No internet access).


At the bottom of the page, there is a footer with contact information: techsupport@hemisphere.com and © Copyright 2022 Hemisphere GNSS. All rights Reserved.

*Continued on next page*

## Setting up R632 RTK Output, Continued

NTRIP Caster,  
continued

Go to **Port Configuration** and click **NTRIP Caster**. Select **Enable** to set a port. If the R632's NTRIP server(s) is pointing to this IP address, you can use the R632 as an NTRIP caster.



The screenshot shows the Hemisphere software interface with the 'Port Configuration' screen active. The left sidebar contains a navigation menu with options: Reference Station, GNSS Configuration, Tracking Solutions, Heading, Ntrip Server, Recording, Port Configuration (selected), Network, and Administration. The main area displays a 'Ports Summary' table with the following data:

Port	Status	Baud Rate	Protocol	Mode	Port	Function
USB	Enable					USB
UHF	Close	440 125 MHz	South 5000	-	-	RTK_OUT(RTKMD)
COM1	Close	115200	RS485	-	-	CMD
COM2	Close	115200	RS485	-	-	CMD
COM3	Enable	115200	RS485			RTK_OUT(RTKMD)
Ntrip Client	Close	-	NTRIP	CLIENT	-	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP	SERVER	6000	RTK_OUT(RTKMD)
Socket 2	Close	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW


Below the table, there is a 'Port Configuration' section for Bluetooth, with a dropdown menu set to 'Bluetooth'. The 'Bluetooth' status is 'Enable' (checked) and the 'Function' is 'CMD(Input/Output)'. There are 'Save' and 'Reset' buttons at the bottom right of the configuration area.

At the bottom of the page, there is a footer with the text: TechSupport@hkgNSS.com © Copyright 2022 Hemisphere GNSS. All Rights Reserved.

## Logging Raw Data

### Logging Raw Data

To record data for converting to Rinex, go to the **Data Recording** tab. The current data logs are displayed. To create a new file, click **New Session**.



Click the **Add Recording** dropdown menu to select and append an existing record, or type a **Schedule Name**, then select a **Path Type** and **File Name**. Click the arrow to select the **File System** (i.e., storage location).

Complete the remaining fields to set the other options. Click **Enable** to automatically convert this data file to your preferred version of Rinex.

You can convert the raw files (.dat file extension) to Rinex. In the example above, a file has been converted to Rinex version 2.11 and 3.02.



## Chapter 3: Installing the R632

### Overview

---

**Introduction** This chapter describes the steps to install and the equipment you need to install the R632.

---

### Contents

Topic	See Page
Routing and Securing the Antenna Cable	58
Measuring Antenna Dimensions	59
Mounting the Antennas	61
Heading Configuration	62
Measuring R632 Dimensions	67
Mounting the R632	69
Connecting the R632	75
Connecting the Receiver to External Devices	77
Connecting the Receiver to External Accessories	84

---

## Routing and Securing the Antenna Cable

---

### Routing and securing the antenna cable

To route and secure the antenna cables, review the following guidelines.

Prior to selecting a cable, consider the attenuation of the cable. Attenuation of a cable is often specified at dB/100m and is related to the frequency of the signal being transmitted. GNSS signals are in the L-band frequency-which ranges from 1GHz –2GHz.

The R632 is designed to work with active GNSS antennas with an LNA gain range of 10 to 40 dB. The purpose of the range is to accommodate for losses in the cable system.

There is a maximum cable loss budget of 30 dB for a 40 dB gain antenna. The A45 antenna gain is 30 dB and has an antenna loss budget of 20 dB.

---

## Measuring Antenna Dimensions

### Antenna dimensions

Hemisphere offers two antennas available for purchase with your R632: the A45 (dual-frequency) antenna and the A25 (single-frequency) antenna.


The phase center measurements are important when using an RTK positioning solution with a dual frequency antenna (A45).

The phase center measurements for the A45 antenna are:

L1=45.8

L2=40.5

Figure 3-1 shows the antenna dimensions.



**Figure 3-1: Antenna dimensions**


*Continued on next page*

## Measuring Antenna Dimensions, Continued

---

### Antenna alignment

An arrow on the bottom of the antenna indicates the forward-facing direction for heading, and the marks on the side of the antenna allow you a “zero” point for measuring the height of the antennas for the surface on which it is mounted. The height is relative to the accuracy of the RTK solution. Figure 3-2 shows the antenna arrow and alignment marks.



**Figure 3-2: Antenna arrow and alignment marks**

---

## Mounting the Antennas

---

### Default configuration

The default configuration is a single antenna position solution. The R632 can be upgraded to a dual antenna heading solution with the addition of an activation purchased from HGNSS or an HGNSS authorized dealer.

---

### Parallel antennas orientation

The most common installation is to orient the antennas parallel to, and along the centerline of, the axis of the vessel with the primary antenna near the stern and the secondary antenna near the bow. This provides a true heading since heading is calculated from the primary to secondary antenna. If the primary antenna is near the bow and secondary antenna near the stern, you will need a heading bias of approximately 180°.

In this orientation, you may need to enter a small heading bias in the RS632 to calibrate the physical heading to the true heading of the vessel.

---

### Perpendicular antenna orientation

You can also install the antennas, so they are oriented perpendicular to the centerline of the vessel's axis.

In this orientation, you will need to enter a heading bias of +90° if the primary antenna is on the star side of the vessel, and -90° if the primary antenna is on the port side of the vessel.

---

### Planning the optimal antenna placement

Proper antenna placement is critical to positioning accuracy. For the best results, orient the antennas so the antennas' connectors face the same direction. Place the antennas with a clear view of the horizon, away from other electronics and antennas, and along the vessel's centerline. When mounting the primary and secondary antennas, consider the following:

- The recommended minimum separation is 0.5m.
  - The maximum separation is 10.0m if the receiver has a multi-frequency activation. If the receiver is only activated for single frequency, the maximum separation is 5.0m.
  - The position is calculated from the primary antenna.
  - Maintain at least 25cm distance from transmitting radios/antennas, as they may interfere with GNSS.
  - Maintain a clear view of the sky, avoiding metal obstructions at a higher elevation than the antenna (when possible).
-


## Heading Configuration

### Heading configuration

If using the R632 as a dual antenna GNSS position + heading solution, you can configure several heading parameters.

Click **Heading** on the left side of the screen.

**Note:** Heading requires an activation.



*Continued on next page*

## Heading Configuration, Continued

---

### Heading configuration, continued

The ACC90 and ACC180 values are dependent on the orientation of the R632 with respect to the antennas. The R632 provides heading, pitch, and roll. An internal gyro allows for the receiver to provide heading for up to 3 minutes during a GNSS outage. For pitch and roll, one axis is calculated from the antenna array and the other axis is calculated from an internal sensor. The ACC90 and ACC180 values are critical for using the gyro during a GNSS outage and for calculating either pitch or roll (whichever is coming from the internal sensor).

When you configure the ACC90/ACC180 values, the internal sensor value will calibrate to zero. It is important that the vehicle/vessel is level.

---

*Continued on next page*

## Heading Configuration, Continued

---

### Heading configuration, continued

The **Heading** page contains the **ACC90** and **ACC180** values. To determine which values to use for ACC90 and ACC180, refer to [Mounting the Antennas](#).

Please note that any changes to the ACC90 and ACC180 values will automatically perform a tilt calibration of the R632's internal gyro. These should not be changed unless the R632 is properly oriented and in a static environment.

#### **Additional items covered in this page:**

**Roll** – If set to YES, the roll value that outputs from the receiver will be based on the antenna array and the pitch value will be calculated from the sensor. If set to NO, the pitch value that outputs from the receiver will be based on the antenna array and the roll value will be calculated from the sensor.

**Neg Tilt** – If set to YES, the sign of the pitch (or roll) value calculated from the antenna array will be reversed.

**GyroAid** – If enabled, the internal gyro will be used to maintain heading for up to 3 minutes during a GNSS outage. **If gyroaid is used, the ACC90/ACC180 values must be properly configured.**

**Level** – You can use level if the vector is always operated within +/- 10 degrees of level. This will improve heading acquisition time at startup.

**MoveBase** – This can only be set to YES if you have a multi-frequency activation. Setting MOVEBAS to YES will enable the receiver to automatically calculate the antenna separation.

**CSEP** – The calculated separation between the primary and secondary antennas.

---

*Continued on next page*



## Heading Configuration, Continued

---

### Heading configuration, continued

**MSEP** – If MOVEBAS is set to NO, the slope distance (measured in meters) between the primary and secondary antenna must be entered.

**PBIAS** – This adds an offset to the pitch (or roll) value calculated by the antenna array. **WARNING:** Adding a PBIAS does not account for the roll of the vessel or vehicle.

**HBIAS** – This adds an offset to the heading value calculated by the antenna array. **WARNING:** Heading is the angle that the projection of the vector onto the horizontal plane makes with respect to north. HBIAS simply adds a constant value to heading.

**HTAU** – This value adjusts the responsiveness of the heading measurement provided. The higher the value, the more smoothing is in place. If you are not sure what to set the value to, you can use the following formula:

#### **Gyro On**

$\text{htau (in seconds)} = 40 / \text{maximum rate of turn (in deg/sec)}$

#### **Gyro Off**

$\text{htau (in seconds)} = 10 / \text{maximum rate of turn (in deg/sec)}$

**HRTAU** – This value adjusts the responsiveness of the rate of turn measurement. The higher the value the more smoothing. If you aren't sure what to set this to, you can use the following formula:

**HRTAU (in seconds) = 10 / maximum rate of turn (in deg / sec<sup>2</sup>)**

**COGTAU** – This value adjusts the responsiveness of the course over ground measurement. If you are not sure what to set it to, use the following formula:

**COGTAU (in seconds) = 10 / maximum change of course (in deg / sec)**

---


*Continued on next page*

## Heading Configuration, Continued

Heading configuration, continued

**SPDTAU** – This value adjusts the responsiveness of the speed measurement (such as velocity in \$GPVTG). If you are unsure what to set it to, use the following formula:

$$\text{SPDTAU (in seconds)} = 10 / \text{maximum acceleration (in m/s}^2\text{)}$$



The screenshot shows the Hemisphere software interface with the 'Heading' settings page. The left sidebar contains a menu with options: Reference Station, GNSS Configuration, Tracking Satellites, Heading (selected), Map Server, Recording, Port Configuration, Network, and Administration. The main content area is titled 'Heading' and contains various configuration fields:

- Heading(°): 0.000
- Compass rose(°): 0.000
- Pitch(°): 0.000
- Heave(m):
- ACGR0:  Enable  Disable
- ACC150:  Enable  Disable
- ROLL:  Enable  Disable
- GYROAID:  Enable  Disable
- TILTAD:  Enable  Disable
- LEVEL:  Enable  Disable
- MOVEBAS:  Enable  Disable
- DYNBASE:  Enable  Disable
- CSEP(m): 1.000
- MSE(PPM): 1
- PBAS(°): 0
- HBAS(°): 0
- PTAU(s): 0.5
- HTAU(s): 0.5
- HRTAU: 2
- COXTAU: 0
- SPDTAU: 0
- COGC(°): 0.000
- Speed(Km/h): 0.000
- Roll(°): 0.000
- ROT(min):

At the bottom right of the settings area, there are 'Save' and 'Reset' buttons. The footer of the software interface includes the text: 'TechSupport@Hemisphere.com' and '© Copyright 2022 Hemisphere GNSS, All Rights Reserved.'

## Measuring R632 Dimensions

### R632 dimensions

Figures 3-3 through 3-6 show the dimensions of the R632 receiver.




Figure 3-3: R632 receiver length





Figure 3-4: R632 bracket

*Continued on next page*


## Measuring R632 Dimensions, Continued

---

**R632**  
dimensions,  
continued



**Figure 3-5: R632 width**



**Figure 3-6: R632 height**

---

## Mounting the R632

---

**Introduction** This section provides information on mounting the R632 in the optimal location, orientation considerations, environmental considerations, and other mounting options.

---

**GNSS satellite reception** When considering where to mount the R632, consider the following satellite reception recommendations:

- Ensure cable length is adequate to route into the machine to reach a breakout box or terminal strip.
- Do not mount the receiver where environmental conditions exceed those specified in the technical specifications of this document.
- Route cables away from any potential source of mechanical damage. Do not locate the antenna where environmental conditions exceed those specified in [Appendix B, Technical Specifications](#) of this document.

---

**Environmental considerations** Hemisphere GNSS Receivers are designed to withstand harsh environmental conditions; however, adhere to the following limits when storing and using the R632:

- Operating temperature: -40°C to +70°C (-40°F to +158°F)
- Storage temperature: -40°C to +85°C (-40°F to +185°F)
- Humidity: IEC 16750-4:2010 Section 5.6 Humid heat, cyclic test

---

**Mounting options** The R632 allows for two different mounting options: mount with bolts, or mount with magnets.

---

*Continued on next page*

## Mounting the R632, Continued

### Power/Data cable considerations

Before mounting the R632, consider the following regarding power/data cable routing:

<b>Do</b>	<b>Do not</b>
Ensure cable reaches appropriate power source.	Run cables in areas of excessive heat.
Keep cable away from corrosive chemicals.	Run cables through a door or window jams.
Connect to a data storage device, computer, or other device that accepts GNSS data.	Crimp or excessively bend the cable.
Keep cable away from rotating machinery.	Place tension on the cable.
Remove unwanted slack from the cable at the R632 end.	
Secure along the cable route using plastic tie wraps.	

**⚠ WARNING:**

**Improperly installed cable near machinery can be dangerous.**

### Connecting the serial and power cable

To connect the serial and power cable:

- Align the cable connector keyway with the R632 connector key.
- Push the connector in until it locks. The locking action is firm; you will feel a positive “click” when it has locked.

**⚠ WARNING:**

**Do not apply a voltage higher than 36 VDC. This will damage the receiver and void the warranty. Also, do not attempt to operate the R632 with the fuse bypassed, as this will void the warranty.**

*Continued on next page*

## Mounting the R632, Continued

### Mounting orientation


Use the WebUI to configure the orientation of the receiver with respect to the antennas.

When you send, the pitch and roll values from the internal sensor will zero, meaning that this should only be sent when the receiver is parallel to the mounting surface.

If you are not configuring the ACC90 and ACC180 values, then ignore pitch and roll from the receiver and turn off the GYROAID and TILTAID.

### Group A

The R632 must be installed parallel or perpendicular to the plane of the antennas as shown in the images below.



\$JATT,ACC90,NO  
\$JATT,ACC180,NO

**Figure 3-7: Group A**


*Continued on next page*

## Mounting the R632, Continued

Mounting orientation, continued

### **Group B**

The R632 must be installed parallel or perpendicular to the plane of the antennas as shown in the images below.



\$JATT,ACC90,YES  
\$JATT,ACC180,NO

**Figure 3-8: Group B**

*Continued on next page*




## Mounting the R632, Continued

Mounting orientation, continued

### Group C

The R632 must be installed parallel or perpendicular to the plane of the antennas as shown in the images below.



\$JATT,ACC90,NO  
\$JATT,ACC180,YES

**Figure 3-9: Group C**


*Continued on next page*

## Mounting the R632, Continued

Mounting orientation, continued

### Group D

The R632 must be installed parallel or perpendicular to the plane of the antennas as shown in the images below.



\$JATT,ACC90,YES  
 \$JATT,ACC180,YES

**Figure 3-10: Group D**


## Connecting the R632

---

### Connectors

The R632 has a single DB26 connector for COMs. Hemisphere provides multiple cables that go from DB26 to various connectors and a breakout box.

Figure 3-11 shows the 26-pin connector and Table 3-1 lists the pin-out for the DB26 connector.



**Figure 3-11: R632 pin-out**

---

*Continued on next page*

## Connecting the R632, Continued

---

Connectors,  
continued

**Table 3-1: R632 pin-out**

Connector	Connector (Label)
1	RS485_2+
2	NC
3	NC
4	Reserved
5	Reserved
6	USB_VBUS
7	USB_P
8	USB_N
9	PPS
10	RS485_2-
11	RS-232 Tx
12	RS-232 Rx
13	GND
14	RJ45_ACT
15	RJ45_LINK
16	ETH
17	3VCC
18	EVENT
19	USB_ID
20	NC
21	RS485_1+
22	RS485_1-
23	RJ45_MX0_P
24	RJ45_MX0_N
25	RJ45_MX1_P
26	RJ45_MX1_N

---

## Connecting the Receiver to External Devices


### Connect to external devices

Using the built-in WebUI, you can connect the R632 to external devices via the Comm connectors. The R632 supports RTK input/output for an external radio, NMEA, and proprietary (proprietary data messages, ephemeris, and observation messages for converting to Rinex, etc.) message output over RS-232, RS-485, Bluetooth, TCP, and UDP.

In the WebUI, locate the **Port Configuration** tab. (To connect to the WebUI, see section [Connecting to the WebUI.](#))

**Note:** The fields highlighted in green are enabled.

To enable a port, click on the port (shown in bold). The port will be shown at the bottom of the screen. Click the **Enable** radio button next to the name of that port.



Port	Status	Baud Rate	Protocol	Mode	Port	Function
Bluetooth	Enable					COM1
UHF	Close	440.125 MHz	South 6000	-	-	RTK_OUT(RTCMD)
COM1	Close	115200	RS485	-	-	COM1
COM2	Close	115200	RS485	-	-	COM2
COM3	Enable	115200	RS232	-	-	RTK_OUT(RTCMD)
Ntrip Client	Close	-	NTRIP	CLIENT	-	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP	SERVER	6000	RTK_OUT(RTCMD)
Socket 2	Close	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

Port Configuration:

Bluetooth

Bluetooth  Enable  Disable

Function

Save Reset

*Continued on next page*


## Connecting the Receiver to External Devices, Continued

**Connect to external devices, continued**

The example below shows the **Bluetooth** port is selected and enabled.

Next, click the drop-down menu next to **Function** to select **NMEA(Output)**. A list of supported NMEA0183 and proprietary messages are displayed.

Click each drop-down menu to select the desired message and streaming rate.



The screenshot shows the Hemisphere software interface with the 'SETTINGS' tab selected. On the left, a navigation menu includes 'Reference Station', 'GNSS Configuration', 'Tracking Satellites', 'Heading', 'Ntrip Server', 'Recording', 'Port Configuration', 'Network', and 'Administration'. The 'Port Configuration' section is active, showing a table of ports and a configuration panel for the selected 'Bluetooth' port.

Socket	Enable	Protocol	Function	Port	Mode	
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

**Port Configuration:**  
 Bluetooth  Enable  Disable  
 Function: NMEA(Output)

**NMEA**

GGA	1Hz	GSA	OFF	DSV	OFF	ZDA	OFF
RMC	OFF	VTG	OFF	GST	OFF	GLL	OFF
HDT	OFF	PASHR	OFF	FM	OFF	HRP	OFF
KSXT	OFF	AJTSTAT	OFF	RTKSTAT	OFF	VCT	OFF
RD1	OFF	OGA2	OFF				

Buttons: [Save] [Reset]

Footer: [techsupport@hkgnss.com](http://techsupport@hkgnss.com)  
 © Copyright 2022 Hemisphere GNSS. All Rights Reserved.

*Continued on next page*

## Connecting the Receiver to External Devices, Continued

Connect to external devices, continued

This port can also be used for configuration. In this example, use the drop-down menu to select **CMD(Input/Output)**.

**Ports Summary :**

Port	Status	Baud Rate	Protocol	Mode	Port	Function
Bluetooth	Enable					CMD
LHF	Close	440 125 MHZ	South 9600	-	-	RTK_OUT(RTCM3)
COM1	Close	115200	RS485	-	-	CMD
COM2	Close	115200	RS485	-	-	CMD
COM3	Enable	115200	NTRIP			RTK_OUT(RTCM3)
Ntrip Client	Close	-	NTRIP	CLIENT	-	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP*	SERVER	6000	RTK_OUT(RTCM3)
Socket 2	Close	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

**Port Configuration :**

Bluetooth

Bluetooth  Enable  Disable

Function

TechSupport@Hemisphere.com  
© Copyright 2022 Hemisphere GNSS. All Rights Reserved.

Use the drop-down menu to select **RTK(Input)** to input RTK from an external source or select **RTK(Output)** to output RTK.

**Ports Summary :**

Port	Status	Baud Rate	Protocol	Mode	Port	Function
Bluetooth	Enable					CMD
LHF	Close	440 125 MHZ	South 9600	-	-	RTK_OUT(RTCM3)
COM1	Close	115200	RS485	-	-	CMD
COM2	Close	115200	RS485	-	-	CMD
COM3	Enable	115200	NTRIP			RTK_IN
Ntrip Client	Close	-	NTRIP	CLIENT	192.168.0.37	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Close	-	TCP*	SERVER	6000	CMD
Socket 2	Enable	-	TCP	SERVER	9000	RAW
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

**Port Configuration :**

Bluetooth

Bluetooth  Enable  Disable

Function

TechSupport@Hemisphere.com  
© Copyright 2022 Hemisphere GNSS. All Rights Reserved.


Continued on next page

## Connecting the Receiver to External Devices, Continued

Connect to external devices, continued

If you select **RTK(Output)**, you must also specify an RTK message format (**RTCM3.0, RTCM 3.2, CMR, ROX, or DGPS**).

Using the drop-down menu next to **Data Type**, click to highlight and select your desired message format.



Device	Status	Protocol	Port	IP Address	Output Format	
Ntrip Client	Close	-	NTRIP	CLIENT	192.168.0.37	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Enable	-	TCP	SERVER	8000	CMR
Socket 2	Enable	-	TCP	SERVER	9000	RTCM
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

Port Configuration:

Bluetooth:  Enable  Disable


Function: **RTK(Output)**

Data Type: **RTCM3.2**

Interval: 1HZ

Ephemers Frequency: OFF

Using the **Function** drop-down menu, select **RAW(Output)** for the binary messages necessary to convert to Rinex.



Device	Status	Protocol	Port	IP Address	Output Format	
Ntrip Client	Close	-	NTRIP	CLIENT	192.168.0.37	Access Data
Ntrip Caster	Close	-	NTRIP	CASTER	6070	Caster
Socket 1	Enable	-	TCP	SERVER	8000	CMR
Socket 2	Enable	-	TCP	SERVER	9000	RTCM
Socket 3	Close	-	TCP	SERVER	9001	RAW
Socket 4	Close	-	TCP	SERVER	9001	RAW
Socket 5	Close	-	TCP	SERVER	9001	RAW

Port Configuration:

Bluetooth:  Enable  Disable

Function: **RAW(Output)**

Interval: 1HZ

Ephemers Frequency: OFF

Continued on next page




## Connecting the Receiver to External Devices, Continued

**Connect to external devices,**  
continued

You can use the COM ports to output messages.

Click on a **COM** port (COM1, COM2, or COM3). Note that **COM3** is **RS232** protocol, and **COM1** and **COM2** are **RS485** protocol. If a **COM** port is selected, you must enter a Baud Rate. Supported baud rates are 4800, 9600, 19200, 38400, 57600, and 115200 bps.



The screenshot shows the Hemisphere software interface with the 'SETTINGS' tab selected. The 'Port Configuration' section is active, showing the following settings:

- COM3: Enable (checked), Disable
- Baud Rate: 115200
- Function: NMEA(Output)

The NMEA output options are as follows:

Option	Setting
GGA	1Hz
GSA	OFF
GSV	OFF
ZDA	OFF
RMC	OFF
VTG	OFF
GST	OFF
GLL	OFF
HDT	OFF
FASHR	OFF
FVI	OFF
HPR	OFF
KSKT	OFF
ATTSTAT	OFF
RTRSTAT	OFF
VDT	OFF
RDT	OFF
GGA2	OFF

At the bottom of the interface, there is a footer with the text: [TechSupport@Hemisphere.com](http://TechSupport@Hemisphere.com) © Copyright: 2022 Hemisphere GNSS. All Rights Reserved.

*Continued on next page*

## Connecting the Receiver to External Devices, Continued

**Connect to external devices, continued**


You can also output messages over TCP or UDP.

Under **I/O Configuration**: use the drop-down menu to select **Socket 1**, **Socket 2**, **Socket 3**, **Socket 4**, or **Socket 5**.

Next to **Type**, use the drop-down menu to select between **UDP** or **TCP**.

Click the drop-down menu next to **Mode** to select either **Server** or **Client**.

Next to **Port**, type in a port name.




The screenshot shows the Hemisphere software interface with the 'Port Configuration' window open. The 'Socket 1' dropdown is selected. The 'Type' is set to 'TCP', 'Mode' is 'Server', and 'Port' is '5550'. The 'Function' is 'NMEA(Outout)'. The 'NMEA' section contains a grid of checkboxes for various NMEA sentences: GGA, 1Hz, GSA, OFF, GSV, OFF, ZDA, OFF, RMC, OFF, VTG, OFF, DST, OFF, GLL, OFF, HDG, OFF, FASHR, OFF, FVI, OFF, HPR, OFF, KRXI, OFF, ATTSAT, OFF, RTKSTAT, OFF, VGT, OFF, RDT, OFF, GGAE, OFF. The 'Record' section has 'Enable/Disable' selected and 'Internal' chosen. The 'Pool' is set to 'MB'. There are 'Save' and 'Reset' buttons at the bottom right.

## Connecting the Receiver to External Accessories

### Connect external accessories

Using the port connections, you can connect the R632 to an external antenna, external power supply, or an LTE or UHF connector. Figure 3-12 shows the R632 external connections.



**Figure 3-12: R632 External Connections**

Refer to the following table a description of the external port connections and functions.

**Table 3-2: External connections**

	<b>Function</b>	<b>Connection</b>
1	To reach work status	Connect to the external antenna to connect to the GNSS1/2.
2	To power on	Connect to the 2-pin power supply cable.
3	To use the SIM card	Insert the SIM card and connect the 4G antenna to the LTE connector.
4	To use the radio	Connect the UHF antenna to the UHF connector.

## Appendix A: Troubleshooting

### Overview

---

**Introduction** Appendix A provides solutions to common questions when operating the R632 receiver.

---

### Contents

	<b>Topic</b>	<b>See Page</b>
	Troubleshooting	85

---

## Troubleshooting

Troubleshooting **Table A-1: R632 Troubleshooting**

Symptom	Possible Solution
Receiver fails to power on	<ul style="list-style-type: none"> <li>• Check to see if the power LED is lit.</li> <li>• Verify polarity of power leads.</li> <li>• Check integrity of power cable connectors.</li> <li>• Check power input voltage (8 to 36 VDC).</li> <li>• Check the voltage from the connector at the end of the cable.</li> <li>• Check current restrictions imposed by power source.</li> </ul>
No data from R632	<ul style="list-style-type: none"> <li>• Check receiver power status to ensure the receiver is powered on.</li> <li>• Use the WebUI to verify desired messages are turned on.</li> <li>• Ensure the baud rate of the R632 matches that of the receiving device.</li> <li>• Check integrity and connectivity of power and data cable connections.</li> </ul>
Random data from R632	<ul style="list-style-type: none"> <li>• Verify that RTCM or binary messages are not being output (use the WebUI to see which messages are enabled).</li> <li>• Ensure the baud rate of the R632 matches that of the remote device.</li> </ul>
No GNSS lock	<ul style="list-style-type: none"> <li>• Verify the R632 has a clear view of the sky.</li> <li>• Use the WebUI to see how many satellites are in view and the SNR values.</li> </ul>

*Continued on next page*

## Troubleshooting, Continued

**Troubleshooting** **Table A-1: R632 Troubleshooting (continued)**  
, continued

Symptom	Possible Solution
No heading or incorrect heading value	<ul style="list-style-type: none"> <li>• Ensure MSEP value is correct, within 2 cm.</li> <li>• Check CSEP value is constant without varying more than 1 cm (0.39 in)—larger variations may indicate a high multipath environment and require moving the receiver location.</li> <li>• The R632 calculates heading from the primary to secondary GNSS antenna (the secondary antenna has an arrow underneath). Ensure via the WebUI there is not a heading bias added to the heading solution.</li> <li>• Check to make sure the R632 has a heading activation.</li> </ul>
R632 will not go RTK fixed	<ul style="list-style-type: none"> <li>• Check to see if the UHF indicator is blinking. If it is not blinking, check to see if the UHF base radio is transmitting data.</li> <li>• Ensure the frequency and settings (modulation, protocol, channel spacing, forward error corrections, and scrambling) of the base radio match the R632 radio.</li> <li>• Check other R632 receivers in the same area are going RTK Fixed. If they are not, the area may not have UHF coverage. Check if the R632 works closer to the base radio. Installation of a repeater may be necessary.</li> </ul>

*Continued on next page*

## Troubleshooting, Continued

Troubleshooting **Table A-1: R632 Troubleshooting (continued)**  
, continued

Symptom	Possible Solution
R632 will not go RTK fixed (continued)	<ul style="list-style-type: none"> <li>• Check the RTK latency. If the R632 remains in RTK Float, but the latency keeps climbing, this usually indicates the radio settings are correct, but the environment is poor (or lacks adequate UHF coverage). If the RTK latency is consistently 1, but the R632 stays RTK Float, ensure the R632 has an RTK activation.</li> </ul>
Constellations	<ul style="list-style-type: none"> <li>• If the R632 is not using satellites from a specific constellation (such as Galileo or BeiDou), verify the base station supports those constellations. Only satellites used at the base station can be used at the rover.</li> <li>• Check the WebUI for multi-GNSS activation.</li> </ul>
Atlas Corrections Are Not Working	<ul style="list-style-type: none"> <li>• Check your subscription end-date in the WebUI.</li> <li>• Use the L-band tab to check the frequency and bandwidth of the tracked satellite. We suggest pressing <b>Auto</b> to use your position to automatically tune to the correct frequency for your region.</li> </ul>

## Appendix B: Technical Specifications

### Overview

---

**Introduction** Appendix B lists the technical specifications of your R632 GNSS receiver.

---

### Contents

	<b>Topic</b>	<b>See Page</b>
	Technical Specifications	89

---



## Technical Specifications

### R632 Technical specifications

**Table B-1: Receiver**

Item	Specification
Receiver Type	Multi-Frequency GPS, GLONASS, BeiDou, Galileo, QZSS, NavIC (IRNSS*), and Atlas L-band
Signals Received	GPS L1CA/L1P/L1C/L2P/L2C/L5 GLONASS G1/G2/G3, P1/P2 BeiDou B1i/B2i/B3i/B10C/B2A/B2B/ ACEBOC GALILEO E1BC/E5a/E5b/E6BC/ALTBOC QZSS L1CA/L2C/L5/L1C/LEX NavIC (IRNSS)* L5 Atlas L-band
GPS Sensitivity	-142 dBm
SBAS Tracking	3-channel, parallel tracking
Update Rate	10 Hz standard, 20 Hz optional (with activation)
Timing (PPS) Accuracy	20 ns
Cold Start	60 s typical (no almanac or RTC)
Warm Start	30 s typical (almanac and RTC)
Hot Start	10 s typical (almanac, RTC and position)
Antenna Input Impedance	50 $\Omega$
Maximum Speed	1,850 kph (999 kts)
Maximum Altitude	18,000 m (59,055 ft)

\*NavIC (IRNSS) will be available as a future firmware update.

*Continued on next page*

## Technical Specifications, Continued

R632 Technical specifications, continued

**Table B-1: Receiver (continued)**

Item	Specification		
Heading (RMS)	0.2° @ 0.5 m antenna separation 0.1° @ 1.0 m antenna separation 0.05° @ 2.0 m antenna separation		
Positioning (RMS)		Horizontal	Vertical
	Single Point	1.2 m	2.4 m
	SBAS <sup>1</sup>	0.3 m	0.6 m
	Atlas H10 <sup>1</sup>	0.04 m	0.08 m
	Atlas H30 <sup>1,3</sup>	0.15 m	0.3 m
	Atlas Basic <sup>1,3</sup>	0.5 m	1.0 m
	RTK <sup>1,2</sup>	8 mm + 1 ppm	15 mm + 1 ppm

*Continued on next page*

## Technical Specifications, Continued

R632 Technical specifications, continued

**Table B-2: L-band receiver**

Item	Specification
Receiver Type	Single Channel
Frequency Range	1525 to 1560 MHz
Sensitivity	-130 dBm
Channel Spacing	5.0 kHz
Satellite Selection	Manual and Automatic
Reacquisition Time	15 seconds (typical)

**Table B-3: Communications**

Item	Specification
Bluetooth	Bluetooth 2.1+EDR / 4.0 LE
Wi-Fi	802.11 b/g
Network	LTE FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/ B18/B19/B20/B25/B26/B28 LTE TDD: B38/B39/B40/B41 UMTS: B1/B2/B4/B5/B6/B8/B19 GSM: B2/B3/B5/B8
Radio	Frequency range: 410MHz ~ 470MHz and 902.4MHz ~ 928MHz Channel Spacing: 12.5 KHz / 25 KHz Protocol: TrimTalk 450S, PCC EOT, TrimMark III(19200)
RTK Formats	RTCM2.1, RTCM2.3, RTCM3.0, RTCM3.1, RTCM3.2 including MSM
Correction I/O Protocol	Hemisphere GNSS proprietary ROX format, RTCM v2.3, RTCM v3.2, CMR, CMR+
Data I/O Protocol	NMEA 0183, Hemisphere GNSS binary
Timing Output	PPS (CMOS, rising edge sync)
Event Marker Output	Open drain, falling edge sync, 10 kΩ, 10 pF load

*Continued on next page*

## Technical Specifications, Continued

R632 Technical specifications, continued

**Table B-4: Physical**

Item	Specification
Weight	550 g
Dimensions	105 x 150 x 34 mm
Power Connector	2-pin metal ODU
Antenna Connector	TNC female, straight (2x)
Data Connector	D-SUB 26 (2x RS485, 1x RS232, 1x USB2, 1x PPS, 1x Event, 1x 100m Ethernet)
LTE Connector	SMA
UHF Connector	SMA
Other: Storage Type	Micro SIM card slot and Micro SD card slot 8 GB internal, Micro SD card up to 32 GB

**Table B-5: Environmental**

Item	Specification
Operating temperature	-30°C ~ +65°C
Storage temperature	-40°C ~ +80°C
Protection	IP6x, IPx6, IPx7
Shock Resistance	EP455 Section 5.41.1 Operational
Humidity	95% non-condensing
Vibration	EP455 Section 5.15.1 Random
EMC	CE (IEC 60945 Emissions and Immunity) FCC Part 15, Subpart B, CISPR22
Inflammability	UL recognized, 94HB Flame Class Rating (3) 1.49 mm
Chemical Resistance	Cleaning agents, soapy water, industrial alcohol, water vapor, solar radiation (UV)

*Continued on next page*

## Technical Specifications, Continued

---

R632 Technical specifications, continued

**Table B-6: Electrical**

Item	Specification
Input Voltage	8 to 36 V DC
Power Consumption	7.65W nominal (all signals + L-band)
Reverse Polarity Protection	Yes
Antenna Voltage Output	5 V DC maximum
Antenna Short Circuit Protection	Yes
Input Range	10 to 40 dB

**Table B-7: User Interface**

Item	Specification
LEDs	Power, Satellite, Bluetooth, Cellular, Wi-Fi, UHF, Heading <sup>3</sup>
WebUI	Supports software updates, receiver status and settings and data downloads via smartphones, tablets, or other Wi-Fi capable devices.

<sup>1</sup>Depends on multipath environment, number of satellites in view, satellite geometry, and ionospheric activity.

<sup>2</sup>Depends also on baseline length.

<sup>3</sup>Requires an activation or subscription from Hemisphere GNSS.

## Index

---

Activation.....	6
ANT-S10 .....	60
Athena RTK .....	12
Atlas .....	6
Atlas L-band .....	13
BeiDou .....	6
Firmware.....	7
GALILEO .....	7
GLONASS.....	7
<b>LED Indicators</b> .....	18
Multipath .....	8
NMEA.....	8
NTRIP .....	12
phase center .....	13
Power/Data cable .....	70
PPS .....	8, 19, 76, 89, 91, 92
RTCM .....	9, 85
SBAS.....	9
Subscription.....	9
UHF .....	86, 87
WebUI.....	85

---

# End User License Agreement

---

## End User license agreement

**IMPORTANT** - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
  - a. install or use more copies of the Software than the number of copies that have been licensed;
  - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
  - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
  - d. modify or create derivative works based on the Software;
  - e. sub-license, rent, lease, loan or distribute the Software;
  - f. permit any third party to use the Software;
  - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
  - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
  - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at anytime.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** "Hemisphere GNSS", "Crescent", "Eclipse" and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential positioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.
12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.

---

*Continued on next page*



## End User License Agreement, Continued

---

### End User license agreement, continued

13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere. 19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a) negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product,

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

- (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
19. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
20. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
21. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
22. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
23. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
24. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
25. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
26. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

**GENERAL.** This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.

---

## Warranty Notice

---

### Warranty notice

**COVERED PRODUCTS:** This warranty covers all products manufactured by Hemisphere GNSS and purchased by the end purchaser (the "Products"), unless otherwise specifically and expressly agreed in writing by Hemisphere GNSS.

**LIMITED WARRANTY:** Hemisphere GNSS warrants solely to the end purchaser of the Products, subject to the exclusions and procedures set forth below, that the Products sold to such end purchaser and its internal components shall be free, under normal use and maintenance, from defects in materials, and workmanship and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for a period of 12 months from delivery of such Product to such end purchaser (the "Warranty Period"). Repairs and replacement components for the Products are warranted, subject to the exclusions and procedures set forth below, to be free, under normal use and maintenance, from defects in material and workmanship, and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater.

**EXCLUSION OF ALL OTHER WARRANTIES.** The LIMITED WARRANTY shall apply only if the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS relevant User's Manual and Specifications, AND the Product is not modified or misused. The Product is provided "AS IS" and the implied warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE and ALL OTHER WARRANTIES,

express, implied or arising by statute, by course of dealing or by trade usage, in connection with the design, sale, installation, service or use of any products or any component thereof, are EXCLUDED from this transaction and shall not apply to the Product. The LIMITED WARRANTY is IN LIEU OF any other warranty, express or implied, including but not limited to, any warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE, title, and non-infringement.

**LIMITATION OF REMEDIES.** The purchaser's EXCLUSIVE REMEDY against Hemisphere GNSS shall be, at Hemisphere GNSS's option, the repair or replacement of any defective Product or components thereof. The purchaser shall notify Hemisphere GNSS or a Hemisphere GNSS's approved service center immediately of any defect. Repairs shall be made through a Hemisphere GNSS approved service center only. Repair, modification or service of Hemisphere GNSS products by any party other than a Hemisphere GNSS approved service center shall render this warranty null and void. The remedy in this paragraph shall only be applied in the event that the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS's relevant User's Manual and Specifications, AND the Product is not modified or misused. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR CONTINGENT DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE

TO PURCHASER, even if Hemisphere GNSS has been advised of the possibility of such damages. Without limiting the foregoing, Hemisphere GNSS shall not be liable for any damages of any kind resulting from installation, use, quality, performance or accuracy of any Product.

**HEMISPHERE IS NOT RESPONSIBLE FOR PURCHASER'S NEGLIGENCE OR UNAUTHORIZED USES OF THE PRODUCT.**

IN NO EVENT SHALL Hemisphere GNSS BE IN ANY WAY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM PURCHASER'S OWN NEGLIGENCE, OR FROM OPERATION OF THE PRODUCT IN ANY WAY OTHER THAN AS SPECIFIED IN Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS is NOT RESPONSIBLE for defects or performance problems resulting from (1) misuse, abuse, improper installation, neglect of Product; (2) the utilization of the Product with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Hemisphere GNSS; (3) the operation of the Product under any specification other than, or in addition to, the specifications set forth in Hemisphere GNSS's relevant User's Manual and Specifications; (4) damage caused by accident or natural events, such as lightning (or other electrical discharge) or fresh/ salt water immersion of Product; (5) damage occurring in transit; (6) normal wear and tear; or (7) the operation or failure of operation of any satellite-based positioning system or differential correction service; or the availability or performance of any satellite-based positioning signal or differential correction signal.

**THE PURCHASER IS RESPONSIBLE FOR OPERATING THE VEHICLE SAFELY.** The purchaser is solely responsible for the safe operation of the vehicle used in connection with the Product, and for maintaining proper system control settings. UNSAFE DRIVING OR SYSTEM CONTROL SETTINGS CAN RESULT IN PROPERTY DAMAGE, INJURY, OR DEATH.

---

*Continued on next page*

## Warranty Notice, Continued

---

### Warranty notice, continued

The purchaser is solely responsible for his/her safety and for the safety of others. The purchaser is solely responsible for maintaining control of the automated steering system at all times. THE PURCHASER IS SOLELY RESPONSIBLE FOR ENSURING THE PRODUCT IS PROPERLY AND CORRECTLY INSTALLED, CONFIGURED, INTERFACED, MAINTAINED, STORED, AND OPERATED IN ACCORDANCE WITH Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS does not warrant or guarantee the positioning and navigation precision or accuracy obtained when using Products. Products are not intended for primary navigation or for use in safety of life applications. The potential accuracy of Products as stated in Hemisphere GNSS literature and/or Product specifications serves to provide only an estimate of achievable accuracy based on performance specifications provided by the satellite service operator (i.e. US Department of Defense in the case of GPS and differential correction service provider. Hemisphere GNSS reserves the right to modify Products without any obligation to notify, supply or install any improvements or alterations to existing Products.

**GOVERNING LAW.** This agreement and any disputes relating to, concerning or based upon the Product shall be governed by and interpreted in accordance with the laws of the State of Arizona.

**OBTAINING WARRANTY SERVICE.** In order to obtain warranty service, the end purchaser must bring the Product to a Hemisphere GNSS approved service center along with the end purchaser's proof of purchase. Hemisphere GNSS does not warrant claims asserted after the end of the warranty period. For any questions regarding warranty service or to obtain information regarding the location of any of Hemisphere GNSS approved service center, contact Hemisphere GNSS at the following address:

**Hemisphere GNSS**

8515 E. Anderson Drive Scottsdale, AZ 85255, USA

Phone: +1-480-348-6380

Fax: +1-480-270-5070

[TECHSUPPORT@HGSS.COM](mailto:TECHSUPPORT@HGSS.COM)

[WWW.HGSS.COM](http://WWW.HGSS.COM)

---



Hemisphere GNSS Inc.  
8515 East Anderson Drive  
Scottsdale, Arizona, US 85255  
Phone: 480-348-6380  
Fax: 480-270-5070  
[PRECISION@HGNSS.COM](mailto:PRECISION@HGNSS.COM)  
[WWW.HGNSS.COM](http://WWW.HGNSS.COM)