

# Hemisphere<sup>®</sup>



**875-0392-10**

Solutions Manual

Revision: A1  
Date: July 28, 2018

**IronOne/VR500  
Grademetrix™**

Machine Control Systems

## Table of Contents

Device Compliance, License and Patents.....	4
Terms & Definitions .....	6
Chapter 1: Overview .....	9
Overview .....	9
Harness Schematic.....	10
Chapter 2: Set Up Iron One.....	11
Overview .....	11
Installing IronOne.....	12
IronOne SIM Card.....	16
IronOne Operating System .....	17
Chapter 3: Set up VR500 Smart Antenna.....	28
Overview .....	28
Configure the VR500 Smart Antenna.....	29
Firmware Upgrades.....	30
Mounting the VR500.....	35
UHF Radio Antenna.....	48
Ports .....	49
Selecting Baud Rates and Message Types .....	50
Connecting the VR500 to External Devices .....	50
Powering the Receiver On/Off.....	55
LED Indicators .....	56
Software Installation.....	57
Chapter 4: Set up GradeMetrix with IronOne .....	60
Overview .....	60
Create a Job.....	61
Modify a Job.....	77
Calibrate Sensors .....	105
Quick Calibrate.....	107
Appendix A: Troubleshooting .....	108

---

Overview .....	108
Appendix A Troubleshooting .....	109
Appendix B: Technical Specifications.....	113
Overview .....	113
IronOne Technical Specifications.....	114
VR500 Technical Specifications.....	117
TS2 Sensor Technical Specifications .....	122
Index.....	124
End User License Agreement .....	125
Warranty Notice.....	129

---

## Device Compliance, License and Patents

### Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

E-Mark Statement: This product is not to be used for driverless/autonomous driving.

### Copyright Notice

Copyright Hemisphere GNSS, Inc. (2018). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

### Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax4™, S320™, SBX-4™, Vector™, XF1™, and XF2™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

### Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

*Continued on next page*

---

## Device Compliance, License and Patents, Continued

---

**Notice to Customers**      Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[PRECISION@HGSS.COM](mailto:PRECISION@HGSS.COM)  
[WWW.HGSS.COM](http://WWW.HGSS.COM)

---

**Technical Support**      If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[SUPPORT.HGSS.COM](http://SUPPORT.HGSS.COM)

---

**Documentation  
Feedback**

Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website: [SUPPORT.HGSS.COM](http://SUPPORT.HGSS.COM)

---

## Terms & Definitions

**Introduction** The following table lists the terms and definitions used in this document.

### VR500 Terms & definitions

Term	Definition
1PPS	1 pulse-per-second is a pulse output by the receiver precisely once per second and is used for hardware synchronization.
Activation	Activation refers to a feature added through a one-time purchase. For features that require recurring fees, see <a href="#">Subscription</a> .
Atlas	Atlas is a subscription-based service provided by Hemisphere that enables the VR500 to achieve sub-decimeter accuracy without a base station or datalink.
Base Station	The Base Station is a receiver placed over a familiar point, provides real-time observations, and sends those observations to nearby RTK rovers via UHF radio or the internet.
BeiDou	BeiDou is a Chinese satellite-based navigation system.
DGPS/DGNSS	Differential GPS/GNSS refers to a receiver using Differential Corrections.
Differential Corrections	A method of improving precision of a GNSS rover. Two GNSS receivers placed in a nearby area will have similar error. A base station is placed over a known point. As the actual position of the base station is known, error can be calculated, and corrections can be applied to nearby rovers. This differs from RTK.

*Continued on next page*

## Terms & Definitions, Continued

### VR500 Terms & definitions, continued

Term	Definition
Elevation Mask	Elevation Mask is the minimum angle between a satellite and the horizon for the receiver to use that satellite in the solution.
Firmware	Firmware is the software loaded into the receiver that controls the functionality of the receiver and runs the GNSS engine.
GALILEO	Galileo is a global navigation satellite system implemented by the European Union and European Space Agency.
GLONASS	Global Orbiting Navigation Satellite System (GLONASS) is a Global Navigation Satellite System deployed and maintained by Russia.
GNSS	Global Navigation Satellite System (GNSS) is a system that provides autonomous 3D position (latitude, longitude, and altitude) and accurate timing globally by using satellites. Current GNSS providers are: GPS, GLONASS and Galileo.
GPS	Global Positioning System (GPS) is a global navigation satellite system implemented by the United States.
Heading	Heading is the angle between true north and the vector calculated from the primary to secondary antenna.
Heading Bias	Heading Bias is an offset applied to the heading value calculated by the receiver.
Multipath	Multipath occurs when the GNSS signal reaches the antenna by two or more paths. This causes incorrect pseudo-range measurements and leads to less precise GNSS solutions.
NMEA	National Marine Electronics Association (NMEA) is a marine electronics organization that sets standards for communication between marine electronics.

*Continued on next page*

## Terms & Definitions, Continued

### VR500 Terms & definitions, continued

Term	Definition
ROX	ROX is a Hemisphere GNSS propriety RTK message format that can be used as an alternative to RTCM3 when both the base and rover are Hemisphere branded.
RTCM	Radio Technical Commission for Maritime Services (RTCM) is a standard used to define RTK message formats so that receivers from any manufacturer can be used together.
RTK	Real-Time-Kinematic (RTK) is a real-time differential GPS method that provides better accuracy than differential corrections.
SBAS	Satellite Based Augmentation System (SBAS) is a system that provides differential corrections over satellite throughout a wide area or region.
Subscription	A subscription is a feature that is enabled for a limited time. Once the end-date of the subscription has been reached, the feature will turn off until the subscription is renewed.
WAAS	Wide Area Augmentation System (WAAS) is a satellite-based augmentation system (SBAS) that provides free differential corrections over satellite in parts of North America.

---

## Chapter 1: Overview

### Overview

---

#### Introduction

Chapter 1 describes the IronOne/GradeMetrix systems integration process. Refer to the harness schematic for a visual representation of the integration process from start-to-finish.

---


#### Contents

Topic	See Page
<a href="#">Harness Schematic</a>	10

---

## Harness Schematic

### VR500 harness schematic



---

## Chapter 2: Set Up Iron One

### Overview

---

#### Introduction

Chapter 2 provides information to help you quickly set up and integrate your Vector VR500 GNSS Smart Antenna™ with the IronOne hardware.

You can download this manual from the Hemisphere GNSS website at [WWW.HGNSS.COM](http://WWW.HGNSS.COM).

---

#### Contents

Topic	See Page
Installing IronOne	12
IronOne SIM Card	16
IronOne Operating System	17

---

*Continued on next page*

## Installing IronOne

### Overview

To install the IronOne refer to the following pin-out and port information:

- Display
- Video
- Communication
- Power
- Video

### IronOne pin-out

The IronOne features 12 pin-outs. Refer to Figure 2-1 for the placement of the IronOne pin-outs.



Figure 2-1: IronOne pin-outs

*Continued on next page*

## Installing IronOne, Continued

**IronOne display pin-out** Table 2-1 lists the IronOne display pin-outs and directions.

**Table 2-1. IronOne display pin-out**

<b>Comm 12 pin</b>	<b>Description</b>	
1	CAN H	COM1 in Win10 device manager
2	RS232 TX 1	COM2 in Win10 device manager
3	RS232 RX 1	
4	GPIO	
5	GND	Signal ground
6	RS422 TX 1	COM4 in Win10 device manager RS232/RS422/RS485 can Switch on BIOS setup: BIOS setup->Advanced->F81216SEC Super Io Configuration->Serial Port 4 Configuration
7	RS422 TX 2	
8	RS422 RX 1	
9	RS422 RX 2	
10	GND	Power ground
11	V12+ OUT	Power out for serial device
12	CAN L	COM1 in Win10 device manager

*Continued on next page*

## Installing IronOne, Continued

### IronOne video pin-out

Table 2-2 lists the IronOne video pin-outs.

**Table 2-2: IronOne video pin-out**

Video 12 pin	Description
1	V12+ OUT1
2	GND
3	CAN2 L_IN
4	CAN2 H_IN
5	NET 1TX+_IN
6	NET1 TX-_IN
7	NET 1RX-I_N
8	NET1 RX+_IN
9	GPIO2_IN
10	GND
11	VIDEO2_IN
12	VIDEO1_IN

### IronOne communication

Table 2-3 lists the IronOne communication ports.

**Table 2-3: IronOne communication ports**

Comm DT15-12PA
CAN x 1
UART (RS232 x 1)
RS422/RS485/RS232 x 1 (Software switch)
GPIO x 1 (Default input pullup 5V)
12V/0.75A Power output

*Continued on next page*

## Installing IronOne, Continued

---

### IronOne power connector

Table 2-4 lists the IronOne power connectors.

**Table 2-4: IronOne power connectors**

Power	Description
1	PWR+
2	PWR-
3	ACC
4	NC
5	PWR-
6	PWR+

---

### IronOne video communication

Table 2-5 lists the IronOne video ports.

**Table 2-5: IronOne video ports**

Video DT15-12PB
CAN x 1
CVBS video input x 2
10M/100M LAN x 1
GPIO x 1 (Default input pullup 5V)
12V/0.75A Power output

---

## IronOne SIM Card

---

### IronOne SIM Card

To remove the weather-tight door on the IronOne, you will need a T10 torx screw driver. This is required for all four screws.

After opening the door, press the SIM card tension tab upwards until it clicks. This allows you to insert the standard GSM SIM Card into the slot. Insert the card and secure the tension tab to its original location.

Return the weather-tight door to the original position. Use the T10 torx screw driver to secure the door to the IronOne enclosure.

**Note:** Ensure the screws are hand-tight.

For cellular configuration, see [Setting Up a Cellular Connection](#).

---

### Powering the IronOne display

#### Power On

Press the power button (for less than 10 seconds) until the device powers on.

#### Power Off


To power off the display, exit the software and navigate to the Windows Start Menu and select Shut down.

---

## IronOne Operating System

### Using the on-screen keyboard


Use the following steps to use the IronOne on-screen keyboard.

Step	Action
1	Starting at the Desktop.  A screenshot of the Windows 10 desktop environment. The background is the standard Windows 10 blue light wallpaper. A 'Recycle Bin' icon is visible in the top-left corner. The taskbar at the bottom shows the Start button, search icon, and several application icons. The system tray on the right shows the 'Desktop' view icon, network, volume, and battery icons, along with the time '1:19 PM' and date '1/9/2018'.
2	Open the <b>Action Center</b> .  A close-up screenshot of the Windows 10 taskbar system tray. The time '9:41 AM' and date '1/30/2018' are displayed. The Action Center icon, which is a speech bubble, is highlighted with a red rectangular box.

*Continued on next page*

# IronOne Operating System, Continued


Using the on-screen keyboard, continued

Step	Action
3	<p data-bbox="568 478 1435 556">Open <b>All Settings</b>.</p>  A screenshot of the Windows Action Center interface. The background is the Windows 10 desktop with a blue light wallpaper. The Action Center is open on the right side of the screen, displaying 'No new notifications'. Below the notification area is a grid of quick settings tiles. The 'All settings' tile is highlighted with a blue border. Other visible tiles include 'Tablet mode', 'Network', 'Note', 'Airplane mode', 'Location', 'Quiet hours', 'Mobile hotspot', 'VPN', 'Cellular', '100%', 'Project', and 'Connect'. The system tray at the bottom shows the time as 9:41 AM on 1/20/2018.

*Continued on next page*

## IronOne Operating System, Continued


Using the on-screen keyboard, continued

Step	Action
4	<p>Click <b>Ease of Access</b>.</p>  <p>The screenshot shows the Windows Settings application. The top section displays various settings categories: System, Devices, Network &amp; Internet, Personalization, Accounts, Time &amp; language, Ease of Access, Privacy, and Update &amp; security. The 'Ease of Access' category is highlighted with a red box in the screenshot. Below this, a second screenshot shows the 'Ease of Access' settings page, where the 'Narrator' option is selected in the left sidebar and highlighted with a red box.</p>
5	Select <b>Keyboard</b> from the side bar menu.

*Continued on next page*

## IronOne Operating System, Continued

### Using the on-screen keyboard, continued



Step	Action
6	<p>Enable the on-screen keyboard.</p> 

*Continued on next page*

## IronOne Operating System, Continued

### Setting up a cellular connection



Use the following steps to set up the cellular connection.

Step	Action
1	<p>Starting at the Desktop.</p> 
2	<p>Select <b>All Settings</b>.</p> 
3	<p>Click <b>Network and Internet</b>.</p>

*Continued on next page*

## IronOne Operating System, Continued


### Setting up a cellular connection, continued

Step	Action
4	<p>Select <b>Cellular</b> from the side bar menu.</p> 
5	<p>Under Cellular Status, click the <b>Advanced Options</b> button.</p> 

*Continued on next page*

## IronOne Operating System, Continued

### Setting up a cellular connection, continued


Step	Action
6	<p>The <b>Advanced Options</b> displays a window to configure your cellular network.</p>  <p>The screenshot shows two screenshots of the Windows Settings application. The top screenshot shows the 'Cellular' settings page with options for 'Cellular network', 'Network selection' (set to 'Automatic'), a 'Search for networks' button, 'Active network' (Cellular turned off), 'Mobile operator settings', and 'Internet APN' (Add an Internet APN). The bottom screenshot shows the 'Properties' section for the cellular network, listing details such as Manufacturer (HUAWEI Technology), Model (HUAWEI Mobile Broadband Module), Firmware (11.430.63.00.00), Network type (GSM), Data class (UMTS, HSDPA, HSUPA, LTE, HSPA+), IMEI (864669020144132), and Mobile number. A 'Copy' button is visible at the bottom of the properties section.</p>
7	Enter Network Credentials and APN if required.

*Continued on next page*

## IronOne Operating System, Continued

### Bluetooth connecting



Use the following steps to connect the IronOne Bluetooth.

Step	Action
1	<p>Starting on the Desktop.</p> 
2	<p>Click <b>All Settings</b>.</p> 
3	<p>Click <b>Devices</b>.</p>

*Continued on next page*

## IronOne Operating System, Continued


### Bluetooth connecting, continued

Step	Action
4	Under <b>Devices</b> , click <b>Bluetooth</b> in the side bar menu.
5	<p>Open <b>Bluetooth Settings</b>.</p> 
6	<p>When your Bluetooth device is recognized, initiate the pairing process by clicking on the correct device and push the <b>Pair</b> button.</p> 

*Continued on next page*

## IronOne Operating System, Continued



**Connect to WIFI** Use the following steps to connect the IronOne to a wireless network.

Step	Action
1	<p>Starting at the Desktop.</p> 
2	<p>Select All settings.</p> 
3	<p>Click <b>Network and Internet</b> from the <b>Settings</b> screen.</p>

*Continued on next page*

## IronOne Operating System, Continued

### Connect to WIFI, continued

Step	Action
4	<p>From the <b>Network and Internet</b> screen, click the <b>Wi-Fi</b> link in the side bar menu. This leads you to the Wi-Fi Status screen.</p>  <p>The screenshot shows the Windows Settings application with the 'Wi-Fi' page selected in the left-hand navigation pane. The 'Wi-Fi' toggle is turned 'On'. Below the toggle, there are links for 'Show available networks', 'Hardware properties', and 'Manage known networks'. The 'Wi-Fi Sense' section is also visible, with a note about signing in with a Microsoft account and a 'Learn more' link. At the bottom, there is a section for 'Hotspot 2.0 networks'.</p>
5	<p>To see available networks in your immediate area, click <b>Show available networks</b> on the status page.</p>  <p>This screenshot is similar to the previous one but includes a pop-up window titled 'Network settings' on the right side. This window displays a list of available Wi-Fi networks, including 'Cellular' (Turned off), 'atlaslink_18801111' (Secured), 'CenturyLink1012' (Secured), 'DIRECT-4b-HP M477 LaserJet' (Secured), 'hemiguest' (Secured), 'hemiwifi' (Secured), and 'MikroTik-FSD45D'. The 'Network settings' window also shows icons for 'Wi-Fi', 'Airplane mode', 'Cellular', and 'Mobile hotspot' at the bottom.</p>
6	<p>Select the desired network and sign into the network using the known credentials.</p>

---

## Chapter 3: Set up VR500 Smart Antenna

### Overview

---

**Introduction** Chapter 3 contains the information needed to configure the VR500 Smart Antenna.

---

### Contents

Topic	See Page
Configure the VR500 Smart Antenna	29
Firmware Upgrades	30
Mounting the VR500	35
UHF Radio Antenna	48
Ports	49
Selecting Baud Rates and Message Types	50
Connecting the VR500 to External Devices	50
Powering the Receiver On/Off	55
LED Indicators	56
Software Installation	57

---

## Configure the VR500 Smart Antenna

### VR500 kit

Table 3-1 lists the parts included with your VR500. The VR500 GNSS Smart Antenna and the power/data cable (accessory item) are the only two required components.

**Note:** The VR500's parts comply with IEC 60945 Section 4.4: "Exposed to the weather."

### VR500 Parts list **Table 3-1 VR500 Parts list**

Part No.	Description	Qty
940-3121-10	HGNSS VR500 Receiver	1
752-0028-10	VR500 Receiver	1

All the following items are available for purchase separately from your VR500 receiver:

Part No.	Description	Qty
054-0181-10	Power/data cable, 15m (includes clamp, screw, washer)	1
710-0147-10	VR500 External UHF, B/T Kit	1

## Firmware Upgrades

---

### Overview

Periodically, Hemisphere GNSS releases firmware upgrades to improve performance, fix bugs, or add new features to a product. To update the firmware on the VR500, choose from one of two options:

1. Download the latest version of Hemisphere GNSS RightArm from the following link:

<HTTPS://HEMISPHEREGNSS.COM/RESOURCES-SUPPORT/SOFTWARE>


2. Use the internal WebUI.
- 

### RightArm Updates

Connect the VR500 to a computer over serial. Firmware can be loaded over either serial port. Set the baud rate of the serial port you are using to 19200.

Launch RightArm.

Click the **Connect** button or navigate to Receiver -> Connect.




*Continued on next page*

## Firmware Upgrades, Continued

**RightArm  
Updates,  
continued**

Choose the COM port connected to the VR500 and click **OK**.



**Note:** The baud rate of the serial port should be set to 19200 bps. Select **Allow Auto Baud** to change the baud rate during the firmware upgrade for a faster update.


*Continued on next page*

## Firmware Upgrades, Continued

---

### RightArm Updates, continued

Click the **Programming** button.



Select a **Program Type**.

The VR500 has two firmware applications, allowing two different versions of GNSS firmware. Hemisphere GNSS suggests loading the new firmware onto both applications.

After the firmware update is completed, check the current GNSS firmware.

If the current firmware is not the same as the newly loaded firmware, the VR500 could be using the other application. You can switch applications by sending the following command:

```
$JAPP,OTHER
```


Choose the Application, and press **Select File** to select the firmware file.

---

*Continued on next page*


## Firmware Upgrades, Continued

### RightArm Updates, continued



Choose the firmware, and click **Erase and Program**.

The **Activate Loader** checkbox in the Programming View window is selected. After pressing the Erase and Program button, this checkbox will de-select, and the **Status** field indicates the receiver is in loader mode (ready to receive the new firmware file).




*Continued on next page*

## Firmware Upgrades, Continued

**RightArm Updates,**  
continued

**Note:** If the Activate Loader check box remains selected, power the receiver off and on. When the receiver powers back on, the Activate Loader box should be de-selected.

**WARNING:** Do not to interrupt the power supply to the receiver, and do not interrupt the communication link between the PC and the receiver until programming is complete. Failure to do so may cause the receiver to become inoperable and will require factory repair.



**Note:** After completing the firmware update, Hemisphere GNSS suggests repeating this process for the other application.

## Mounting the VR500

### Introduction

This section provides information on mounting the VR500 in the optimal location, orientation considerations, environmental considerations, and other mounting options.

### GNSS satellite reception

When considering where to mount the VR500, consider the following satellite reception recommendations:

- Ensure there is a clear view of the sky available to the VR500 so the GNSS and L-band satellites are not masked by obstructions that may reduce system performance
- Mount the VR500 in a position in respect to the primary GNSS antenna (located on the end opposite the recessed arrow on the underside of the enclosure)
- Locate any transmitting antennas away from the VR500 by at least a few meters to ensure tracking performance is not compromised
- Ensure cable length is adequate to route into the machine to reach a breakout box or terminal strip
- Do not locate the antenna where environmental conditions exceed those specified in Appendix B, Technical Specifications of this document.



**Figure 3-2: Recessed arrow**

*Continued on next page*

---

## Mounting the VR500, Continued

---

### Environmental considerations

Hemisphere Vector Smart Antennas are designed to withstand harsh environmental conditions; however, adhere to the following limits when storing and using the VR500:

- Operating temperature: -40°C to +70°C (-40°F to +158°F)
  - Storage temperature: -40°C to +85°C (-40°F to +185°F)
  - Humidity: IEC 16750-4:2010 Section 5.6 Humid heat, cyclic test
- 

### Mounting orientation

The VR500 outputs heading, pitch, and roll readings regardless of the orientation of the antennas. The relation of the antennas to the machine's axis determines if you need to enter a heading, pitch, or roll bias.

The primary antenna is used for positioning and the primary and secondary antennas, working in conjunction, output heading, pitch, and roll values.

---

### Parallel orientation

Parallel installation orients the VR500 parallel to, and along the centerline of, the axis of the machine. **This provides a true heading.** In this orientation:

- If you use a gyrocompass and there is a need to align the Vector smart antenna, you can enter a heading bias in the VR500 to calibrate the physical heading to the true heading of the machine.
  - You may need to adjust the pitch/roll output to calibrate the measurement if the Vector is not installed in a horizontal plane.
- 

### Perpendicular orientation

You can also install the antennae so they are oriented perpendicular to the centerline of the machine's axis. In this orientation:

- Enter a heading bias of +90° if the primary antenna is on the right side of the machine and -90° if the primary antenna is on the left side of the machine.
  - Configure the receiver to specify the GNSS smart antenna is measuring the roll axis using the VR500 WebUI.
  - Enter a roll bias to properly output the pitch and roll values.
  - You may need to adjust the pitch/roll output to calibrate the measurement if the Vector is not installed in a horizontal plane.
- 

*Continued on next page*

## Mounting the VR500, Continued

Mounting  
orientation  
example




Figure 3-3: Recommended orientation and resulting signs of HPR values

*Continued on next page*

## Mounting the VR500, Continued

Mounting orientation example, continued




Figure 3-4: Alternate orientation and resulting signs of HPR values

*Continued on next page*

## Mounting the VR500, Continued

---

### Mounting alignment

The top of the VR500 enclosure incorporates sight design features to help you align the enclosure on your machine.

To use the sights, center the small post on the opposite side of the enclosure from you, within the channel made in the medallion located in the center of the enclosure top as shown in Figure 3-5 and Figure 3-6.

The long site alignment accuracy (Figure 3-5) is approximately  $\pm 1^\circ$ . Short site alignment accuracy (Figure 3-6) is approximately  $\pm 2.5^\circ$ .



**Figure 3-5: Long site alignment**

---

*Continued on next page*

## Mounting the VR500, Continued

### Mounting alignment, continued



**Figure 3-6: Short sight alignment**

### Mounting options

The VR500 allows for two different mounting options: flush-mount and pole-mount.

1. **Flush-mount**-The bottom of the VR500 contains eight M8-1.25 holes for flush mounting the unit to a flat surface (see Figure 3-11). The eight holes comprise two sets of four holes. Flush mounting does not provide any additional dampening to the receiver. The VR500 can be mounted using an optional mounting bracket. See Table 1-6 for bracket part information.
2. **Pole-mount**-The VR500 can be mounted using a mounting pole.


**Note:** Hemisphere GNSS does not supply mounting surface hardware or a mounting pole. You must supply the appropriate mounting hardware required to complete VR500 installation.

*Continued on next page*

## Mounting the VR500, Continued

### VR500 dimensions

Figure 3-7 illustrates the physical dimensions of the VR500.



**Figure 3-7: VR500 physical dimensions**

*Continued on next page*

## Mounting the VR500, Continued

VR500  
dimensions,  
continued




Figure 3-8: VR500 dimensions

Figure 3-9 shows the VR500 with remote antennas dimensions.




Figure 3-9: VR500 remote antenna dimensions

*Continued on next page*

# Mounting the VR500, Continued

VR500  
dimensions,  
continued




Figure 3-10 VR500 with remote antennas dimensions

Continued on next page

## Mounting the VR500, Continued

### Power/Data cable considerations

Before mounting the VR500, consider the following regarding power/data cable routing:

Do	Do not
Ensure cable reaches appropriate power source	Run cables in areas of excessive heat
Keep cable away from corrosive chemicals	Run cables through a door or window jams
Connect to a data storage device, computer, or other device that accepts GNSS data	Crimp or excessively bend the cable
Keep cable away from rotating machinery	Place tension on the cable
Remove unwanted slack from the cable at the VR500 end	
Secure along the cable route using plastic wrapping	

**⚠ WARNING:** Improperly installed cable near machinery can be dangerous.

### Connecting the Serial Power/Data cable

1. Align the cable connector key-way with the VR500 connector key.
2. Rotate the cable ring clockwise until it locks. The locking action is firm; you will feel a positive “click” when it has locked.
3. Attach the power/data cable to the cable clamp.
4. Fasten the clamp to the bottom of the VR500 using the screw and washer.

*Continued on next page*

## Mounting the VR500, Continued

---

### Flush-mounting the VR500

The bottom of the VR500 contains eight holes (two sets of four holes) for flush-mounting the unit to a flat surface (Figure 3-11).




**Figure 3-11: Flush-mounting holes on bottom of VR500**

---

*Continued on next page*

**Mounting the VR500, Continued**

**Assembly drawing**



**Figure 3-12: Assembly drawing**

Assembly drawing, continued




Figure 3-13: Pole-mounting specifications

## UHF Radio Antenna

### VR500 UHF Radio Antenna

The VR500 has an internal UHF radio for receiving RTK corrections.

The VR500 also has an internal UHF radio antenna to receive RTK with no need for an external radio or antenna.

If the UHF range needs to be increased, an external antenna can be installed using a TNC connector.

If ...	Then ...
RTK corrections are to be sent to the internal UHF radio	an external UHF radio antenna may be installed for increased range, or the internal radio antenna can be used.  <b>Note:</b> The VR500 has an external TNC connector (opposite side as the power/data cable).
an external antenna is to be used	the UHF antenna should be mounted to the top of the machine and the coaxial cable should be run safely and securely to the VR500.



**Figure 3-14: UHF antenna connections**

## Ports

---

**Overview** The VR500 offers serial port, CAN, and Ethernet port functionality.

---

**Serial ports** The VR500 has two serial ports:

- Port A can be both full-duplex RS-232 and half-duplex RS-422 (transmit only)
- Port B is full-duplex RS-232 or RS-422

You can receive external differential corrections via either Port A (full-duplex RS-232) or Port B (full-duplex RS-232 or full-duplex RS-422). You can connect up to three devices at one time using two ports.

One device can receive data via Port A (RS-422 transmit only) while two devices can transmit and receive data via Ports A and B (one connected to Port A RS-232 and one connected to Port B).

You can update firmware via Port A (RS-232) or Port B.

**Note:** The VR500 has maximum baud rate of 115200.

---

**Serial port configuration** You may configure Port A or Port B of the GNSS receiver to output any combination of data.

Port A can have a different configuration from Port B in data message output, data rates, and the baud rate of the port, and configure the ports independently based upon your needs. Both RS-232 and RS-422 output signals may be used simultaneously.

The RS-232 Port A and RS-422 Port A output the same data messages at the same baud rate. If the baud rate or messages for the RS-422 port need to be changed, this needs to be commanded through the RS-232 port.

**Note:** For successful communications, use the 8-N-1 protocol and set the baud rate of the VR500's serial ports to match that of the devices to which they are connected. Flow control is not supported.

---

---

## Selecting Baud Rates and Message Types

---

### Baud Rates & Message Types

When selecting your baud rate and message types, use the following formula to calculate the bits/sec for each message and sum the results to determine the baud rate for your required data throughput.

Message output rate \* Message length (bytes) \* bits in byte = Bits/second  
(1 character = 1 byte, 8 bits = 1 byte, use 10 bits/byte to account for overhead).

For information on message output rates refer to the [Hemisphere GNSS Technical Reference Manual](#).

---

## Connecting the VR500 to External Devices

---

### Recommendations for connecting to other devices

When interfacing to other devices, ensure the transmit data output and the signal grounds from the VR500 is connected to the data input of the other device.

The RS-422 is a balanced signal with positive and negative signals referenced to ground; ensure you maintain the correct polarity.

When connecting the transmit data output positive signal to the receive line of the other device, it should be connected to the receive positive terminal.

The negative transmit data signal from the VR500 is then connected to the receive data negative input of the other device.

For a list of Hemisphere GNSS commands, please refer to the [Hemisphere GNSS Technical Reference Manual](#). To configure the unit through the WebUI, please refer to [Configuring the VR500 using WebUI](#).


---

*Continued on next page*

## Connecting the VR500 to External Devices, Continued

### Power/Data cable considerations

The VR500 uses a single 15m (49 ft) cable for power and data input/ output.



**Figure 3-15: Power/Data cable, 15m**

**Note:** Cover drain wire with black shrink tube.

The receiver end of the cable is terminated with an environmentally-sealed 22-pin connection while the opposite end is unterminated and requires field stripping and tinning.

### Power/Data cable considerations, continued

Depending on the application and installation needs, you may need to shorten this cable. However, if you require a longer cable run than 15m, you can bring the cable into a break-out box that incorporates terminal strips, within the machine.

When lengthening the cable keep the following in mind:

- To lengthen the serial lines inside the machine, use 20-gauge twisted pairs and minimize the additional wire length.
- When lengthening the power input leads to the VR500, ensure the additional voltage drop is small enough that your power system can continue to power the system above the minimum voltage of the system. Wire of 18-gauge or larger should also be used.
- Minimize RS-232 cable length to ensure reliable communication.

*Continued on next page*

## Connecting the VR500 to External Devices, Continued


---

**VR500 with 22 to 18 pins adapter**

Use the 22 to 18 pin adapter if you want to use a V320 cable.

**Note:** Using the adapter will cause you to lose ethernet capability.

Figure 3-16 shows the VR500 with 22 to 18 pins adapter.



---

*Continued on next page*

## Connecting the VR500 to External Devices, Continued

---

VR500 with 22  
to 18 pins  
adapter,  
continued




Figure 3-16: VR500 with 22 to 18 pins adapter

---

Power/data  
cable pin-out  
assignments

Figure 3-17 shows the power/data cable pin-out assignments.




Figure 3-17: VR500 pin-out assignments

---

*Continued on next page*

## Connecting the VR500 to External Devices, Continued

Power/data  
cable pin-out  
specifications

Table 3-7 shows the cable pin-out specifications.

**Table 3-7: VR500 pin-out specifications**

Pin	Signal	Color
1	Power+	Red
2	CAN1_H	Orange-black stripe
3	CAN1_L	Yellow-black stripe
4	R232_IPT2/RS422_A	Orange
5	RS232_OPT1/RS422_Z	Yellow
6	CAN2_H	Green
7	CAN2_L	Blue
8	RS422_B	Purple
9	RS422_Y	Grey
10	1PPS_OUTPUT	White
11	ECLIPSE-PA-RXD_RS232	Pink
12	ECLIPSE-PA-TXD_RS232	Turquoise
13	GND	Black-white stripe
14	TD+	Brown-white stripe
15	TD-	Red-white stripe
16	HEADING WARNING	Orange-white stripe
17	SPEED_OUTPUT	Green-white stripe
18	RD+	Blue-white stripe
19	RD-	Purple-white stripe
20	MARK_INPUT	Red-black stripe
21	POWER+	Brown
22	POWER-	Black

## Powering the Receiver On/Off

---

### Power the receiver on/off

To power on the VR500, connect the ends of the VR500 power cable to a clean power source providing 9 to 32VDC, and hold the soft power switch until the screen illuminates.

The VR500 accepts an input voltage of 9 to 32 VDC via the power cable. The supplied power should be continuous and clean for best performance. Refer to [Appendix B](#) Technical Specifications, for the power specifications of the VR500.

**⚠ WARNING:**

**Do not apply a voltage higher than 32 VDC. This will damage the receiver and void the warranty. Also, do not attempt to operate the VR500 with the fuse bypassed as this will void the warranty.**

The VR500 features reverse polarity protection to prevent damage if the power leads are accidentally reversed. Although the VR500 proceeds through an internal startup sequence when you apply power, it will be ready to communicate immediately.

Initial startup may take 5 to 15 minutes depending on the location. Subsequent startups will output a valid position within 1 to 5 minutes depending on the location and time since the last startup.

The VR500 may take up to 5 minutes to receive a full ionospheric map from SBAS. Optimum accuracy is obtained once the VR500 is processing corrected positions using complete ionospheric information.

**Note:** Hemisphere GNSS recommends using a weather-tight connection and connector if the connection is located outside.

### Electrical isolation

The VR500's power supply is isolated from the communication lines and the enclosure isolates the electronics mechanically from the machine (preventing machine hull electrolysis).

---

## LED Indicators

### Overview

The VR500 has four LED lights located bottom of the unit. Table 1-8 below describes each LED indicator.



Figure 3-18: VR500 LED

Table 3-8: LED indicators

Indicator	Description/Function
Power	Solid red light when receiver is powered on
GNSS	Solid amber light when the primary antenna is tracking four or more satellites
Heading	Indicates the Vector has calculated a heading value
UHF	Blinks each time an RTK message is received over UHF

---

## Software Installation

### Operating system requirements

GradeMetrix can be installed to a ruggedized field computer or an office PC. The latest software version can be found on the [Hemisphere GNSS website](#).

GradeMetrix was designed to run on Windows 7, Windows 8, and Windows 10.

---

### Files and formats used in GradeMetrix

Various files are loaded into SiteMetrix on specific, recommended directories on the Control Panel. Files are loaded into these directories using a couple of different methods: manually selecting files in SiteMetrix from memory sticks (USB drives, thumb drives, etc.) or using Windows Explorer to copy files.

GradeMetrix can support:


- Site Plan File: DWG, DXF
  - Surface Model File: MESH, GRID, TIN, GRD, DWG, DXF, NTD, DTM, FLT, XYZ
  - Site Reference File: WKT, DC
  - Survey Topo File: TOPO
  - Backdrop File: PNG, JPG, BMP
  - Tin File: MESH, TIN, NTR, DXF, DWG, FLT
  - Grid File: GRID, GRD, DTM, XYZ
  - Localization File: LOCAL, LOC
- 

*Continued on next page*

## Software Installation, Continued

### Install GradeMetrix software



To install your GradeMetrix software, complete the following steps:

Step	Action
1	<p>Click on the install file. The Select Destination Location screen displays. Verify the location is correct or click Browse to select another file location.</p> 
2	Click <b>Next</b> .

*Continued on next page*

## Software Installation, Continued

Files and formats used in GradeMatrix, continued

Step	Action
3	<p>The Select Additional Tasks screen displays. The option to Create a desktop shortcut is selected and click <b>Next</b>.</p> 
4	<p>The GradeMatrix software begins installing on your computer.</p> 

---

## Chapter 4: Set up GradeMetrix with IronOne

### Overview

---

**Introduction** Chapter 4 contains the steps needed to integrate GradeMetrix software with the IronOne hardware.

---

### Contents

Topic	See Page
Create a Job	61
Modify a Job	77
Calibrate Sensors	105
Quick Calibrate	107


---

## Create a Job

### Create a job

To create a job, on the GradeMetrix Home screen, click **New Job**. The **Job Basics** screen displays.

**Note:** You must be logged in as an administrator to create a new job in GradeMetrix. The New Job icon is disabled for users not logged in as administrator.




*Continued on next page*

## Create a Job, Continued


### Job basics screen

Click in a field and type the job name, description and job notes.

Click **Next**.



The screenshot shows the 'Job Basics' form with three input fields: 'Name' containing 'New Job', 'Description' (empty), and 'Notes' (empty). At the bottom right, there are three buttons: 'Back' (disabled), 'Next' (active), and 'Cancel' (disabled).



The screenshot shows the 'Job Basics' form with three input fields: 'Name' containing 'New Job Example', 'Description' containing 'This is my new job.', and 'Notes' containing 'These are my notes.'. At the bottom right, there are three buttons: 'Back' (disabled), 'Next' (disabled), and 'Cancel' (disabled).

*Continued on next page*

## Create a Job, Continued


---

**Job files screen** Click the document icon to add job documentation to your GradeMetrix job:

- Localization\*
- Linework\*
- Guideline
- Survey Topo
- Backdrop

(\*Required field)

Click **Next**.



The screenshot shows a window titled "Job Files" with five input fields, each with a document icon to its right:

- Localization: [text input]
- Linework: [text input]
- Guideline: [text input]
- Survey Topo: [text input]
- Backdrop: [text input]

At the bottom right of the window are three buttons: "Back" (with a left arrow), "Next" (with a right arrow), and "Cancel" (with a red X).


---

*Continued on next page*

## Create a Job, Continued


, continued

The **Job Files** screen displays.



The screenshot shows the 'Job Files' screen with the following fields: Localization, Linework, Guideline, Survey Topo, and Backdrop. Each field has a file selection icon on the right. A red box highlights these icons. At the bottom, there are 'Back', 'Next', and 'Cancel' buttons.

To add Job Localization, click the icon on the right of the **Localization** field.




The screenshot shows the 'Job Files' screen with the 'Localization' field containing the text 'Example Calibration.local'. The file selection icon for the Localization field is highlighted with a red box. The other fields (Linework, Guideline, Survey Topo, Backdrop) and the 'Back', 'Next', and 'Cancel' buttons are also visible.

*Continued on next page*

## Create a Job, Continued

**Job files screen, continued** A list of the available files displays. Click on the filename you wish to add and click **Open**.




*Continued on next page*

## Create a Job, Continued

, continued

The selected filename displays in the **Linework** field.



**Job Files**

Localization: Example Calibration.local 

Linework: Example Linework.dxf 

Guideline: 


Survey Topo: 



Backdrop: 

To add the **Linework** file, click the document icon on the right.



**Job Files**

Localization: 

Linework: 

Guideline: 

Survey Topo: 



Backdrop: 


  

*Continued on next page*

## Create a Job, Continued

**Job files screen,**  
continued

A list of available files is displayed. Click the file you wish to add and click **Open**.



To add the **Guideline** file, click the document icon on the right.




*Continued on next page*


## Create a Job, Continued

, continued

A list of available files is displayed. Click to select the file you wish to add and click **Open**.



To add the **Survey Topo** file, click the document icon on the right.




*Continued on next page*

## Create a Job, Continued

---

**Job files screen continued** A list of available files is displayed. Click to select the file you wish to add and click **Open**.

The **Survey Topo** filename displays in the field.



The screenshot shows a 'Job Files' dialog box with the following fields and controls:

- Localization:** Example Calibration.local (with a file icon)
- Linework:** Example Linework.dxf (with a file icon)
- Guideline:** (empty field with a file icon)
- Survey Topo:** Example Topo.topo (with a file icon)
- (empty field with a dropdown arrow)
- Backdrop:** (empty field with a file icon)

At the bottom right, there are three buttons: **Back** (left arrow), **Next** (right arrow), and **Cancel** (red X).


To set the **Survey Topo** elevation, click the down arrow, and click to select the elevation.

---

*Continued on next page*

## Create a Job, Continued

### Job files screen continued



The screenshot shows the 'Job Files' screen with the following fields and values:


- Localization: Example Calibration.local
- Linework: Example Linework.dxf
- Guideline: (empty)
- Survey Topo: Example Topo.topo
- Backdrop: (empty)

A dialog box is open over the Linework field, containing four radio button options:

- #, North, East, Elevation
- North, East, Elevation
- #, East, North, Elevation
- East, North, Elevation

At the bottom of the dialog box is a 'Cancel' button with a red 'X' icon. At the bottom of the main screen are three buttons: 'Back' (green left arrow), 'Next' (green right arrow), and 'Cancel' (red 'X').

To set the Backdrop (additional linework), click the document icon to the right.



The screenshot shows the 'Job Files' screen with all fields empty:

- Localization: (empty)
- Linework: (empty)
- Guideline: (empty)
- Survey Topo: (empty)
- Backdrop: (empty)

At the bottom of the screen are three buttons: 'Back' (green left arrow), 'Next' (green right arrow), and 'Cancel' (red 'X').

*Continued on next page*

## Create a Job, Continued

---


**Job files screen continued** A list of available files is displayed. Click to select the file you wish to add and click **Open**.

The **Backdrop** filename displays in the field.

Click **Next**.

---

**Surface options window** The **Surface Options** window displays. Click Add and type the name of the surface you would like to add.



**Note:** You can add multiple types of surfaces.

To upload a file, click the document icon to the right of the File Path: field and select the desired file.

---

*Continued on next page*

## Create a Job, Continued

---

Surface options  
window,  
continued

Click the down-arrow to select the **Work Type**.

1. **Design**—the most commonly selected option. The Design surface is the surface you are grading to. – this is the most common.
2. **Actual**—select **Actual** if you have a jobsite topo to upload to the current actual surface.

**Note:** The following surfaces are in development for GradeMetrix Phase 2 development.

3. **Warning** – select to trigger a warning in the software if your elevation is either above or below (see ‘Alert Method’ this surface) the uploaded surface.
4. **Watch** – similar to a Warning surface. This allows for two levels of alert (i.e. you can choose to upload a ‘Watch’ surface to set low priority alerts to an operator and set another ‘Warning’ surface for higher priority alerts to an operator.
5. **Pass Count**—color the screen based on how many times a machine has passed over a grid cell.


---

*Continued on next page*

## Create a Job, Continued

Surface options window, continued

The **Surface Option** name you entered displays in the **Surfaces:** list.



For each **Surface Option** you enter, you must select (set) the following:

- File Path
- Work Type
- Fill Style
- Fill Color
- Line Style
- Line Color
- Alert Method (**Note: Alert Method** is only applicable if **Work Type** is set to **Warning** or **Watch**. Select from **Alert When Below** or **Alert When Above**.)

Click to select: **Show in Views**, and click **Next**.

**Note:** **Show in Views** must be selected to display your design in the design surface.

*Continued on next page*

## Create a Job, Continued

### Job Mapping window


The **Job Mapping** window displays.

Click the down-arrow to select units for the following fields:

- Units of Measure
- Transform Method
- Alignment Method
- Job Scale

To set a geographical reference grid, click **Geo-reference/State Grid**. Click to select from the displayed list.

Click **Next**.



**Job Mapping**

Units of Measure: US-Survey Feet

Transform Method: Plane Similarity

Alignment Method: Align to Grid

Job Scale: 1.0000000000000000


Geo-reference/State Grid: UTM/UPS Standard

Back Next Cancel

*Continued on next page*

# Create a Job, Continued

**Job Localization screen** The Job Localization screen displays.




*Continued on next page*

## Create a Job, Continued

**Job Localization**  
screen,  
continued

Click the **Add** button to add the job localization settings:

- Latitude
- Longitude
- Height
- Northing
- Easting
- Elevation



Use the keyboard icon to the right of each field to add values to that field.

Click **Ok**.


Click **Finish**.

## Modify a Job

### Modify a job

To modify an existing job in GradeMetrix, click the **Modify Job** icon on the GradeMetrix Home screen.

**Note:** To modify a Job, you must be logged in as “Administrator”.




*Continued on next page*

## Modify a Job, Continued

### Modify Job basics screen

The **Job Basics** screen displays the **Name**, **Description**, and **Notes** about the job. You can click to select and modify these job fields.



The left navigation menu provides links to the following job information:

- Basics
- Files
- Surfaces
- Mapping
- Localization

*Continued on next page*


## Modify a Job, Continued

### Modify Files screen

Click **Files** to modify job file information. The **Job Files** screen display the following job data:

- Localization\*
- Linework\*
- Guideline\*
- Survey Topo
- Backdrop

(\*Required fields)



The screenshot shows the 'Job Files' screen in a software application. On the left is a navigation pane with icons for 'Basics', 'Files', 'Surfaces', 'Mapping', and 'Localization'. The 'Files' icon is selected. The main area is titled 'Job Files' and contains five rows of input fields, each with a file icon on the right:

- Localization: Demo.local
- Linework: Linework.dxf
- Guideline: Sample.guide
- Survey Topo: (empty)
- Backdrop: (empty)


At the bottom right of the window are 'Ok' and 'Cancel' buttons. A lock icon is visible in the bottom left corner of the window frame.

*Continued on next page*

## Modify a Job, Continued

### Modify Files screen, continued

To modify the **Localization** file, click the document icon on the right of the **Localization** field.




The localization files display. To change the file, click the **Data** folder and click to select a different file name.

*Continued on next page*


## Modify a Job, Continued

Modify Files screen, continued

Click **Open**.



The **Job Files** window display the **Localization** file you selected.




*Continued on next page*


## Modify a Job, Continued

**Modify Files**  
screen,  
continued

To modify the **Linework** file, click the document icon on the right side of the **Linework** field.



The **Linework** file list displays.




*Continued on next page*

## Modify a Job, Continued

### Modify Files screen, continued

To select a different **Linework** file, click the **Data** folder, and click to highlight the Job file and double-click.




Click to highlight the name of the **Linework** file you wish to use and click **Open**.


*Continued on next page*

## Modify a Job, Continued

Modify Files screen, continued



The **Linework** file name displays in the **Linework** field.




*Continued on next page*

## Modify a Job, Continued


**Modify Files**  
screen,  
continued

To modify the **Guideline** file, click the document icon on the right of the **Guideline** field.



Click the **Data** file in the left navigation menu to display the list of available files and click to highlight the name of the file you wish to use.

Click **Open**.




*Continued on next page*

## Modify a Job, Continued

### Modify Files screen, continued

The **Job Files** screen displays the Guideline filename you selected.




The screenshot shows the 'Job Files' configuration window. On the left is a sidebar with icons for 'Basics', 'Files', 'Surfaces', 'Mapping', and 'Localization'. The 'Files' icon is selected. The main area contains several input fields, each with a document icon to its right for file selection:

- Localization: Demo.local
- Linework: Linework.dxf
- Guideline: Sample.guide
- Survey Topo: (empty)
- Backdrop: (empty)

At the bottom right, there are 'Ok' and 'Cancel' buttons.

To modify the **Survey Topo** file, click the document icon to the right.




This screenshot is identical to the previous one, but a mouse cursor is positioned over the document icon to the right of the 'Survey Topo' field, indicating the user is about to click it to open a file selection dialog.

*Continued on next page*


## Modify a Job, Continued

### Modify Files screen, continued

Click the **Data** file in the left navigation menu to display the list of available files and click to select the file you wish to use. Click **Open**.



The **Survey Topo** file you selected is displayed in the **Job Files** screen field.




*Continued on next page*

## Modify a Job, Continued

### Modify Files screen, continued

To change the **Survey Topo** elevation setting, click the down arrow on the right.



A pop-up window displays a list of elevations:


- ID, North, East, Elevation
- North, East, Elevation
- ID, East, North, Elevation
- East, North, Elevation

*Continued on next page*


## Modify a Job, Continued

### Modify Files screen, continued

Select from this list of options and click **Ok**.



The elevation you selected displays in the **Job Files** window.




*Continued on next page*


## Modify a Job, Continued

### Modify Files screen, continued

To change the **Backdrop** file, click the document icon on the right.



On the left navigation menu, click to select the **Data** file to display the list of available files. Click to highlight and select the file you wish to add and click **Open**.




*Continued on next page*

## Modify a Job, Continued


### Modify Files screen, continued

The **Backdrop** file you selected is displayed in the Job Files window. Click **Ok**.



### Modify Job mapping screen

From the left navigation menu, click the Mapping icon. The **Job Mapping** screen displays.




*Continued on next page*

## Modify a Job, Continued

**Modify Job mapping screen, continued**

To change the **Units of Measure** from the default of setting of **US-Survey Feet**, click the down arrow. Click to select the measurement unit you wish to use. You can choose from **US-Survey Feet**, **Meters**, or **International Feet**.



Click the down arrow to select **Transform Method** from the following options:


- Rigid Body Without Scale
- Plane Similarity

*Continued on next page*

## Modify a Job, Continued

### Modify Job mapping screen, continued

Click to change your selection.



To change the **Alignment Method**, click the down arrow. You can choose from:


- Align to Grid
- Geodetic

*Continued on next page*


## Modify a Job, Continued

Modify Job mapping screen, continued

Click **Ok**.



To type the **Job Scale** value, click the keyboard icon on the right and use the keypad to type the numbers. Click **Next**.




*Continued on next page*

## Modify a Job, Continued

**Modify Job mapping screen, continued**

If your project is using coordinates from a known coordinate system, click **Geo-reference/State Grid** and select the appropriate projection from the list.

Click **Ok**.




*Continued on next page*

## Modify a Job, Continued

### Add job surfaces

To modify GradeMetrix **Job Surface** data, click **Surfaces** on the left navigation menu.

The **Surface Options** window displays.




*Continued on next page*

## Modify a Job, Continued

### Add job surfaces, continued

To add a **Surface**, click **Add**.




Use the pop-up keyboard to type the name of the **Surface Option** you wish to add. Click the **Enter** key.

*Continued on next page*

## Modify a Job, Continued

### Add job surfaces, continued



The added **Surface Option** displays in the **Surfaces:** field.

You can modify the following Surface Options:


- File Path
- Work Type
- Fill Style
- Fill Color
- Line Style
- Line Color
- Alert Method

*Continued on next page*


## Modify a Job, Continued

### Add job surfaces, continued

To modify a Surface option File Path, in the **Surface Options** window, click the document icon to the right of the **File Path** field.



To modify a GradeMetrix Job Work Type, in the **Surface Options** window, click the down-arrow to the right of the **Work Type**: field.



*Continued on next page*


## Modify a Job, Continued

### Add job surfaces, continued

A pop-up window displays the following **Work Type** options:

- Design
- Actual
- Warning
- Watch
- Pass Count
- Density
- Counting
- Information
- Changes Only
- Difference

Click to select the desired **Work Type**. The selected **Work Type** displays in the **Work Type:** field.




*Continued on next page*

## Modify a Job, Continued

### Add job surfaces, continued continued

To modify the **Fill Style** of a **Surface Option**, in the **Surface Options** window, click the down-arrow to the right of the **Fill Style:** field.



A pop-up window displays the following **Fill Style** options:


- Transparent
- Solid Fill
- Backward Diagonal Hatch
- Cross Diagonal Hatch
- Forward Diagonal Hatch
- Cross Hatch
- Horizontal Hatch
- Vertical Hatch
- User Defined

*Continued on next page*

## Modify a Job, Continued


Add job surfaces, continued

Click to select the desired **Fill Style**.



The selected **Fill Style** displays in the **Fill Style** field. Click to select and set your preferences for the remaining options:

- Fill Color
- Line Style
- Line Color




*Continued on next page*


## Modify a Job, Continued

### Remove a surface option

To remove a **Surface Option**, click to highlight the **Surface Option** name and click **Remove**.



The **Surface Option** is no longer displayed in the **Surface Options** field. When you have finished modifying all the necessary **Surface Options**, click **Ok**.




*Continued on next page*

## Modify a Job, Continued

### Remove a surface option, continued


The currently opened GradeMetrix Job appears. A slight system delay will occur, as GradeMetrix applies the job modifications.



## Calibrate Sensors


### Calibrate sensors

On the GradeMetrix Home screen, click the **Calibrate Sensors** icon.



The **Calibration Stage 1** screen displays. Click **Calibrate**.


To calibrate a body sensor, line up the machine up and press Calibrate to average results over a few seconds.



*Continued on next page*


## Calibrate Sensors, Continued

### Calibrate sensors, continued



Click **Next**. The **Calibration Stage 2** screen displays. Click **Calibrate** and click **Finish**.

Then turn the machine 180 degrees and place the blade in the same location and press **Calibrate** again.




## Quick Calibrate

**Quick calibrate** The Quick Calibrate function allows users to manually enter a slope. On the GradeMetrix Home screen, click the **Quick Calibrate** icon.

Use **Quick Calibrate** if you have the long and cross slope of your machine or blade.

The previous section of this User Guide provides instructions for calculating the delta values for cross and long slope, so offsets can be applied.



---

# Appendix A: Troubleshooting

## Overview

---

**Introduction** Appendix A provides troubleshooting for common problems.

---

## Contents

Topic	See Page
Appendix A Troubleshooting	109

---

## Appendix A Troubleshooting

### Troubleshooting

Symptom	Possible Solution
Incorrect position	<p>First, check the control point with the machine and the survey rover.</p> <p>If the horizontal or vertical position is off, the first thing you should consider is if it is off by a consistent amount throughout the jobsite, or if the position bust varies throughout the job. if it is consistent, consider the following:</p> <ol style="list-style-type: none"> <li>1. Check your machine measurements/offsets. If any of these are incorrect, your projected position will be off</li> <li>2. Bad localization. Make sure that all of the points in your localization file have low residuals and/or that the correct coordinate system has been chosen (this can make huge differences)</li> </ol> <p>If there is an inconsistent position bust, check:</p> <ol style="list-style-type: none"> <li>3. Sensor mounting was incorrectly chosen and/or sensor was not calibrated               <ol style="list-style-type: none"> <li>a. The above is evident if your position is correct when flat, but not if you are on a slope</li> </ol> </li> <li>4. If the position at the GPS antenna is correct, but the position bust worsens as you approach the cutting edge, it may be a heading offset error.</li> </ol>

*Continued on next page*

## Appendix A Troubleshooting, Continued

### Troubleshooting , continued

Symptom	Possible Solution
No GPS position	<ol style="list-style-type: none"><li>5. First check to see if the VR500 or VR1000 is powered on.</li><li>6. If the receiver isn't powered, disconnect the cable and use a multimeter to verify it is receiving power from the IronOne. Check the Monitor screen and Sky Plots to see if there is any data from the receiver. If there is no data, but the receiver is powered, there could be a bad serial connection/mismatched baud rate.</li><li>7. If using a VR1000, use a multi-meter to measure the voltage from the primary antenna port. The voltage should be 5V. If it is reading 5V from the receiver, check the other end of the cable (that would plug into the antenna). If there isn't any voltage, it may be a damaged cable or bulk head connector.</li></ol>

*Continued on next page*

## Appendix A Troubleshooting, Continued

**Troubleshooting**  
, continued

Symptom	Possible Solution
No RTK	<ol style="list-style-type: none"> <li>1. If using a base station onsite (versus an NTRIP service), first check to verify the base station is turned on.</li> <li>2. If the base station is turned on and sending RTK out over UHF, check to see if the Tx (or TD on some radios) light is flashing once per second.</li> <li>3. If it is flashing once per second, check to verify the settings (frequency, bandwidth, forward error corrections, modulation, and protocol) at the base match that of the rover.</li> <li>8. Check to see if the UHF light at the rover is blinking once per second. If it isn't, refer to (3.).</li> <li>9. The receiver may be out of UHF range. Consider installing the external UHF antenna (if using a VR500). You may need to install repeaters. See if the RTK corrections work when the machine is closer to the base station.</li> <li>10. If using NTRIP, check cellular connectivity. One option is to exit GradeMetrix and verify you can go to a website via the browser.</li> </ol>

*Continued on next page*

## Appendix A Troubleshooting, Continued

Troubleshooting  
, continued

Symptom	Possible Solution
IronOne will not power on	<ol style="list-style-type: none"> <li>1. Check to verify the power cable is connected to machine power. The positive should go to a reliable, clean power source and ground it to the chassis of the machine.</li> <li>2. Disconnect the cable and refer to the pinout to see if 12V or 24V (depending on machine) is going into the IronOne by using a multi-meter. If the multimeter reads 12V or 24V, then power is confirmed, and the IronOne may need to be serviced. If you don't have any power, then check your power source, ground, and all fuses.</li> </ol>
No heading	<ol style="list-style-type: none"> <li>11. If using a VR1000, you need two external antennas. Use a multi-meter to check the voltage coming out of the N-type connectors is 5V. If 5V is coming from the receiver, check the other end of the cable (that would plug into the antenna). If there is no voltage, then it is a damaged cable or bulk head connector.</li> <li>12. If using a VR1000, check your MSEP. Your MSEP is the distance, in meters, between the two antennas, and should be accurate to within 2cm.</li> </ol>

---

## Appendix B: Technical Specifications

### Overview

---

**Introduction** Appendix B provides the technical specifications for the IronOne hardware, the VR500 Smart Antenna, and GradeMetrix software.

---

### Contents

Topic	See Page
<a href="#">IronOne Technical Specifications</a>	114
<a href="#">VR500 Technical Specifications</a>	117
<a href="#">TS2 Sensor Technical Specifications</a>	122

---

## IronOne Technical Specifications

### IronOne technical specifications

The following details technical specifications for the IronOne.

**Table B-1: IronOne system specifications**

System	
Processor	Intel Atom dual-core CPU E3825 @ 1.33 GHz
Storage	SSD 32GB, RAM 2GB, 128 GB with Micro SD
Operating System	Windows 10

**Table B-2: IronOne screen specifications**

Screen	
Display Type	8" TFT-LCD capacitive touchscreen
Size	192.8 mm × 116.9 mm (7.59" × 4.6")
Resolution	1280 × 720, 16:9
Luminance	750 nit

**Table B-3: IronOne input specifications**

Input	
Start button	1× mechanical waterproof button
Function button	2× mechanical waterproof buttons
Ignition Input	Yes

*Continued on next page*

## IronOne Technical Specifications, Continued

IronOne  
technical  
specifications,  
continued

**Table B-4: IronOne communication specifications**

<b>Communication</b>	
Serial Port	1x RS232×1, 1x RS422/RS485/RS232 (switch by software)
Camera Interface	2× CVBS
USB	1× USB2.0
Ethernet	10M/100M
Wi-Fi	IEEE 802.11b/g/n
Bluetooth	Bluetooth 4.0
Cellular	4G LTE (optional with SIM card port)
Data I/O Protocol	NMEA 0183

*Continued on next page*

## IronOne Technical Specifications, Continued

IronOne  
technical  
specifications,  
continued

**Table B-5: IronOne mechanical specifications**

<b>Mechanical</b>	
Dimensions	22.9 L x 16.9 W x 5.2 H (cm) 9.0 L x 6.6 W x 2.0 H (in)
Weight	1.38 kg (3.04 lbs)
Mount	Adjustable 1.5" RAM ball mount

**Table B-6: IronOne environmental specifications**

<b>Environmental</b>	
Operating Temperature	-20°C to +70°C (-4°F to 158°F)
Storage Temperature	-40°C to +85°C (-40°F to 185°F)
Operating Humidity	30% ~ 95% (Relative Humidity)
Storage Humidity	45% ~ 80% (Relative Humidity)
Enclosure	IP67
Vibration	EP455 5.15

**Table B-7: IronOne power specifications**

<b>Power</b>	
Input Voltage	7 - 36 VDC
Power Consumption	36 W
Current Consumption	3.0 A @ 12 VDC

**Table B-8: IronOne sensor and multimedia specifications**

<b>Sensor and Multimedia</b>	
1x 2W Buzzer	
1x Headphone Jack	

## VR500 Technical Specifications

### VR500 sensor specifications

**Table B-9: VR500 sensor specifications**

Item	Specification
Receiver type	GPS, GLONASS, BeiDou, Galileo and RTK with carrier phase and L-band dual antenna
Channels	788
Satellites	12 L1CA GPS 12 L1P GPS 12 L2P GPS 12 L2C GPS 15 L5 GPS 12 G1 GLONASS 12 G2 GLONASS 12 G3 GLONASS 22 B1 BeiDou 22 B2 BeiDou 14 B3 BeiDou 12 Galileo E1 12 Galileo E5a 12 Galileo E5b 3 SBAS or 3 additional L1CA GPS 2 L-band
Primary antenna	GPS L1,L1P,L2C,L2P,L5 GLONASS G1,G2,Pcode BeiDou B1,B2,B3 Galileo E1,E5a,E5b L-band

*Continued on next page*

## VR500 Technical Specifications, Continued

VR500 sensor specifications, continued

**Table B-9: VR500 sensor specifications (continued)**

Item	Specification		
Secondary antenna	GPS L1,L1P,L2C,L2P GLONASS G1,G2 BeiDou B1,B2 Galileo E1,E5b L-band		
GPS sensitivity	-142 dBm		
SBAS tracking	3-channel, parallel tracking		
Update rate	10 Hz standard, 20 Hz and 50 Hz available		
Horizontal accuracy		<b>RMS (67%)</b>	<b>2DMRS (95%)</b>
	RTK <sup>1,2</sup>	8 mm + 1 ppm	15 mm +2 ppm
	Atlas	0.04 m	0.08 m
	SBAS (WAAS) <sup>1</sup>	0.3 m	0.6 m
	Autonomous, no SA <sup>1</sup>	1.2 m	2.4 m
Heading accuracy	< 0.17° RMS @ 0.5 m antenna separation < 0.09° RMS @ 1.0 m antenna separation < 0.04° RMS @ 2.0 m antenna separation < 0.02° RMS @ 5.0 m antenna separation		
Pitch/roll accuracy	< 1° RMS		
Heave accuracy	30 cm <sup>4</sup>		
ROT	145°/s maximum		
Timing (1PPS) accuracy	20 ns		
Cold start time	< 60 s typical (no almanac or RTC)		
Warm start time	< 30 s typical (almanac and RTC)		
Hot start time	< 10 s (almanac, RTC, and position)		
Maximum speed	1,850 km/h (999 kts)		

*Continued on next page*

## VR500 Technical Specifications, Continued

### VR500 sensor specifications, continued

**Table B-9: VR500 sensor specifications (continued)**

Item	Specification
Maximum altitude	18,288 m (60,000 ft)
Differential options	SBAS, Autonomous, External RTCM v2.3, RTK v3, L-band (Atlas), and DGPS
Antenna LNA gain input	10 to 40 dB

### VR500 communication specifications

**Table B-10: VR500 communication specifications**

Item	Specification
Serial ports	3x full-duplex UART's 2x 3.3V CMOS 1x RS-232
CAN	2 CAN ports NMEA2000, ISO-11783
Baud rates	4800 - 115200
Data I/O protocol	NMEA 0183, CAN, Hemisphere GPS binary
Correction I/O protocol	Hemisphere GNSS' ROX, RTCM v2.3 (DGPS), RTCM v3 (RTK), CMR, CMR+3, and Atlas
Timing output	1 PPS CMOS, active high, rising edge sync, 10 k $\Omega$ , 10 pF load
Event marker input	CMOS, active low, falling edge sync, 10 k $\Omega$ 10 pF load
USB	1 USB Device, OTG with future firmware update
Ethernet	1x 10/100 base-T

### VR500 power specifications

**Table B-11: VR500 power specifications**

Item	Specification
Input voltage	9-32 VDC
Power consumption	10.5W Maximum (All signals and L-band)
Current consumption	1.2A Maximum
Antenna voltage input	5 VDC Maximum
Antenna short circuit	Yes
Antenna input	50 $\Omega$

*Continued on next page*

## VR500 Technical Specifications, Continued

### VR500 environmental specifications

**Table B-12: VR500 environmental specifications**

Item	Specification
Operating temperature	-40°C to +85°C (-40°F to +185°F)
Storage temperature	-40°C to +85°C (-40°F to +185°F)
Humidity	95% non-condensing (when installed in an enclosure)
Shock and vibration <sup>4</sup>	<b>Vibration:</b> EP455 Section 5.15.1 Random  <b>Mechanical Shock:</b> EP455 Section 5.14.1 Operational (when mounted in an enclosure with screw mounting holes utilized)
EMC <sup>5</sup>	CE (ISO 14982 Emissions and Immunity) FCC Part 15, Subpart B CISPR22

### VR500 mechanical specifications

**Table B-13: VR500 mechanical specifications**

Item	Specification
Dimensions	100 L x 60 W x 10 H mm (2.81 L x 1.60 W x 0.40 H in)
Weight	35-37 grams
Status indication	Power, GNSS lock, Differential lock, DGNSS position, Heading lock
Power/Data connector	24-pin (12x2) male header 0.078 in (2 mm) pitch 16-pin (8x2) male header 0.078 in (2 mm) pitch
Antenna connector	MMCX, female, straight

*Continued on next page*

## VR500 Technical Specifications, Continued

### VR500 L-band sensor specifications

**Table B-14: VR500 L-band sensor specifications**

Item	Specification
Receiver type	Single Channel
Channels	1525 to 1560 MHz
Sensitivity	140 dBm
Channel spacing	5.0 kHz
Satellite selection	Manual and Automatic
Reacquisition time	15 seconds (typical)

### VR500 aiding device specifications

**Table B-15: VR aiding device specifications**

Device	Description
Gyro	Provides smooth heading, fast heading reacquisition, and reliable < 3° heading for periods up to 3 minutes when loss of GPS has occurred. <sup>5</sup>
Tilt sensor	Provide pitch and roll data and assist in fast startup and reacquisition of heading solution.

<sup>1</sup> Depends on multi-path environment, number of satellites in view, satellite geometry, and ionospheric activity

<sup>2</sup> Depends also on baseline length

<sup>3</sup> Receive only, does not transmit this format

<sup>4</sup> When integrated in conjunction with the recommended shielding and protection as outlined in this guide

<sup>5</sup> Under static conditions

## TS2 Sensor Technical Specifications

TS2 sensor  
technical  
specifications

**Table B-16: TS2 sensor specifications**

Feature	Specification
Measurement Range	<b>Pitch:</b> $\pm 180^\circ$ <b>Roll:</b> $\pm 90^\circ$
Sensor Accuracy	<b>Angular Precision:</b> $\pm 0.1^\circ$ over the full angle range <b>Resolution:</b> $\pm 0.01^\circ$ <b>Repeatability:</b> $\pm 0.1^\circ$ <b>Refresh Rate:</b> 10-100HZ, software selectable <b>Base Sensor Cycle:</b> 5ms <b>Hysteresis:</b> $\pm 0.1^\circ$
Interface	<b>Protocol:</b> CANopen <b>Profile:</b> DS-410 <b>Transmission Rate:</b> Default 250 kB <b>Connector:</b> M12 male, 5-pin, a-code <b>Input Voltage:</b> 12V/24V DC <b>Firmware:</b> Updated via CANbus
Electrical	<b>Supply Voltage:</b> 5.5 – 30 VDC <b>Current:</b> $\leq 10\text{mA}$ @ 24 VDC <b>EMC Emittance:</b> DIN EN 61000-6-4 <b>EMC Immunity:</b> DIN EN 61000-6-2
Environmental	<b>Operating Temperature:</b> $-40^\circ\text{C}$ to $85^\circ\text{C}$ ; $-40^\circ\text{F}$ to $185^\circ\text{F}$ <b>Storage Temperature:</b> $-40^\circ\text{C}$ to $85^\circ\text{C}$ ; $-40^\circ\text{F}$ to $185^\circ\text{F}$ <b>Ingress Protection:</b> IP68 / IP69K Shock: MIL-STD-883 Method 2002-B <b>Vibration:</b> 1.5mm (10-59Hz) and $\leq 20\text{g}$ (58-2000Hz)
Size and Weight	<b>Dimensions:</b> 90mm(L) x 30mm(W) x 20mm(D); 3.54" (L) x 1.18" (W) x 0.79"(D) <b>Weight:</b> 120g; 4.2oz
Materials	<b>Industrial Version:</b> Aluminum Housing and Zinc Connectors (fully encapsulated electronics) <b>Marine Version:</b> 316 Stainless Steel (fully encapsulated electronics)

*Continued on next page*

## TS2 Sensor Technical Specifications, Continued

TS2 sensor technical specifications, continued

Feature	Specification
Pinouts	<ol style="list-style-type: none"><li data-bbox="716 489 889 516">1. CAN GND</li><li data-bbox="716 527 943 554">2. Power Supply</li><li data-bbox="716 564 824 592">3. GND</li><li data-bbox="716 602 886 630">4. CAN High</li><li data-bbox="716 640 878 667">5. CAN Low</li></ol>

---

## Index

1PPS.....	6, 54	Line Color .....	73, 98
<b>Activate Loader</b> .....	33, 34	Line Style .....	73, 98
Activation .....	6	Linework.....	63, 66, 79, 82, 83, 84
Alert Method.....	73	long site alignment.....	39
Alignment Method.....	93	Message Types.....	50
Atlas .....	6, 119	Multipath .....	7
Backdrop .....	80, 90, 91	Name.....	78
Base Station .....	6	NMEA .....	7, 119
Baud Rates .....	50	Parallel orientation .....	36
BeiDou.....	6, 117, 118	Perpendicular orientation.....	36
<b>Control</b> .....	57	Pitch .....	118
Data file.....	85, 87, 90	<b>Pole-mount</b> .....	40
Description.....	62, 78	Power/Data cable .....	44, 51
DGPS/DGNSS.....	6	<b>Program Type</b> .....	32
Differential Corrections .....	6	Radio .....	8
Electrical isolation .....	55	RightArm .....	30, 31, 32, 33, 34
Elevation .....	88	ROX.....	8, 119
Elevation Mask.....	7	RS-422 .....	49, 50
environmental.....	35, 36	RTCM.....	8, 119
Ethernet .....	49, 119	RTK .....	6, 8, 48, 117, 119
File Path.....	73, 98, 99	SBAS .....	8, 55, 117, 118, 119
Files .....	57, 78, 79	Serial port configuration.....	49
Fill Color .....	73, 98	Serial ports .....	49, 119
Fill Style .....	73, 98, 101, 102	Short site alignment.....	39
firmware.....	30, 31, 32, 33, 34, 49	Show in Views .....	73
Firmware .....	7, 30, 31, 32, 33, 34	Site Calibration.....	78
Flush-mount.....	40	Status .....	33, 120
GALILEO.....	7	Subscription .....	6, 8
Geodetic.....	93	<b>Surface Options</b> .....	96, 98, 99, 101, 103
GLONASS .....	7, 117, 118	<b>Surfaces</b> .....	73, 96, 98
GPS .....	6, 7, 8, 117, 118, 119, 121	Survey Top.....	63
Grid.....	93	<b>Survey Topo</b> .....	68, 69, 71, 79, 86, 87, 88
Guideline.....	63, 79, 85, 86	Transform Method.....	92
Heading .....	7, 56, 118, 120	UHF.....	6, 48, 56
Home screen .....	61, 77	UHF Radio Antenna.....	48
<b>HPR values</b> .....	37	<b>Units</b> .....	92
Job Basics .....	61, 78	<b>Units of Measure</b> .....	92
<b>Job Files</b> .....	64, 81, 86, 87, 89, 91	WAAS .....	8, 118
<b>Job Scale</b> .....	94	WebUI .....	30, 50
<b>LED indicators</b> .....	56	Work Type.....	73, 98, 99, 100

# End User License Agreement

---

## End User license agreement

**IMPORTANT** - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
  - a. install or use more copies of the Software than the number of copies that have been licensed;
  - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
  - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
  - d. modify or create derivative works based on the Software;
  - e. sub-license, rent, lease, loan or distribute the Software;
  - f. permit any third party to use the Software;
  - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
  - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
  - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at anytime.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** "Hemisphere GNSS", "Crescent", "Eclipse" and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential positioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.
12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere. 19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a) negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product,

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

- (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
19. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
20. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
21. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
22. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
23. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
24. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
25. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
26. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

**GENERAL.** This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.

---

## Warranty Notice

---

### Warranty notice

**COVERED PRODUCTS:** This warranty covers all products manufactured by Hemisphere GNSS and purchased by the end purchaser (the "Products"), unless otherwise specifically and expressly agreed in writing by Hemisphere GNSS.

**LIMITED WARRANTY:** Hemisphere GNSS warrants solely to the end purchaser of the Products, subject to the exclusions and procedures set forth below, that the Products sold to such end purchaser and its internal components shall be free, under normal use and maintenance, from defects in materials, and workmanship and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for a period of 12 months from delivery of such Product to such end purchaser (the "Warranty Period"). Repairs and replacement components for the Products are warranted, subject to the exclusions and procedures set forth below, to be free, under normal use and maintenance, from defects in material and workmanship, and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater.

**EXCLUSION OF ALL OTHER WARRANTIES.** The LIMITED WARRANTY shall apply only if the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS relevant User's Manual and Specifications, AND the Product is not modified or misused. The Product is provided "AS IS" and the implied warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE and ALL OTHER WARRANTIES,

express, implied or arising by statute, by course of dealing or by trade usage, in connection with the design, sale, installation, service or use of any products or any component thereof, are EXCLUDED from this transaction and shall not apply to the Product. The LIMITED WARRANTY is IN LIEU OF any other warranty, express or implied, including but not limited to, any warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE, title, and non-infringement.

**LIMITATION OF REMEDIES.** The purchaser's EXCLUSIVE REMEDY against Hemisphere GNSS shall be, at Hemisphere GNSS's option, the repair or replacement of any defective Product or components thereof. The purchaser shall notify Hemisphere GNSS or a Hemisphere GNSS's approved service center immediately of any defect. Repairs shall be made through a Hemisphere GNSS approved service center only. Repair, modification or service of Hemisphere GNSS products by any party other than a Hemisphere GNSS approved service center shall render this warranty null and void. The remedy in this paragraph shall only be applied in the event that the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS's relevant User's Manual and Specifications, AND the Product is not modified or misused. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR CONTINGENT DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE

TO PURCHASER, even if Hemisphere GNSS has been advised of the possibility of such damages. Without limiting the foregoing, Hemisphere GNSS shall not be liable for any damages of any kind resulting from installation, use, quality, performance or accuracy of any Product.

**HEMISPHERE IS NOT RESPONSIBLE FOR PURCHASER'S NEGLIGENCE OR UNAUTHORIZED USES OF THE PRODUCT.** IN NO EVENT SHALL Hemisphere GNSS BE IN ANY WAY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM PURCHASER'S OWN NEGLIGENCE, OR FROM OPERATION OF THE PRODUCT IN ANY WAY OTHER THAN AS SPECIFIED IN Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS is NOT RESPONSIBLE for defects or performance problems resulting from (1) misuse, abuse, improper installation, neglect of Product; (2) the utilization of the Product with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Hemisphere GNSS; (3) the operation of the Product under any specification other than, or in addition to, the specifications set forth in Hemisphere GNSS's relevant User's Manual and Specifications; (4) damage caused by accident or natural events, such as lightning (or other electrical discharge) or fresh/ salt water immersion of Product; (5) damage occurring in transit; (6) normal wear and tear; or (7) the operation or failure of operation of any satellite-based positioning system or differential correction service; or the availability or performance of any satellite-based positioning signal or differential correction signal.

**THE PURCHASER IS RESPONSIBLE FOR OPERATING THE VEHICLE SAFELY.** The purchaser is solely responsible for the safe operation of the vehicle used in connection with the Product, and for maintaining proper system control settings. UNSAFE DRIVING OR SYSTEM CONTROL SETTINGS CAN RESULT IN PROPERTY DAMAGE, INJURY, OR DEATH.

---

*Continued on next page*

## Warranty Notice, Continued

---

### Warranty notice, continued

The purchaser is solely responsible for his/her safety and for the safety of others. The purchaser is solely responsible for maintaining control of the automated steering system at all times. THE PURCHASER IS SOLELY RESPONSIBLE FOR ENSURING THE PRODUCT IS PROPERLY AND CORRECTLY INSTALLED, CONFIGURED, INTERFACED, MAINTAINED, STORED, AND OPERATED IN ACCORDANCE WITH Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS does not warrant or guarantee the positioning and navigation precision or accuracy obtained when using Products. Products are not intended for primary navigation or for use in safety of life applications. The potential accuracy of Products as stated in Hemisphere GNSS literature and/or Product specifications serves to provide only an estimate of achievable accuracy based on performance specifications provided by the satellite service operator (i.e. US Department of Defense in the case of GPS and differential correction service provider). Hemisphere GNSS reserves the right to modify Products without any obligation to notify, supply or install any improvements or alterations to existing Products.

**GOVERNING LAW.** This agreement and any disputes relating to, concerning or based upon the Product shall be governed by and interpreted in accordance with the laws of the State of Arizona.

**OBTAINING WARRANTY SERVICE.** In order to obtain warranty service, the end purchaser must bring the Product to a Hemisphere GNSS approved service center along with the end purchaser's proof of purchase. Hemisphere GNSS does not warrant claims asserted after the end of the warranty period. For any questions regarding warranty service or to obtain information regarding the location of any of Hemisphere GNSS approved service center, contact Hemisphere GNSS at the following address:

**Hemisphere GNSS**

8515 E. Anderson Drive Scottsdale, AZ 85255, USA

Phone: +1-480-348-6380

Fax: +1-480-270-5070

[TECHSUPPORT@HREGNSS.COM](mailto:TECHSUPPORT@HREGNSS.COM) [WWW.HGNSS.COM](http://WWW.HGNSS.COM)

---



Hemisphere GNSS Inc.  
8515 East Anderson Drive, Suite A  
Scottsdale, Arizona, US 85255  
Phone: 480-348-6380  
Fax: 480-270-5070  
[PRECISION@HGNSS.COM](mailto:PRECISION@HGNSS.COM)  
[WWW.HGNSS.COM](http://WWW.HGNSS.COM)