



**GRADEMETRIX™ SCRAPER**  
**INSTALLATION GUIDE**  
**Revision: A2**



Additional information, documentation, and software can be found at:  
[WWW.HGNSS.COM](http://WWW.HGNSS.COM)



## Device Compliance, License and Patents

---

### Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and  
this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT).

E-Mark Statement: This product is not to be used for driverless/autonomous driving.

---

### Copyright Notice

Copyright Hemisphere GNSS, Inc. (2022). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

---

### Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™, Cygnus™, Atlas™, ARTK, SureFix™, and Athena™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

---

### Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

---

*Continued on next page*



## Device Compliance, License and Patents, Continued

---

**Notice to Customers** Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc.  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[PRECISION@HGNSS.COM](mailto:PRECISION@HGNSS.COM)  
[HTTPS://WWW.HEMISPHERENGNSS.COM/](https://www.hemispherengnss.com/)

---

**Technical Support** If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[SUPPORT.HGNSS.COM](mailto:SUPPORT.HGNSS.COM)

---

**Documentation Feedback** Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website:

[HTTPS://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2](https://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2)

---

## Table of Contents

---

<b>Device Compliance, License and Patents .....</b>	2
Chapter 1: Getting Started.....	6
Overview .....	6
Getting Started.....	7
Tools List .....	8
Preparing for Installation .....	9
Safety Information and Warnings.....	10
What's Included in Your Kit.....	11
Machine Inspection Checklist .....	15
Chapter 2: GMS-1 Sensor Installation.....	16
Overview .....	16
GMS-1 Sensor Installation.....	17
Chapter 3: Installing the Sensor Junction Box .....	22
Overview .....	22
Install the Junction Box.....	23
Chapter 4: Install the VR1000 Receiver .....	27
Overview .....	27
Install the VR1000 Receiver .....	28
Chapter 5: Install the VR1000 Antenna .....	32
Overview .....	32
Install the Mast .....	33
Chapter 6: Installing the IronOne or IronTwo Control Box.....	36
Overview .....	36
IronOne/Iron Two Display Installation.....	37
Chapter 7: GradeMetrix System .....	42
Overview .....	42
Measure and Set Up Equipment.....	43
Configure Machine Measure .....	49
Calibrate System .....	51
Verify Machine Accuracy .....	52

---



Save Machine Settings .....	55
Appendix A: Troubleshooting .....	57
Overview .....	57
Troubleshooting .....	58
Appendix B: Technical Specifications.....	61
Overview .....	61
VR1000 GNSS Receiver .....	62
<b>IronOne</b> .....	67
IronTwo .....	70
GMS-1 Sensor.....	72
Appendix C: Cable Pin-Outs .....	74
Overview .....	74
VR1000 Cables .....	75
VR1000 Installation Schematic .....	78
Index.....	79
End User License Agreement.....	80

---

## Chapter 1: Getting Started

### Overview

---

#### Introduction

Chapter 1 provides you with the information and proper tooling needed to begin a GradeMetrix Scraper installation.

It is recommended for only an experienced service technician perform the installation and configuration of the Hemisphere GradeMetrix system.

---

#### Contents

	Topic	See Page
Getting Started		7
Tools List		8
Preparing for Installation		9
Safety Information and Warnings		10
What's Included in Your Kit		11
Machine Inspection Checklist		15

---

## Getting Started

---

**Introduction** This section lists the tools required, preparation, and power setup necessary to prepare your machine for the GradeMetrix scraper system installation.

---

## Tools List

---

### Tools list

A variety of tools are needed to properly set up and install your GradeMetrix Scraper system.

Review the following list and locate these required tools prior to beginning installation:

- Slotted screwdriver
- Phillips screwdriver
- Adjustable wrench
- ½" & 3/8" ratchet set
- Inch sockets
- Metric sockets
- Cable tie cutters
- Allen wrench set (inch)
- Allen wrench set (metric)
- Torx wrench
- Wire stripper / Crimp tool
- GNSS base/rover
- Open wheel measuring tape
- Cable ties
- Split tube or other cable protection
- Electrical Tape
- Heat Shrink
- Electrical terminals i.e., spade, ring etc.
- Thread locker (Loctite Blue)
- Nickel anti-seize grease or similar
- Cold Gal and Machine-color paint if welding

---

## Preparing for Installation

---

### Prepare for installation

To prepare for a scraper installation place the scraper on a flat surface.

Locate a clean source of power and a safe mounting location for the control box. Check to ensure the IronOne/IronTwo control box and sensors have power. The GMS-1 sensors are powered through the IronOne/IronTwo and receiver.

**Important:** The IronOne/IronTwo must receive 9 – 36 VDC of input power from the machine (most machines should provide 24 V directly from the battery). **Ground to the machine chassis. Do not ground to the negative terminal of the battery.**

**Note:** The IronOne or IronTwo must be installed so the operator can see the screen. Use care not to place the IronOne or IronTwo in a location that might compromise visibility or block an exit from the cab.

---

## Safety Information and Warnings

---

### Safety information and warnings

Refer to the safety manual for proper operation and safety precautions. Store this guide and all related safety information with related machine manuals for future reference.

Prior to installing and operating GradeMetrix, read and follow all safety precautions as outlined in this manual.

Review and adhere to the follow safety warnings:

- Before you begin working on the machine, use the machine's master switch to disconnect power to the machine.
- A human operator is required to manually maintain a safe operating speed.
- GradeMetrix is a grade reference tool and is not designed to replace the machine's operator. **Do NOT allow a driver to operate without safety instructions. Avoid obstacles to prevent human, machine, and property injury.**

**Important: The safety warnings contained in this manual are intended as guidelines and are not meant to be a complete list of potential hazards.**

---

## What's Included in Your Kit

---

<b>Kit contents</b>	Your GradeMetrix kit contains the parts listed in Table 1-1, Installation Kit Contents.
---------------------	---

**Table 1-1: Installation Kit Contents**

Part Number	Description	Qty
752-0030-10	HGNSS VR1000 Receiver	1
752-0041-10	A46 ANTENNA, HGNSS	1
051-0415-10	Cable, RG 213, N-Type, Male, with Caps, 25ft	2
051-0419-10	CBL,VR1000 Excav Rcvr I/O,23to12pin,0.5m	1
051-0420-10	CBL,VR1000 Excav Chassis,12to2X6Pin,5m	1
710-0237-10	KIT, BULKHEAD, N-TYPE QTY 1, M12-5PIN	1
051-0425-30	Cable, M12 CAN M/F Sensor, 5m	1
051-0425-40	Cable, M12 CAN M/F Sensor, 10m	2
710-0217-10	KIT, GMS-1 SENSOR MOUNT, WITH COVER	1
750-5019-10	SENSOR,GMS-1,DUAL AXIS,VER,M12-5PIN,M-F	1
150-0018-000	ANT,450-470MHZ,3DB-MEG,3.4",BLK/WHT	1
150-0053-10	IronX BT_Wifi Antenna	1
150-0054-10	IronX Cellular Antenna	1
478-0022-10	MAGNET BASE, 3.25" DIA, CHROME, UHF ANT, 12' CABLE, TNC	1
710-0148-10	IronX Flush Mount Kit	1
710-0149-10	IronX U-Mount Kit	1
710-0161-10	KIT, MOUNTING MAGNETS, VR1000	1
710-0223-10	KIT, BT/WIFI ANTENNA WITH ADAPTER	1
710-0231-10	GradeMetrix Consumables Kit, VR1000	1
750-0245-10	CAN TERMINATION RESISTOR, M12(F)	1
400-1105-10	N-Type, Coupler	1

---

*Continued on next page*

## What's Included in Your Kit, Continued

---

Kit contents,  
continued

**Table 1-1: Installation Kit Contents**

**Note:** You must add either an IronOne or an IronTwo kit to your GradeMetrix Scraper kit.

	<b>IronTwo Terminal Kit, NA &amp; EMEA</b>	<b>Qty</b>
050-0022-01	CBL, ADO, POWER	1
050-0046-20	CBL, ADO, PWR ADAPT, GRADEMETRIX	1
051-0426-10	HGNSS IronTwo Bulkhead Cable	1
752-0040-10	IronTwo Terminal	1

	<b>IronTwo Terminal Kit, APAC</b>	<b>Qty</b>
050-0022-01	CBL, ADO, POWER	1
050-0046-20	CBL, ADO, PWR ADAPT, GRADEMETRIX	1
051-0426-10	HGNSS IronTwo Bulkhead Cable	1
752-0040-20	IronTwo Terminal, APAC	1

	<b>IronOne Terminal Kit</b>	<b>Qty</b>
051-0408-10	HGNSS IronOne Bulkhead Cable	1
054-0182-11	HGNSS IronOne Power Cable	1
752-0036-10	IronOne Terminal	1

---



*Continued on next page*

## What's Included in Your Kit, Continued

---

### Optional Accessories

**Table 1-2: Option Accessories**



Part Number	Description
<b>710-0247-10</b>	KIT, MOUNTING BRACKET, R/A, 1.4M MAST 
<b>710-0246-10</b>	

---

*Continued on next page*

## What's Included in Your Kit, Continued

Kit contents,  
continued

Part Number	Description
<b>710-0239-10</b>	KIT, 1.4 METER MAST 
<b>720-0087-10</b>	CBL ASSY, RF, N(M)-N(M), COILED, 15FT 

**NOTE:** Due to manufacturing processes outside of HGNSS purview, the installer may be required to adapt the GradeMetrix kit to your individual system.

## Machine Inspection Checklist

### Machine Inspection Checklist

To ensure peak performance, GradeMetrix should be installed only after a thorough machine inspection has been conducted.

To avoid bodily and machine injury, follow the machine inspection checklist below:

- Park the machine on a clean and level surface.
- Turn off the machine and remove power from the batteries.
- Lower all implements to the ground.
- Apply the parking brake and chock wheels if necessary.
- Inspect any drilling and/or cutting sites to ensure no electrical wiring damage will be incurred.
- Periodically re-measure the blade width at the tips to adjust accuracy due to blade wear.

## Chapter 2: GMS-1 Sensor Installation

### Overview

---

#### Introduction

The scraper uses one GMS-1 sensor. This sensor provides the pitch and roll values of the cutting edge so that accurate calculations can be done from the GNSS antenna to the cutting edge – allowing GradeMetrix to provide an accurate cut/fill.

---


#### Contents

Topic	See Page
GMS-1 Sensor Installation	17

---

## GMS-1 Sensor Installation

**Sensors** Your GradeMetrix Scraper kit comes with a GMS-1 sensor (P/N: 750-5019-10). The sensor will be mounted to the outside of the scraper.



**Important: It is crucial to choose a safe welding location for the sensor.**


---

*Continued on next page*

## GMS-1 Sensor Installation, Continued

### Brackets


The GMS-1 sensors include a base bracket (P/N: 602-1194-10) that can be welded to the machine. This bracket has two welding holes, so the bracket can be welded to the machine and hide the weld. **Prior to welding, disconnect the control box and switch off the master ground disconnect.** Refer to Figure 2-1 bracket dimensions.



**Figure 2-1: Bracket dimensions**

Strain relief wings are also included. Screw the strain relief wing onto the bracket with the provided 14mm M6x1mm screws. The CAN cable can be zip-tied to the strain relief wing.

Figure 2-2 shows the drawing of P/N: 602-1196-10 strain relief wing.



**Figure 2-2: P/N: 602-1196-10 strain relief wing**

*Continued on next page*

## GMS-1 Sensor Installation, Continued


---

### Brackets, continued

After the base bracket has been welded onto the machine, the GMS-1 sensor can be bolted onto the bracket with the provided 20mm M6x1mm screws.

One strain relief plate and one spacer (P/N: 602-1197-10) is included for the blade. The spacer can be attached to the base bracket on the opposite side of the strain relief wing using the provided 14mm M6x1mm screws. See the following example.

A cover is added to the sensor bracket for protection.



**Figure 2-3: Strain Relief Plate and Spacer**

---

*Continued on next page*

## GMS-1 Sensor Installation, Continued

**Sensor Placement** Place the sensor on the outside of the can.

**Important: Ensure the antenna and sensor are on the same plane. When the can is raised, the antenna should raise with the can.**

The LED light can be placed facing left, right, up, or down. Take care to square the sensor so the LED faces one of these locations.

The image below shows a red line along the antenna mast axis. The blue line shows the plane that the sensor is installed on. When the can is pitched or rolled, the antenna and sensor will be pitched or rolled along the same angle.



**Figure 2-4: Antenna and Sensor**

---

*Continued on next page*

## GMS-1 Sensor Installation, Continued

---

### Sensor Placement, continued

The image below shows a closer image of the sensor.



**Figure 2-5: Sensor placement**

The sensor shown above, is mounted to the outside of the can.

## Chapter 3: Installing the Sensor Junction Box

### Overview

---

<b>Introduction</b>	This chapter provides the information to install the sensor junction box in your scraper.
---------------------	---

---

### Contents

Topic	See Page
Install the Junction Box	23

## Install the Junction Box

**Steps to install the junction box** For a pull pan scraper, the tractor towing the scraper can disconnect from the pan. Since the GradeMetrix system requires components be installed on both the tractor (IronOne or IronTwo control box and VR1000 GNSS receiver) and on the pan (GMS-1 sensor and A46 antenna), there must be an easy way to disconnect the system.

The GradeMetrix Scraper system comes with a junction box.

A CAN cable runs from the IronOne or IronTwo (inside of the cab) to the junction box and from the junction box to the GMS-1 sensor. Additionally, a GNSS antenna cable runs from the VR1000 to the junction box and from the junction box to the A46 antenna.

The junction box must be installed near the point where the tractor attaches to the pan. It can be installed on either the pan or on the tractor.

---

*Continued on next page*


## Install the Junction Box, Continued

---

**Steps to install  
the junction  
box, continued**

To install the junction box, follow the steps as detailed in Table 3-1: Install Sensor Junction Box.

**Table 3-1: Install Sensor Junction Box**

Step	Action
1	<p>The junction box is a base plate that can be welded onto the machine. The junction box will have one 5-pin M12 bulkhead connector for the CAN cable and either one or two N-Type connectors for the GNSS antennas. Most systems come with a single GNSS antenna, and the secondary antenna is optional.</p>  <p><b>Figure 3-1: Junction Box</b></p>


---

*Continued on next page*

## Install the Junction Box, Continued

### Steps to install the junction box, continued

**Table 3-1: Install Sensor Junction Box (continued)**

Step	Action
2	<p>In the photo below, the junction box is securely welded to the machine near the point where the tractor can disconnect from the pan. Paint the junction box to help protect it from rust.</p> <p><b>Prior to welding, disconnect the control box and switch off the master ground disconnect.</b></p> 
3	<p>A cover is provided to place over the junction box. If you are using two GNSS antennas, you can punch out the additional slot on the cover.</p> 

**Figure 3-2: Junction Box Installed**


*Continued on next page*

## Install the Junction Box, Continued

---

### Steps to install the junction box, continued

**Table 3-1: Install Sensor Junction Box (continued)**

Step	Action
4	<p>The junction box has four rubber hooks for attaching the cover.</p> 
5	<p>The junction box should be placed in a protected area when possible.</p> 

## Chapter 4: Install the VR1000 Receiver

### Overview

---

<b>Introduction</b>	A VR1000 receiver is used for position. This section describes how to install the VR1000 onto the scraper.
---------------------	--

---

### Contents

Topic	See Page
Install the VR1000 Receiver	28

---


## Install the VR1000 Receiver

---

### Install the VR1000 (Magnets)

The first step is to install the VR1000 magnet kit (P/N: 710-0161-10) onto the VR1000, so the VR1000 can be secured in a safe location on the scraper.

Use the M5x0.8mm screws to attach the magnets to the VR1000.



**Figure 4-1: VR1000 with magnets**

The VR1000 will look as shown:



**Figure 4-2: VR1000 with magnets attached**

---

*Continued on next page*

## Install the VR1000 Receiver, Continued

---

### Mount the corrections radio antenna

Mount the radio antenna at the highest point and secure with mounting bolts or a mag mount.

**Note 1:** The mounting location for the RTK antenna can typically be located on top of the cab using a magnet mounted antenna.

**Note 2:** If receiving RTK over NTRIP, a UHF radio antenna is not necessary.



**Figure 4-3: Radio antenna**

---

*Continued on next page*

## Install the VR1000 Receiver, Continued

---

### Mount the VR1000

Mount the VR1000 in the battery compartment, the engine compartment, or behind the seat. Ensure the VR1000 is mounted far from any heat sources. The GradeMetrix Scraper Installation Kit contains magnetic mounts that allow the VR1000 to be mounted in a convenient location.

Carefully run the cables into the cab. The default GradeMetrix Scraper comes with one A46 antenna, although there is an option to purchase a second A46 antenna. This would require installing an additional Rf cable (as shown in the photo below).

**Note:** Run the power and communication cable into the cab to connect to the IronOne/IronTwo cable. Run the UHF antenna to the roof of the machine.



**Figure 4-4: Mounted VR1000**

---

*Continued on next page*

## Install the VR1000 Receiver, Continued

**Running Cables** The VR1000 has a short, 50cm cable that connects to the 23-pin connector on the VR1000 (P/N: 051-0419-10).




Figure 4-5: VR1000 Cable, P/N: 051-0419-10

Connect the J2 connector of P/N: 051-0419-10 to the J1 connector of the 5m VR1000 cable (P/N: 051-0420-10) that runs to the IronOne or IronTwo control box.




Figure 4-6: VR1000 Cable, P/N: 051-0420-10

The 5m cable must be run safely to the inside of the cab, where the IronOne or IronTwo is installed. The J2 connector of cable (P/N: 051-0420-10) connects to the IronOne or IronTwo cable and provides both power and communication to the VR1000 (see [Installing the IronOne or IronTwo](#)). The J3 connector can be used for an external RTK correction source. See [Appendix C](#) for further details on pinouts.

## Chapter 5: Install the VR1000 Antenna

### Overview

---

#### Introduction

Chapter 5 provides all the information you need to install the VR1000 antenna and antenna mast.

---

#### Contents

	Topic	See Page
	Install the Mast	33

---

## Install the Mast

### Steps to install the A46 antenna mast

The A46 antenna is installed onto a mast. The mast is provided as an optional accessory (Part Number: 710-0239-10). The mast is a 1.4m (4.6ft) tall mount for the A46 GNSS antenna. The dimensions of the mast base are shown below. Several adapter plates are available for purchase. All dimensions are in millimeters. Note: do not torque more than 15 lbs.-ft/20 Nm.

**Note:** When bolting the mast down, make sure to use a thread locker (Loctite Blue) to secure the base to the mounting plate. Place grease on the  $5/8"$ -11 thread that the A46 antenna mounts to.




Figure 5-1: Antenna Mast Base

*Continued on next page*

## Install the Mast, Continued

---

**Steps to install the A46 antenna mast, continued**

To install the A46 antenna mast, follow the steps as detailed in Table 5-1.

**Table 5-1: Install A46 antenna mast**

Step	Action
1	<p>If the A46 antenna mast is not mounted over the cutting edge of the scraper you can enter the offsets into the software.</p> <p>It is important that it is mounted to part of the can, so when the cutting edge is raised, the antenna is also raised to be on the same articulation. The antenna should move with the cutting edge. Refer to <a href="#">Installing the sensor</a>.</p>  

---

*Continued on next page*

## Install the Mast, Continued

---

Steps to install  
the A46  
antenna mast,  
continued

**Table 5-1: Install A46 antenna mast (continued)**

Step	Action
2	<p>The A46 antenna screws onto the 5/8" thread at the top of the mast. A coil cable is available as an optional accessory (Part Number 720-0087-10).</p>  A photograph showing a yellow construction vehicle, likely a scraper, with a mast and antenna installed. The mast is a vertical yellow pole with a circular top. A coiled yellow cable is attached to the mast. The vehicle has a yellow body with some text and a red 'STOP' sign on the side. The background shows a blue sky and some trees.

# Chapter 6: Installing the IronOne or IronTwo Control Box

## Overview

---

<b>Introduction</b>	This chapter provides information necessary to install the IronOne or IronTwo to your GradeMetrix scraper.
---------------------	--

---

## Contents

---

Topic	See Page
IronOne/Iron Two Display Installation	37

---

## IronOne/Iron Two Display Installation

---

### Install the IronOne or IronTwo

The GradeMetrix Scraper Installation Kit comes with the following components:

- IronOne (P/N: 752-0036-10) or IronTwo (P/N: 752-0040-10 or P/N: 752-0040-20)
- IronOne Power Cable (P/N: 710-0210-10) or IronTwo Power Cable (P/N: 050-0022-01 and P/N: 050-0046-01)
- IronOne/IronTwo U-Mount Kit (P/N: 710-0149-10)
- IronOne/IronTwo Flush Mount Kit (P/N: 710-0148-10)

To install the components, you must have:

- Philips Screwdriver
- Nut driver

The IronOne/IronTwo control panel console (P/N: 752-0036-10) and mounting assembly (the RAM mount included in the GradeMetrix Scraper Installation Kit) should be installed inside of the cab in a location the gives the operator a clear view.



**Figure 6-1: IronTwo control box-mounting option #1**

---

*Continued on next page*

## IronOne/Iron Two Display Installation, Continued

---

Install the  
IronOne or  
IronTwo,  
continued



Figure 6-2: IronOne control box-mounting option #2

**Note:** Individual machines may differ, and some customization may be necessary to complete any portion of this installation. Installers may wish to mount the IronOne /IronTwo in a different location than shown, or with custom built brackets.

---

*Continued on next page*

## IronOne/Iron Two Display Installation, Continued

---

**Install the  
IronOne or  
IronTwo,  
continued**

Follow these steps to install the control box to your machine:

**Table 6-1: Install IronOne or IronTwo control box**

Step	Action
1	Attach the 1.5" RAM ball to the rear of the IronOne or IronTwo using the included bolts.
2	Install the 1.5" RAM base mount to an unobstructed location in the cab for console mounting. <b>Note:</b> The RAM swivel mount can be used to adjust the location and viewing angle of the console.
3	Using the IronOne/IronTwo U-Mount Kit (P/N: 710-0149-10), mount the IronOne/IronTwo to the window rails at the right-side of machine cab.
4	Ensure adequate cable slack is provided, so the IronOne/IronTwo can swivel on the RAM mount without putting stress on the cables.

The IronOne or IronTwo power cable runs power to the console.

**IMPORTANT!**

**The main power cable (IronOne P/N: 054-0182-10 and IronTwo P/N: 050-0022-01, P/N: 050-0046-01 connected) leads should be installed to system power (9-36 +VDC and chassis ground).**

**Do NOT ground to the negative terminal of the battery; always ground to the machine chassis.**

The IronTwo power cable comes with an ignition wire (orange) that can be connected to the switch power. If connected to the switch power, the IronTwo will automatically be turned on after receiving power. Switch power should have 12v or 24v (depending on machine voltage) when the ignition is keyed on and have 0v when ignition is keyed off. If you do not want to use switch power, connect the ignition to the constant machine voltage power.

---

*Continued on next page*

## IronOne/Iron Two Display Installation, Continued

---

### Install the IronOne or IronTwo, continued

The IronOne/IronTwo bulkhead adapter cable harness (P/N: 054-0182-11 and P/N: 051-0426-10) must be installed and routed along the interior side of the cab. Install harness cables away from sharp edges and other areas that could damage cables. The cable provides the following connections for the installation:

- **Serial (1)** – 6-pin Deutsch Connector -Connects to the GNSS receiver.
- **CAN (1)** – M12 Connector -Connects to the CAN axial sensors for monitoring boom, stick, and bucket movement.

**Note:** When installing cables, ensure you leave enough slack behind the IronOne /IronTwo so the display screen may be moved in any direction and will not place any stress on the cabling.

---

*Continued on next page*

## IronOne/Iron Two Display Installation, Continued

**IronOne cable schematic** The diagrams below show the cable schematics for P/N: 051-0408-10 (IronOne) and P/N: 051-0426-10 (IronTwo). The J1 connector plugs into the IronOne/IronTwo. The J2 connector connects a CAN cable. The J3 connector connects to the VR1000 cable.




Figure 6-3: Cable schematic for P/N: 051-0408-10 (IronOne)




Figure 6-4: Cable schematic for P/N: 051-0426-10 (IronTwo)

## Chapter 7: GradeMetrix System

### Overview

---

#### Introduction

This chapter provides information necessary to use the GradeMetrix System to measure and setup your equipment.

---

#### Contents

Topic	See Page
Measure and Set Up Equipment	43
Configure Machine Measure	49
Calibrate System	51
Verify Machine Accuracy	52
Save Machine Settings	55



---

## Measure and Set Up Equipment

### Steps to measure and set up equipment

To measure and setup your equipment, log in as administrator, and follow the steps as detailed in Table 7-1: Measure and Set Up Equipment.

**Table 7-1: Measure and Set Up Equipment**

Step	Action
1	<p>Select Equipment Setup.</p> 
2	<p>Select Scraper in the General Settings screen.</p> 
3	<p>Select Machine Type.</p>


*Continued on next page*

## Measure and Set Up Equipment, Continued

---

Steps to measure and set up equipment, continued

**Table 7-1: Measure and Set Up Equipment (continued)**

Step	Action
4	<p>Assign a <b>Machine ID</b>.</p> <p><b>Note:</b> Your Machine ID should be a unique identifier that will identify this specific machine to your company.</p>
5	<p>Select the unit of measure. Click <b>NEXT</b>.</p> 


---

*Continued on next page*

## Measure and Set Up Equipment, Continued

Steps to  
measure and  
set up  
equipment,  
continued

**Table 7-1: Measure and Set Up Equipment (continued)**


Step	Action
6	<p>Follow the screen directions for measuring the machine.</p> <p>The first dropdown box –<b>Type</b> – references the GNSS option for the scraper.</p> <div style="border: 1px solid red; padding: 5px; margin: 10px 0;"> <p><b>Important! Scraper kits use either a VR1000 or a VR1000 SA. This is a critical setting.</b></p> </div> <p>Select <b>VR1000</b> if you are using two A46 antennas. Select <b>VR1000 SA</b> if you are using one A46 antenna.</p> <p>If you select VR1000 but only have one A46 antenna installed, the system will not provide cut/fill because the VR1000 detects only one antenna.</p> <p>When installing the antenna, keep the mast vertical, so to be measured to the right and from behind to the bottom of the mast. The antenna height to the cutting edge should not change when moving up or down, as they move together as one single piece.</p> 

*Continued on next page*

## Measure and Set Up Equipment, Continued

Steps to measure and set up equipment, continued

**Table 7-2: Configure machine measure**

Step	Action						
1	<p>On the <b>Antenna</b> tab, select the type of antenna and receiver you are using.</p> <table border="1" data-bbox="571 570 1403 887"> <thead> <tr> <th data-bbox="571 570 840 612">Field</th><th data-bbox="840 570 1403 612">Description</th></tr> </thead> <tbody> <tr> <td data-bbox="571 612 840 696">Pitch orientation</td><td data-bbox="840 612 1403 696">This option is not used when operating a scraper.</td></tr> <tr> <td data-bbox="571 696 840 887">Roll orientation</td><td data-bbox="840 696 1403 887">Roll orientation displays if you are using a dual antenna setup. Roll orientation implies that the antennas are perpendicular to the centerline of the machine.</td></tr> </tbody> </table> <p>MBias</p> <p>MBias displays if you are using a dual antenna setup. MBias is the angle between the vector created from the primary to secondary antennas and the centerline of the machine. If using a roll orientation, this vector is offset by 90 degrees.</p> 	Field	Description	Pitch orientation	This option is not used when operating a scraper.	Roll orientation	Roll orientation displays if you are using a dual antenna setup. Roll orientation implies that the antennas are perpendicular to the centerline of the machine.
Field	Description						
Pitch orientation	This option is not used when operating a scraper.						
Roll orientation	Roll orientation displays if you are using a dual antenna setup. Roll orientation implies that the antennas are perpendicular to the centerline of the machine.						


*Continued on next page*

## Measure and Set Up Equipment, Continued

---

Steps to measure and set up equipment, continued

**Table 7-2: Configure machine measure (continued)**

Step	Action	
	Field	Description
2	PBias	This option displays if you are using a dual antenna setup. This is the angle created between the vector from the primary to secondary antenna and the machine's chassis.  
	Right	The distance of the primary antenna from the left side of the machine.
	Behind	The distance from the primary antenna to the cutting edge. If the antenna is in front of the cutting edge, this value will be <b>negative</b> . If the antenna is behind the cutting edge, this value will be positive.
	Height	The height of the antenna above the cutting edge.

---


*Continued on next page*

## Measure and Set Up Equipment, Continued

---

Steps to measure and set up equipment, continued

**Table 7-2: Configure machine measure (continued)**

Step	Action
3	<p>Click the <b>Chassis</b> tab. Type the body length, width, and height per the diagram below. The blade width is defined by the chassis width. Body length and height are for graphical purposes and should be accurate to within +/- 1m.</p> 



---

## Measure and Set Up Equipment

### Steps to measure and set up equipment, continued

After clicking **Next** in the screen above, you will see the **Sensor Placement** screen.

**Table 7-3: Set up sensor**

Step	Action
1	<p>Click <b>Sensor Network</b>. Set <b>Network</b> to <b>J1939</b>.</p> 
2	<p>The sensor is unconfigured.</p> <p>Click the sensor name and click <b>Configure</b>. A dialogue window displays. Click the dropdown box next to <b>Placement</b>. Click <b>Chassis</b>. Click <b>Use internal termination</b>. Click <b>OK</b>.</p> 


*Continued on next page*

## Measure and Set Up Equipment, Continued

---

Steps to measure and set up equipment, continued, continued

**Table 7-3: Set up sensor (continued)**


Step	Action						
3	<p>Set up the orientation of the sensor. <b>Mount Position</b> refers to the direction of the label.</p> <table border="1" data-bbox="576 576 1405 734"> <thead> <tr> <th data-bbox="576 576 992 620">If ...</th><th data-bbox="992 576 1405 620">Then ...</th></tr> </thead> <tbody> <tr> <td data-bbox="576 620 992 665">the label is facing forward</td><td data-bbox="992 620 1405 665">Set to <b>Label Forward</b></td></tr> <tr> <td data-bbox="576 665 992 734">The label is facing toward the cab</td><td data-bbox="992 665 1405 734">Set to <b>Label Back</b></td></tr> </tbody> </table>	If ...	Then ...	the label is facing forward	Set to <b>Label Forward</b>	The label is facing toward the cab	Set to <b>Label Back</b>
If ...	Then ...						
the label is facing forward	Set to <b>Label Forward</b>						
The label is facing toward the cab	Set to <b>Label Back</b>						
							
	4 Click <b>FINISH</b> .						

---

## Calibrate System

**Calibrate system** To calibrate the system, follow the steps as detailed in Table 6-4: Calibrate System. Use this method to calibrate all the sensors using GradeMetrix.


**Table 7-4: Calibrate System**

Step	Action
1	<p>Click <b>Quick Calibrate</b> and follow instructions.</p> <p>It is recommended to use a firm, flat surface during the calibration process.</p> 
2	<p>The cross slope of the blade needs to be 0. If you cannot get the cross slope at 0, use a smart level to measure the cross slope. Raise or lower the blade until the antenna mast is plumb. It is important that when entering primary antenna offsets, you measure while the machine is in this position.</p> <p>Click <b>Calibrate</b>. Click <b>OK</b>.</p> 

## Verify Machine Accuracy

**Verify machine accuracy** To verify the accuracy of the machine, follow the steps as detailed in Table 7-5: Verify Machine Accuracy.

**Table 7-5: Verify Machine Accuracy**



Step	Action
1	<p><b>Warning: if using a VR1000 with a single antenna (VR1000 SA), you must move the machine before checking accuracy, since course over ground is used to determine machine azimuth.</b></p> <p>From the main operational screen, select the “folder” icon in the upper-right corner of the screen.</p> 

*Continued on next page*

## Verify Machine Accuracy, Continued

Verify machine accuracy, continued

**Table 7-5: Verify Machine Accuracy (continued)**


Step	Action
2	<p>Verify you have an <b>RTK Fixed</b> solution before proceeding.</p>  <p><b>Raw Position Information</b></p> <ul style="list-style-type: none"> <li>Latitude: N33°04'02.9207"</li> <li>Longitude: W111°56'12.6082"</li> <li>Height: 339.528m</li> <li>Separation: -30.644m</li> <li>Orthometric: 370.171m</li> <li>Speed: 0.000m/s</li> <li>Solution: RTK Fixed</li> <li>SATS Used: 22</li> <li>Visible SATS: 22</li> </ul> <p><b>Raw Status Information</b></p> <ul style="list-style-type: none"> <li>RTK Status: 2s, RTCM3, BaseID: 420</li> <li>Quality: 91%</li> <li>RTK Date: 2021-07-19</li> <li>RTK Time: 22:40:16</li> <li>PDOP: 0.814</li> <li>HDOP: 0.500</li> <li>VDOP: 0.643</li> <li>HRMS: 0.02ft</li> <li>VRMS: 0.03ft</li> <li>Speed: 0.000m/s</li> <li>Heading: 128.3° (GNSS)</li> <li>LBias: 1.429°</li> <li>Declination: 9.96°</li> <li>CSEP: 1.686ft</li> <li>Speed: 0.0mph</li> </ul> <p><b>Local Antenna Position</b></p> <ul style="list-style-type: none"> <li>Northing: 50514.93ft</li> <li>Easting: 60845.39ft</li> <li>Elevation: 512.04ft</li> <li>Separation: 0.00ft</li> </ul> <p><b>Directional Information</b></p> <ul style="list-style-type: none"> <li>Heading: 128.3° (GNSS)</li> <li>LBias: 1.429°</li> <li>Declination: 9.96°</li> <li>CSEP: 1.686ft</li> <li>Speed: 0.0mph</li> </ul>
3	<p>Select the <b>VEH (Vehicle)</b> tab to verify the blade accuracy.</p>  <p><b>Vehicle Information</b></p> <ul style="list-style-type: none"> <li>Northing: 50510.84ft</li> <li>Easting: 60849.68ft</li> <li>Elevation: 502.74ft</li> <li>Station: Off Guide</li> </ul> <p><b>Status Information</b></p> <ul style="list-style-type: none"> <li>Azimuth: 129.1°</li> <li>MBias: -2.289°</li> <li>LBias: 1.429°</li> <li>Speed: 0.0mph</li> <li>Direction: Forward</li> <li>Status: Stopped</li> </ul> <p><b>Design Information</b></p> <ul style="list-style-type: none"> <li>Elevation: 502.68ft</li> <li>Cut/Fill: 0.00ft (cut)</li> <li>Grading Offset: 0.00ft</li> <li>Cross-Slope: 0.00%</li> <li>Long-Slope: 0.00%</li> </ul>

*Continued on next page*

## Verify Machine Accuracy, Continued

Verify machine accuracy, continued


**Table 7-5: Verify Machine Accuracy (continued)**

Step	Action																												
4	<p>Select <b>3D Point Check</b> to check the accuracy at multiple locations. Use a rover to verify accuracy at left and right of cutting edge.</p>  <table border="1" data-bbox="816 675 1183 988"> <thead> <tr> <th>Point-Of-Interest</th> <th>Northing</th> <th>Easting</th> <th>Elevation</th> </tr> </thead> <tbody> <tr> <td>Antenna</td> <td>50559.547ft</td> <td>60837.075ft</td> <td>502.834ft</td> </tr> <tr> <td>Mast</td> <td>50559.547ft</td> <td>60837.075ft</td> <td>502.834ft</td> </tr> <tr> <td>Tracks</td> <td>50554.591ft</td> <td>60836.418ft</td> <td>502.834ft</td> </tr> <tr> <td>Center</td> <td>50554.591ft</td> <td>60836.418ft</td> <td>502.834ft</td> </tr> <tr> <td>Left</td> <td>50559.547ft</td> <td>60837.075ft</td> <td>502.834ft</td> </tr> <tr> <td>Right</td> <td>50549.634ft</td> <td>60835.760ft</td> <td>502.834ft</td> </tr> </tbody> </table>	Point-Of-Interest	Northing	Easting	Elevation	Antenna	50559.547ft	60837.075ft	502.834ft	Mast	50559.547ft	60837.075ft	502.834ft	Tracks	50554.591ft	60836.418ft	502.834ft	Center	50554.591ft	60836.418ft	502.834ft	Left	50559.547ft	60837.075ft	502.834ft	Right	50549.634ft	60835.760ft	502.834ft
Point-Of-Interest	Northing	Easting	Elevation																										
Antenna	50559.547ft	60837.075ft	502.834ft																										
Mast	50559.547ft	60837.075ft	502.834ft																										
Tracks	50554.591ft	60836.418ft	502.834ft																										
Center	50554.591ft	60836.418ft	502.834ft																										
Left	50559.547ft	60837.075ft	502.834ft																										
Right	50549.634ft	60835.760ft	502.834ft																										

## Save Machine Settings

**Save Machine Settings** To save the settings for your machine, use the following steps.

**Table 7-6: Save Machine Settings**


Step	Action
1	<p>To save your machine settings, go to <b>Equipment Setup</b>.</p> 
2	<p>Click <b>Next</b>.</p> 

*Continued on next page*

## Save Machine Settings, Continued

Save Machine  
Settings,  
continued

**Table 7-6: Save Machine Settings (continued)**

Step	Action
3	<p>Click <b>Next</b> until the final screen displays. Click <b>Export to...</b> and save the machine settings to a USB thumb drive.</p> 

## Appendix A: Troubleshooting

### Overview

---

#### Introduction

Appendix A provides troubleshooting for the scraper installation.

**Note:** It is important to review each category in detail to eliminate it as a problem.

---

#### Contents

Topic	See Page
Troubleshooting	58

---

## Troubleshooting

Troubleshooting **Table A-1: Troubleshooting**

Issue	Possible Solution
Incorrect Position	<p>First, check a control point with the machine and the survey rover. If the horizontal or vertical position is off, first consider if it is off by a consistent amount throughout the jobsite, or if the position bust varies throughout the job. If it is consistent, consider the following:</p> <ul style="list-style-type: none"><li>• Check your machine measurements/offsets. If any of these are incorrect, your projected position will be off.</li><li>• Bad localization. Make sure that all points in your localization file have low residuals and/or that the correct coordinate system is selected (this can make a significant difference). If there is an inconsistent position bust, check:<ul style="list-style-type: none"><li>• Sensor mounting was incorrectly selected and/or the sensor was not calibrated. This is evident if your position is correct when flat, but not if you are on a slope.</li><li>• If the position at the GPS antenna is correct, but the position bust worsens as you approach the cutting edge, it may be a heading offset error.</li><li>• If using a single antenna solution, you need to move the machine before checking accuracy, since course-over-ground is used for machine azimuth calculation. Once you move the machine several meters, you no longer need to move the machine since the last valid course-over-ground will be locked in. This must be forward movement (not driving in reverse).</li></ul></li></ul>

---

*Continued on next page*

## Troubleshooting, Continued

---

Troubleshooting,  
continued

**Table A-1: Troubleshooting (continued)**

Issue	Possible Solution
No GPS Position	First, check to see if the VR1000 is powered on. There are LED lights underneath the receiver. If the receiver is not powered, disconnect the cable and use a multimeter to verify it is receiving power and ground. Check the monitor screen and sky plots to see if there is any data from the receiver. If there is no data, but the receiver is powered, there could be a bad serial connection / mismatched baud rate.
No RTK	<ol style="list-style-type: none"> <li>1. If using a base station onsite (versus an NTRIP service), first check to verify the base station is turned on.</li> <li>2. If the base station is turned on and sending RTK out over UHF, check to see if the Tx (or TD on some radios) light is flashing once per second.</li> <li>3. Verify that the other rovers on the job site are receiving RTK corrections, if available.</li> <li>4. If it is flashing once per second, check to verify the settings (frequency, bandwidth, forward error corrections, modulation, and protocol) at the base match that of the rover.</li> <li>5. Check to see if the UHF light at the rover is blinking once per second. If it is, refer to #3.</li> <li>6. The receiver may be out of UHF range. Install the radio antenna (if using a VR1000). You may need to install repeaters. See if the RTK corrections work when the machine is closer to the base station.</li> <li>7. If using NTRIP, check cellular connectivity. One option is to exit GradeMetrix and verify you can go to a website via the browser.</li> </ol>

---

*Continued on next page*

## Troubleshooting, Continued

---

Troubleshooting,  
continued

**Table A-1: Troubleshooting (continued)**

Issue	Possible Solution
IronOne/IronTwo Will Not Power On	<ol style="list-style-type: none"><li>1. Check to verify the power cable is connected to machine power. The positive should go to a reliable, clean power source and ground to the chassis of the machine.</li><li>2. Disconnect the cable and refer to the pinout to see if 12V or 24V (depending on machine) is going into the IronTwo by using a multi-meter. If the multimeter reads 12V or 24V, then power is confirmed, and the IronTwo may need to be serviced. If you do not have any power, then check your power source, ground, and all fuses.</li></ol>

---

## Appendix B: Technical Specifications

### Overview

---

#### Introduction

Appendix B contains the technical specifications for the VR1000 GNSS receiver, the IronTwo control box, and the GMS-1 sensor.

---

#### Contents

	Topic	See Page
VR1000 GNSS Receiver		62
IronTwo		70
GMS-1 Sensor		72

---

## VR1000 GNSS Receiver

---

**VR1000 GNSS receiver** **Table B-1: VR1000 GNSS Receiver**

Item	Specification
Receiver Type	GNSS Position & Heading RTK Receiver
Signals Received	GPS, GLONASS, BeiDou, Galileo, QZSS, NavIC (IRNSS) and Atlas®
Channels	1059
GPS Sensitivity	-142 dBm
SBAS Tracking	3-channel, parallel tracking
Update Rate	10 Hz standard, 20 Hz optional
Timing (PPS) Accuracy	20 ns
Rate of Turn	100°/s maximum
Cold Start	40 s (no almanac or RTC)
Warm Start	20 s typical (almanac and RTC)
Hot Start	5 s typical (almanac, RTC, and position)
Heading Fix	10 s typical (Hot Start)
Antenna Input Impedance	50 Ω
Maximum Speed	1,850 mph (999 kts)
Maximum Altitude	18,288 m (60,000 ft)
Differential Options	SBAS, Atlas (L-band), RTK

---

*Continued on next page*

## VR1000 GNSS Receiver, Continued

---

VR1000  
accuracy

**Table B-2: VR1000 Accuracy**

Item	Specification	
<b>Positioning</b>	<b>RMS (67%)</b>	<b>2DRMS (95%)</b>
<b>Autonomous, no SA:<sup>2</sup></b>	<b>1.2 m</b>	<b>2.5 m</b>
<b>SBAS:<sup>2</sup></b>	<b>0.25 m</b>	<b>0.5 m</b>
<b>Atlas:<sup>2,3</sup></b>	<b>0.04 m</b>	<b>0.08 m</b>
<b>RTK:<sup>1</sup></b>	<b>10 mm + 1 ppm</b>	<b>20 mm + 2 ppm</b>
Heading (RMS)	< 0.2° @ 0.5 m antenna separation < 0.1° @ 1.0 m antenna separation < 0.05° @ 2.0 m antenna separation < 0.02° @ 5.0 m antenna separation < 0.01° @ 10.0 m antenna separation	
Pitch/Roll (RMS)	1°	
Heave (RMS)	30 cm (DGPS) <sup>3</sup> , 10 cm (RTK) <sup>3</sup>	

---

VR1000  
communications

**Table B-3: VR1000 Communications**

Item	Specification
Ports	1x full-duplex RS-232/RS-422, 1x full-duplex RS232, 2x CAN, 1x Ethernet
Baud Rates	4800 - 115200
Radio Interfaces	Bluetooth 2.0 (Class 2), Wi-Fi 2.4 GHz, UHF (400 MHz)
Correction I/O Protocol	Hemisphere GNSS proprietary ROX format RTCM v2.3, RTCM v3.2, CMR <sup>5</sup> , CMR+ <sup>5</sup>
Data I/O Protocol	NMEA 0183, Hemisphere GNSS binary
Timing Output	PPS, CMOS, active high, rising edge sync, 10kΩ, 10 pF load
Event Marker Input	CMOS, active low, falling edge sync, 10 kΩ, 10pF load

*Continued on next page*

## VR1000 GNSS Receiver, Continued

---

VR1000 power

**Table B-4: VR1000 Power**

Item	Specification
Input Voltage	9-36 VDC
Power Consumption	10.8W Maximum (All signals and L-band)
Current Consumption	1.2A Maximum
Power Isolation	No
Reverse Polarity Protection	Yes

---

VR1000  
environmental

**Table B-5: VR1000 Environmental**

Item	Specification
Operating Temperature	-40°C to +70°C (-40°F to +158°F)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Humidity	95% non-condensing
Mechanical Shock	50G, 11ms half sine pulse (MIL-STD-810G w/ Change 1 Method 516.7 Procedure 1)
Vibration	7.7 Grms (MIL-STD-810G w/Change 1 Method 514.7 Category 24)
EMC	CE ISO14982/EN13309/ISO13766/IEC60945), Radio Equipment Directive 2014/53/EU, E-Mark, RCM
Enclosure	IP69K

---

*Continued on next page*

## VR1000 GNSS Receiver, Continued

---

VR1000 L-  
band receiver

**Table B-6: VR1000 L-band receiver**

Item	Specification
Receiver Type	Single Channel
Channels	1530 to 1560 MHz
Sensitivity	-140 dBm
Channel Spacing	5 kHz
Satellite Selection	Manual or Automatic
Reacquisition Time	15 sec (typical)

---

VR1000 aiding  
devices

**Table B-7: VR1000 Aiding devices**

Item	Specification
Gyro	Provides smooth heading, fast heading reacquisition and reliable < 0.5° per min heading for periods up to 3 min. when loss of GNSS has occurred. <sup>4</sup>
Tilt Sensors	Provide pitch/roll data and assist in fast start-up and reacquisition of heading solution.

---

VR1000  
mechanical

**Table B-8: VR1000 Mechanical**

Item	Specification
Dimensions No Plate	23.2 L x 16.5 W x 7.9 H (cm) 9.1 L x 6.5 W x 3.1 H (in)
Dimensions with Plate	23.2 L x 21.4 W x 8.3 H (cm) 9.1 L x 8.4 W x 3.3 H (in)
Status Indications (LED)	Power, Primary Antenna, Secondary Antenna, Heading, Quality, Atlas, Bluetooth, Wi-Fi, CAN1, CAN2, Ethernet, Radio
Power/Data Connector	23-pin multi-purpose

*Continued on next page*

## VR1000 GNSS Receiver, Continued

---

<b>VR1000 footnote references</b>	<sup>1</sup> Depends on multipath environment, number of satellites in view, satellite geometry, no SA, and ionospheric activity <sup>2</sup> Depends on multipath environment, number of satellites in view, WAAS coverage and satellite geometry <sup>3</sup> Requires a subscription <sup>4</sup> Depends on multipath environment, number of satellites in view, satellite geometry, baseline length (for differential services), and ionospheric activity <sup>5</sup> CMR and CMR+ do not cover proprietary messages outside of the typical standard
---	--

---

## IronOne

IronOne  
system

**Table B-9: IronOne System**

Item	Specification
Processor	Intel Atom dual-core CPU E3825 @ 1.33 GHz
Storage	SSD 32GB, RAM 2GB
Operating System	Windows 10

IronOne  
mechanical

**Table B-10: IronOne Mechanical**

Item	Specification
Dimensions	22.9 L x 16.9 W x 5.2 H (cm) 9.0 L x 6.6 W x 2.0 H (in)
Weight	1.38 kg (3.04 lbs.)
Mount	Adjustable 1.5" RAM ball mount

IronOne  
environmental

**Table B-11: IronOne Environmental**

Item	Specification
Operating Temperature	-20°C to +70°C (-4°F to 158°F)
Storage Temperature	-40°C to +85°C (-40°F to 185°F)
Operating Humidity	30% ~ 95% (Relative Humidity)
Storage Humidity	45% ~ 80% (Relative Humidity)
Enclosure	IP67
Vibration	EP455 5.15

## VR1000 GNSS Receiver

IronOne  
power

**Table B-12: IronOne Power**

Item	Specification
Input Voltage	7 - 36 VDC
Power Consumption	36 W
Current Consumption	3.0 A @ 12 VDC

IronOne  
screen

**Table B-13: IronOne Screen**

Item	Specification
Display Type	8" TFT-LCD capacitive touchscreen
Size	192.8 mm × 116.9 mm (7.59" × 4.6")
Resolution	1280 × 720, 16:9
Luminance	750 nit

IronOne  
input

**Table B-14: IronOne Input**

Item	Specification
Power Button	1x mechanical waterproof button
Function Button	2x mechanical waterproof button
Ignition Input	Yes

*Continued on next page*

## VR1000 GNSS Receiver, Continued

---

### IronOne communication

**Table B-15: IronOne Communication**

Item	Specification
Serial Port	1x RS232×1, 1x RS422/RS485/RS232 (software controlled)
Camera Interface	2x CVBS
USB	1x USB 2.0
Ethernet	10/100
Wi-Fi	IEEE 802.11b/g/n
Cellular	4G LTE
Data I/O Protocol	NMEA 0183

### IronOne sensor and multimedia

**Table B-16: IronOne Sensor and multimedia**

Specification
1x 2W Buzzer
1x Headphone Jack

## IronTwo

---

### IronTwo system

**Table B-17: System**

Item	Specification
Processor	Intel® Celeron N3350
Storage	SSD 64GB, RAM 4GB
Operating System	Windows 10

---

### IronTwo mechanical

**Table B-18: Mechanical**

Item	Specification
Dimensions	263.28 W x 171 H x 35.7 D (mm) 10.4 W x 6.7 H x 1.4 D (in)
Weight	1.38 kg (3.04 lbs)
Mount	Adjustable 1.5" RAM ball mount

---

### IronTwo environmental

**Table B-19: Environmental**

Item	Specification
Operating Temperature	-20°C to +60°C (-4°F to 140°F)
Operating Humidity	30% ~ 90% (non-condensing)
Enclosure	IP65

---

*Continued on next page*

**IronTwo, Continued****IronTwo power****Table B-20: Power**

Item	Specification
Input Voltage	9 - 36 VDC

**IronTwo screen****Table B-21: Screen**

Item	Specification
Display Type	10.1" TFT edge-to-edge projective capacitive multi-touch screen
Size	192.8 mm × 116.9 mm (7.59" × 4.6")
Resolution	1920 × 1200, 800:1
Luminance	700 cd/m

**IronTwo communication****Table B-22: Communication**

Item	Specification
Serial Port	2 x RS232
CANBUS	2 × CANBUS
USB	2 × USB 2.0
Ethernet	2x 10/100 LAN
Wi-Fi	IEEE 802.11a/b/g/n/ac
Cellular	4G LTE
Bluetooth	Bluetooth 4.1

## GMS-1 Sensor

---

GMS-1 sensor  
measurement  
range

**Table B-23: Measurement range**

Item	Specification
Pitch	$\pm 180^\circ$
Roll	$\pm 85^\circ$

---

GMS-1 sensor  
accuracy

**Table B-24: Sensor accuracy**

Item	Specification
Absolute Accuracy	$\pm 0.30^\circ$
Resolution	$\pm 0.01^\circ$
Repeatability	$\pm 0.05^\circ$
Refresh Rate	20 Hz
Base Sensor Cycle	5ms
Hysteresis	$\pm 0.05^\circ$

---

GMS-1 sensor  
electrical

**Table B-25: Electrical**

Item	Specification
Supply Voltage	9 – 30 VDC
Current	$\leq 65\text{mA}$ @ 10 VDC
EMC Emissance	DIN EN 61000-6-4
EMC Immunity	DIN EN 61000-6-2

---

*Continued on next page*

## GMS-1 Sensor, Continued

GMS-1 sensor  
pin-outs




Figure B-1: GMS-1 Sensor pin-out

Table B-26: GMS-1 Sensor pin-out

Signal	Connector	Pin Number
Power Supply	Connector 1	2
GND	Connector 1	3
CAN High	Connector 1	4
CAN Low	Connector 1	5
CAN GND	Connector 1	1
Power Supply	Connector 2	2
GND	Connector 2	3
CAN High	Connector 2	4
CAN Low	Connector 2	5
CAN GND	Connector 2	1

## Appendix C: Cable Pin-Outs

### Overview

---

#### Introduction

Appendix C contains the cable pin-outs used for installation of the VR1000 and IronTwo.

---

#### Contents

	Topic	See Page
VR1000 Cables		75
VR1000 Installation Schematic		78
Index		80

---

## VR1000 Cables

P/N: 051-  
0419-10




Figure C-1: P/N: 051-0419-10

Table C-1: P/N: 051-0419-10 Pin-Outs

J1	J2	Signal
5	1	VR1000 Port A RS232 Rx
8	5	Power Ground
13	6	VR1000 Port A RS232 Tx
15	5	Power Ground
18	8	Signal Ground
19	2	Signal Ground
20	9	VR1000 Port B RS232 Tx
21	10	VR1000 Port B RS232 Rx
22	3	Power Positive
23	3	Power Positive

Continued on next page

## VR1000 Cables, Continued

P/N: 051-0420-10




Figure C-2: P/N: 051-0420-10

Table C-2: P/N: 051-0420-10 Pin-Outs

J1	J2	J3	Signal
1	1	NC	VR1000 Port A RS232 Rx
2	2	NC	Signal Ground
3	3	NC	Power Positive
5	5	NC	Power Ground
6	6	NC	VR1000 Port A RS232 Tx
8	NC	5	Signal Ground
9	NC	3	VR1000 Port B RS232 Tx
10	NC	2	VR1000 Port B RS232 Tx

*Continued on next page*

## VR1000 Cables, Continued

P/N: 051-  
0477-10





Figure C-3: P/N: 051-0477-10

Table C-3: P/N: 051-0477-10

C1	C2	Signal
2	2	VR1000 Port B RS232 Rx
3	3	VR1000 Port B RS232 Tx
5	5	Signal Ground

## VR1000 Installation Schematic

### VR1000 Installation Schematic

**Table C-4: Scraper Schematic-R232 and Power, IronOne -VR1000**

051-0408-10 J1 (IronOne)	051- 0408-10 J3	051-0420- 10 J1	051-0419- 10 J1	VR1000
2	1	1	5	VR1000 Rx (IronOne RS232 Tx)
3	6	6	13	VR1000 Tx (IronOne RS232 Rx)
5	2	2	19	Signal Ground
10	5	5	15	Power Ground
11	3	3	23	12V+ Out

**Table C-5: Scraper Schematic-R232 and Power, IronTwo -VR1000**

051-0426-10 J1 (IronTwo)	051- 0426-10 J3	051-0420- 10 J1	051-0419- 10 J1	VR1000
3	6	6	13	VR1000 Tx (IronTwo RS232 Rx)
4	1	1	5	VR1000 Rx (IronTwo RS232 Tx)
7	2	2	19	Signal Ground
10	3	3	22/23	Power+
12	5	5	8/15	Power Ground

## Index

GradeMetrix.....	6	radio antenna.....	29
installation .....	6, 40	RAM.....	37, 39, 67, 70
Installation Kit .....	37	VR1000.....	41, 62, 65, 66
Message interface.....	17		

# End User License Agreement

---

## End User license agreement

**IMPORTANT** - This is an agreement (the "Agreement") between you, the end purchaser ("Licensee") and Hemisphere GNSS Inc. ("Hemisphere") which permits Licensee to use the Hemisphere software (the "Software") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "Product". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "Software"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
  - a. install or use more copies of the Software than the number of copies that have been licensed;
  - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
  - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
  - d. modify or create derivative works based on the Software;
  - e. sub-license, rent, lease, loan or distribute the Software;
  - f. permit any third party to use the Software;
  - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
  - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
  - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("Update") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at any time.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™ XF1™, XF2™, Cygnus™, Atlas™ aRTK, SureFix™, Athena™, Aquila™, Lyra™, Outback Guidance™, and EDRISE™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners. and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential Ipositioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement

12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.
13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere.
19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a)

---

*Continued on next page*

# End User License Agreement, Continued

---

## End User license agreement

negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product, (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.

19. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
20. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
21. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
22. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
23. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
24. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
25. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
26. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

**GENERAL.** This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.



Hemisphere GNSS Inc.  
8515 East Anderson Drive  
Scottsdale, Arizona, US 85255  
Phone: 480-348-6380  
Fax: 480-270-5070  
[PRECISION@HGNSS.COM](mailto:PRECISION@HGNSS.COM)  
[WWW.HGNSS.COM](http://WWW.HGNSS.COM)